

PANEL DIAL SWITCHING SYSTEM

(BATTERY CUT-OFF — WITHOUT ZONE REGISTRATION)

TRAINING MANUAL

SEQUENCE CHARTS AND OPERATIONAL SKETCHES

THE AMERICAN TELEPHONE AND TELEGRAPH COMPANY

OPERATION AND ENGINEERING DEPARTMENT

PLANT OPERATION DIVISION

FOR TRAINING PURPOSES ONLY

FEBRUARY 1955

PREFACE

This provisional training material covers the Panel System, Battery Cut-Off type. - without Zone Registration

This manual contains a series of typical circuit diagrams. These are drawn in the simplified style which is used in teaching the complex 'Common Control' switching systems now in current use. This method makes use of sequence charts and operational sketches. This volume contains a chart and sketch for each of the typical circuits.

Since the drawings are intended to be used in the study of the Panel System, Battery Cut-Off type, without zone registration, and do not necessarily conform to any particular office, it may be necessary to consider the regular Schematic Drawings (SD's) and Circuit Descriptions (CD's) when preparing learners to work in a specific office.


Students should be cautioned that the particular circuits contained in this manual are intended to be used as training aids, and are not necessarily applicable for maintenance.

INDEX OF OPERATIONAL SKETCHES


TITLE	SKETCH NO.
LEGEND FOR OPERATIONAL SKETCHES	300
STARTING LINE FINDER	-301 - 1
TRIP & LINK CIRCUIT ALLOTING	-302 - 36
FINDING LINE	-303 - 2
LINE TRIP START & LINK CIRCUITS	-304 - 53
START CIRCUIT FAILURE ALL LINKS BUSY & OVFL.	-305 - 54
SUB. GROUP A & B KEY TRANS. AT LK. FR. LINK M. B., DIST. MB.	-306 - 55
DISTRICT BRUSH & GROUP SELECTION	-307 - 19
DISTRICT - TRUNK SELECTION TRUNK TEST	-308 - 10
DISTRICT ADVANCE - CABLE CHARGE	-309 - 27
TALK SELECTION & TRUNK CLOSURE	-310 - 28
CALLED PARTY SUPERVISION	-311 - 33
RELEASE OF DISTRICT - CHARGE CALL	-312 - 34
EARLY RELEASE - DIST POS 2/ 6 SDR POS 1/3	-313 - 42
ADVANCE LINK, PRESELECT DISTRICT	-314 - 31
DISTRICT OVERFLOW ON FULL MECHANICAL OR P. C. I. CALL	-315 - 43
DISTRICT TELL TALE-INCOMING TELL TALE	-316 - 44
2-PARTY DISTRICT - T RELAY TEST-PARTY TEST-CALLED PTY ANSWER	-317 - 37
2-PARTY DISTRICT - RETURN TO NORMAL	-318 - 38
SEIZING A SENDER	-319 - 3
SUBSCRIBER SENDER - REGISTRATION AND PULSE COUNTING	-320 - 4
" TRUNK HUNTING CABLE DISCHARGE	-321 - 22
FINAL BRUSH SELECTION	-322 - 23
" TENS & UNITS SELECTION	-323 - 24
INCOMING ADVANCE	-324 - 15
RELEASE OF SENDER	-325 - 26
SENDER TIME MEASURE SWITCH	-326 - 32
DIAL ZERO CALL	-327 - 50
STUCK SENDER SECOND TRIAL	-328 - 47
LATE RELEASE-FULL MECH. & OPERATOR CALLS	-329 - 51
	-330 - 49

TITLE	SKETCH NO.
P. C. I. IMPULSES & LINE PULSE DRAWING	-331 - 48 ABC/1/1/1
SEIZING A DECODER	-332 - 5
DECODER - REGISTRATION RELAYS & TEST OF RECEIVING LEADS	-333 - 6
" - HA - HB, TA - TB RELAY OPERATION	-334 - 7
" - GROUNDING A CODE POINT	-335 - 8
" - CLASS OF SERVICE RELAYS	-336 - 9
" - OPERATION OF ROUTE RELAYS	-337 - 10
" - TRANSMITTING CLASS INFORMATION	-338 - 11 ABC
" - " COMPENSATING RESISTANCE INFORMATION	-339 - 12
" - " DISTRICT BRUSH INFORMATION	-340 - 13
" - " DISTRICT GROUP "	-341 - 14
" - " OFFICE BRUSH "	-342 - 15
" - " OFFICE GROUP "	-343 - 16
" - " TALK SELECTION INFORMATION	-344 - 17
" - CHECK OF TRANSMITTING LEADS & RELEASE	-345 - 18 64
DECODER & CONNECTOR TIME OUT	-346 - 51
LINE TESTING	-347 - 29
RINGING & TRIPPING	-348 - 30
RELEASE OF INCOMING & FINAL	-349 - 35
LINE FINDER OVERFLOW & TELL TALE - INCOMING OVERFLOW	-350 - 45
FINAL TELL TALE	-351 - 46
OFFICE SELECTIONS AND OFFICE TEST	-352 - 21
COIN DISTRICT CALLED PARTY ANSWER - COIN CONTROL	-353 - 39
COIN DISTRICT RETURN TO NORMAL	-354 - 40
COIN DISTRICT LINE TEST - TALKING TO OPERATOR	-355 - 41



LEGEND FOR SEQUENCE CHARTS	SC-300
RECEIVER OFF HOOK TO SENDER SEIZURE	SC-301
DECODER FUNCTIONS	SC-302
APPENDIX A BASIC CIRCUITS	




RECEIVER




METHOD OF CONNECTING WIRING POINT TO POINT




REPEAT COIL




RETARD COIL WDS.




RETARD COIL 2 WDS.




NON LOCKING KEY



LOCKING KEY




HOOK CONTACTS




CONDENSERS




TRANSMITTER




DIAL



SEQUENCE SWITCH CAM AND SPRINGS




SILVER PLATED CAM




NO. 1 SPRING CLOSED ALL POSITIONS


NUMBERS INDICATE POSITIONS IN WHICH CAM IS BROKEN ON "A" CAM ONLY



ROTARY MAGNET




METHOD OF SHOWING INTERVAL OF INTERRUPTION




SEQUENCE SWITCH CAM CUTTINGS


1-5 MEANS CLOSED ONLY IN POS. 1 & 5
1/5 MEANS CLOSED CONTINUOUSLY POS. 1 TO 5 INC.
5/2 MEANS CLOSED CONTINUOUSLY POS. 5 TO 2 INC.




INTERRUPTER



CLUTCH MAGNETS
H.S. HIGH SPEED
L.S. LOW SPEED




COMMUTATOR SEGMENT AND BRUSH STRAPPING



COMMUTATOR BRUSHES
BANK TERM.
MULTIPLE BRUSHES
COMMUTATOR TERMINALS




PLUG



HANDSET




A.C. RINGER



GENERATOR




GROUND




WIRING NOT CONNECTED




WIRING CONNECTED




TERMINAL



TERMINAL STRIP




BUZZER



48V BATTERY



STRAP LEAD



CROSS CONNECT




ALTERNATE WIRING




RESISTANCE




FUSE



CONTACTS ON COIN ROTARY SELECTOR




24V BATTERY




JACK


RELAYS




FAST OPERATING
MAKE BEFORE BREAK CONTACTS




DASHPOT




2 INDUCTIVE WINDINGS
DIFFERENTIAL




SLOW OPERATING




POLARIZED




MARGINAL
2 INDUCTIVE WINDINGS
1 NON-INDUCTIVE WINDING




SLOW RELEASE




1 INDUCTIVE WINDING
1 NON-INDUCTIVE WINDING




NORMALLY OPERATED



INDICATES INNER
END OF WINDING
USUALLY CONNECTED
TO GROUND



ALTERNATING
CURRENT



1 INDUCTIVE WINDING
1 NON-INDUCTIVE WINDING

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
LEGEND FOR
OPERATIONAL SKETCHES
PANEL SYSTEM
BATTERY

OS-300

SHEET 1 OF 2


THE SYMBOLS AND CONVENTIONS FOR THE OPERATIONAL SKETCHES ARE THE SAME AS THOSE USED ON SCHEMATIC DRAWINGS (SD-1) WITH THE FOLLOWING EXCEPTIONS.

1. DETACHED CONTACT SYMBOLS ARE USED WHENEVER THEIR EMPLOYMENT AIDS IN SIMPLIFYING THE SKETCHES. THEY ARE SHOWN THUS:


(A) MAKE CONTACTS:

ALL RELAYS HAVING TOP AND BOTTOM SPRINGS.




ATTACHED CONTACTS



ALL RELAYS NOT HAVING TOP AND BOTTOM SPRINGS. (MULTI-CONTACT)





EQUIVALENT DETACHED CONTACTS





(B) BREAK CONTACTS:

ATTACHED CONTACTS





EQUIVALENT DETACHED CONTACTS




(C) TRANSFER CONTACT:

ATTACHED CONTACTS




EQUIVALENT DETACHED CONTACTS





(D) OTHER CONTACTS:

ATTACHED CONTACTS




EQUIVALENT DETACHED CONTACTS




(E) 206 AND SIMILAR TYPE SELECTORS.

ATTACHED CONTACTS




EQUIVALENT DETACHED CONTACTS



2. INNER ENDS OF WINDINGS ARE OMITTED.

3. BATTERY SYMBOL WITH THE NOMINAL VOLTAGE IS SHOWN THUS:



4. CONTACT PROTECTIONS IN GENERAL ARE OMITTED.

5. SEQUENCE CHARTS ARE IN GENERAL PROVIDED ON EACH SKETCH. THE DESIGNATIONS FOR ALL RELAYS OF WHICH THE OPERATING PATHS ARE SHOWN ON THE SKETCH ARE IN HEAVY CHARACTERS. ALL OTHERS ARE IN LIGHT CHARACTERS.

6. IN GENERAL STRAPPING OR MULTIPLE CONVENTIONS ARE OMITTED.

7. $\overline{TB0-TB9}$ INDICATES THAT THE MAKE CONTACTS (ONE EACH) ON RELAYS TB0 TO TB9 ARE WIRED IN PARALLEL.

8. $\overline{CB-}$ INDICATES A MAKE CONTACT ON ONE OF A SERIES OF CB RELAYS.

9. GA/GB INDICATES THAT EITHER GA OR GB DESIGNATION APPLIES.












10. $\overline{TR}$ JACK INDICATES A BREAK CONTACT ON THE TR JACK.

11. $\overline{MB}$ JACK INDICATES A MAKE CONTACT ON THE MB JACK.

12. $\overline{\text{ground}}$ INDICATES OFF-NORMAL GROUND

$\overline{\text{battery}}$ INDICATES OFF-NORMAL BATTERY

PLANT SCHOOL FOR TRAINING PURPOSES ONLY	
LEGEND FOR OPERATIONAL SKETCHES	
PANEL SYSTEM BATTERY CUT-OFF	OS-300




PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
STARTING LINE FINDER
PANEL SYSTEM
BATTERY CUT-OFF


OS-301

SHEET 1 OF 2



LINE, START & TRIP



(LO) OPR
(R) FAILS TO OPR
32 MA



(H) OP
(R) FAILS TO OP
64 MA




AFTER (H) OPR'S
(R) WILL OPR
ABOUT 144 MA


"GA" LOOPS THRU
ANY SWITCHES UNTIL
ONE IS FOUND IN POS 1

1 & 4 OF (P)
MADE ALWAYS

2 & 3 OF (P)
MADE 2/9
11/8



GA/CB LEAD SIMILAR
EXCEPT P & N CAMS USED
SEE








STA/STB
STA LEAD LOOPS
THRU ANY SS NOT
IN POS 1 TIL A
LINK SW IN POS 1
IS FOUND.

3 & 4 (P) MADE
ALWAYS

1 & 2 (P) NOT MADE
POS 1

LINE & LINK ALLOTING CKTS. ³⁶




1-10 AWAIT. CALL
2-11 HUNT. SNDR. & ROLLS NEXT LINK TO ALLOTING
9-18 AWAIT. ALLOTMENT

SD 20294-01 | LINE TRIP START & LINK CCTS.

**PLANT SCHOOL
FOR TRAINING PURPOSES ONLY**

TRIP & LINK CIRCUIT.
ALLOTING


PANEL SYSTEM BATTERY COT-OFF OS-302



DISTRICT

SEQUENCE CHART

(SHOWN ON OS#301)




THE (H) SHUNTS ITS OWN WINDING W/ A 50 A NON-IND. WDG OF (D) IN ORDER TO OPER QUICKLY. THE (A) IN TRIP CKT DOES NOT REQUIRE SH-OF (D)

DIST. R1 SWITCH

- 1. NORMAL
- 2. AWAIT. CALL/L.F. HUNT.
- 3. AWAIT. SNDR. FOR D. BR. SEL.

NOTES

- 1. WHEN "K" COMM. MAKES "TR" RELEASES BREAKS "ST"
- 2. WHEN "C" COMM. BREAKS "LF" RELEASES "H" OPERATES WHEN LINE IS FOUND.



(TR) - SHUTS DOWN WHEN []
(ST) - WHEN []




S.D. 21077-011 L.F. & DIST. C.T.
S.D. 20294-011 LINE, TRIP, START & LK. C.T.

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

FINDING LINE



PANEL SYSTEM
BATTERY C.T. OFF

OS-303




OTHER TRIP CKT'S OK
IF BR FAILS TO
TRIP AS P.45

TAI - ONE PER TRIP CIRCUIT
TAC - ONE PER LINE GROUP






CD 20294
P.6 P.13

S.D. 20294-011 LINE, TRIP, START & LINK CKT.
**PLANT SCHOOL
FOR TRAINING PURPOSES ONLY**
TRIP AND START CIRCUIT
TRIP CIRCUIT TIME OUT
PANEL SYSTEM
BATTERY CUT-OFF **OS-304**



SILENT THROW OVER

SEQUENCE CHART
ALL LINKS BUSY (A SUB GRP)SEQUENCE CHART
ALL LINKS BUSY -
(A AND B SUB GRPS)

Misc Row CTT

OF

1/2

48V

2

ALL LINKS BUSY

PB REG.

S.D. 20294-011 LINE TRIP, START & LINK CTT.

PLANT SCHOOL
FOR TRAINING PURPOSES ONLYSTART CIRCUIT FAILURE 54
ALL LINKS BUSY & OVERFLOWPANEL SYSTEM
BATTERY CUT-OFF 05-305



X $\boxed{P_2}^2$ $\boxed{P_2}^1$
Y 50.3

TO: CHECK FOR CROSSES IN COUNTER ROLLS


TOOTH PICK OPR (RL) & (MB)

— CRD TEST RFL-TOUCH MAKE CONTACT OF COUNTER,
COUNTER & PRIME will op only

GRO BACK CONTACT OF PRIME COUNTRIES & ASSOCIATED COUNTRIES will op.

GRD 5' to top of C. coralline

DIST. RI SWITCH
3. AWAIT. SDE.
4. BRUSH SELECTION
5. AWAIT SDE. (TRIP)
6. GROUP SELECTION




NOTES—

1. GRD ON DIST "A" COMM HOLDS "L" OPERATED
AND SHUNTS DOWN "STP" RELAY OVER "FT" LEAD.


2. WHEN A "000" COMM. HITS METAL SEGMENT
"STP" RELAY RELEASES, WHEN IT HITS INSULATED
SEGMENT SHUNT IS REMOVED AND "STP" OPERATES.

3. #10 COMM. HOLDS "L" RELAY OPERATED UNTIL
SELECTOR ROD IS CENTERED FOR BRUSH TRIPPING.

SOLID LINES ON SEQUENCE CHART DENOTES BRUSH SELECTION
DOTTED " " " " " GROUP



DISTRICT



"N" WIRING BATTERY SUPPLIED FROM OPERATED "RL" LOWER CONTACTS 3,2,1.
"M" WIRING BATTERY SUPPLIED FROM OFF NORMAL BATTERY.

FO3 will OP THEN FO1
NORMAL IN POS 2/3 TO
SAVE TIME NO NEED TO
ADD TIME DELAY
TO PROVEN


STP OPR FALSELY A/c CAPACITANCE

SENDER P2 SWITCH POS. - 2 BRUSH SEL.
" " " " - 3 GROUP SEL.
TO PUT (STP) ACROSS LOOP AFTER
BATT & GRD FROM LOOP

RL-1° DECOILING Cmp
SD° TIMING DELAY
TW° 2WD IN DIFF BLDG (APPS TIMING)

SEL	DB RELAY	SEL	DG RELAY
DB-0	NONE	DG-0	NONE
1	1	1	1
2	2	2	2
3	1-3	3	1-2
4	2-3	4	4
		5	5
		6	1-5
		7	2-5
		8	1-2-5
		9	4-5

TO SHEET 1
SEE OS#321
FOR LINK



(OF) WRONG POLARITY
WON'T OPR UNTIL - 48V PUT
TO - SIDE OF RELAY


SENDER

S.D. 2193-011-012-013 SUBS SDR CCT.
S.D. 20294-011 LINK CCT.
S.D. 21077-011 LINE AND B. DIST. CCT.

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

DISTRICT BRUSH AND
GROUP SELECTION 19


PANEL SYSTEM
BATTERY SYSTEM OS-307



AD WIRING

PANEL SYSTEMS
DECODER
TRANSMITTING CLASS INFORMATION
DDD FEATURES OS-6N 11B

11c




PANEL SYSTEMS
 DECODER
 DDD FEATURES

11c


OS-6P



1. FOR OPERS. ON DOTTED LINES SEE OS-325
2. FOR OPER CKTS. SEE OS-319
3. HD-1 SLOW REL. TO ALLOW HD TIME TO SUPPLY
OFF NOR. GRD. BEFORE HD-1 RELS.
4. CHARGE CABLE CAP TO PREVENT FALSE
OPERATION OF "A" DELAY.



(SC) OF SDR DOESN'T RELEASE ON (AVI).
... (SC) IN DIST DOES.



S.D. 21115-01 INC. SEL. CCT.
S.D. 21077-011 LF. & DIST. CCT.
S.D. 21193-011-012-013 SUBS. SDR.




PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

DISTRICT ADVANCE
CABLE CHARGE

PANEL SYSTEM BATTERY CUT-OFF	OS-309
---------------------------------	--------

25

SENDER



PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
TALK SELECTION AND
TRUNK CLOSURE
PANEL SYSTEM
BATTERY CUT-OFF

NO TST CALL

GROUND OVER TIP OF AC CIRCUIT UNDER CONTROL OF LTD OR OPERATOR

FIN. IN POS 6^{3/4}/7 OPA'S (S) IN FINAL.

(TK) DROPS & DOES NOT HOLD TO OPR (S)

SWITCH ROLLS TO 12 IN FINAL & NO

TST IS MADE BY (C) IN POS 10^{1/4}, ALLOWING FINAL
TO RIDE ONTO BUSY FINAL # SEE P. 26

(C) WILL NOT OPER IN
POS 7 AS IN NORMAL CALL.

X POS 6^{3/4}/7

- TK
- S

X [R] 9

(C) FAILS TO OPER. IN POS 7 A/C TK RELEASING THEREFORE NO TEST
MADE OF TEL # SLV AS SW. PASSES 10^{1/4}

X [R] 12

- C

X TK

X [R] 13

DISCONNECT P. 35


- TK

NO TEST EQUIP PUTS BATT TO SLV






X [R] 16

WITH S^O AS SWITCH PASSES POS 15^{1/4} (C) WILL NOT OPER P. 35

X S



PLANT SCHOOL FOR TRAINING PURPOSES ONLY	
CALLED PARTY SUPERVISION	33
PANEL SYSTEM BATTERY CUT-OFF	OS-311






S.D. 21193-011-012-013 SUBS. SDR. COT.
S.D. 21077-011 LINE, FIND. & DIST COT.

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

EARLY RELEASE
DIST. POS. 2/6 SDR. POS 1/3

PANEL SYSTEM BATTERY CUTOFF	05-313
--------------------------------	--------





S.D. 21079-011 LINE FIND & DIST COT.
S.D. 20294-011 LINE TRIP START & LINK COT.

PLANT SCHOOL FOR TRAINING PURPOSES ONLY	
ADVANCE LINK PRESELECT DISTRICT	31
PANEL SYSTEM BATTERY CUTOFF	06-314

Seattle WA

SEQUENCE CHART 43




NOTES ÷
1. WHEN DAILING IS COMP.
[R] IS ADV TO POS 15
UNLESS AM OPTION

S.D. 21077-011 LINE, F/ND, & DIST CCT.

**PLANT SCHOOL
FOR TRAINING PURPOSES ONLY**

DISTRICT OVERFLOW ON FULL MECHANICAL OR PCI CALL 43



PANEL SYSTEM BATTERY CUT-OFF	OS-315
---------------------------------	--------



INCOMING TELL-TALE

DISTRICT TELL-TALE

44





NOTE:

1. WHEN X ADVANCES INC. TO POS. 9, OPERATIONS IN SDR., INC. & DISTRICT ARE THE SAME AS OS-350 (INC. OVFL.) EXCEPT X ADV. SW. 12/15. # 45

2. INC GOES TO T₁ DUE TO NO COUNT DOWN W/ (LR) IN SDR. OPR.

SEE OS-313 FOR (LR) OPER ON ABANDONED CALL OS-330


SEE OS 321 FOR (LR) OPENING COUNTING RELAY PATH



DISTRICT

LINK

SENDER




SEE P. 42 FOR R₂ PATH TO ROTATE R₂ SWITCH TO NORMAL


S.D. 21077-011 LINE, FIND & DIST. CCT.
S.D. 21115-011 INCOMING CCT.

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

DISTRICT TELL-TALE 44
INCOMING TELL-TALE

PANEL SYSTEM
BATTERY CUT-OFF OS-316






[illegible]

NOTE!!
WHEN MAKING SECOND LINE TEST,
GROUND DETECTION ON TIP OR
RING OF LINE INDICATES LINE
TROUBLE. T RELAY OPERATES.
R1 SWITCH DIST. IN POS. 1G
RESTORE SELECTOR MANUALLY,
REFER LINE TROUBLE.


38 2 PARTY DISTRICT
RETURN TO NORMAL
PANF SYSTEM
BATTERY CUT-OFF 05-318




S.D. 21079-01 2 PARTY DIST CCT.	
PLANT SCHOOL FOR TRAINING PURPOSES ONLY	
TWO PARTY DISTRICT RETURN TO NORMAL 38	
PANEL SYSTEM BATTERY CHG-OFF	05-318

LINE FINDER FRAME
400 TERMINALS

399	A	B	360
360	BANK 9		399
359	A	B	320
320	BANK 8		359
319	A	B	280
280	BANK 7		319
279	A	B	240
240	BANK 6		279
239	A	B	200
200	BANK 5		239
199	A	B	160
160	BANK 4		199
159	A	B	120
120	BANK 3		159
119	A	B	80
80	BANK 2		119
79	A	B	40
40	BANK 1		79
39	A	B	0
0	BANK 0		39







SENDER

- NOTE 1 THE COMM. LOCKS THE C RELAY UNTIL THE SELECTOR ROD CENTERS ON THE TERMINAL.
- NOTE 2 WHEN THE LINK ADVANCES TO POSITION '3' LEADS T, R, FT, FR, & SC ARE CLOSED THRU THE SENDER.
- NOTE 3 THE FT & FR RELAYS & LEADS MAY BE OPEN OR CLOSED DEPENDING UPON THE SUBSCRIBER'S CLASS OF SERVICE.
- NOTE 4 WITH THE SB RELAY NORMAL, BATTERY IS SUPPLIED TO THE T RELAY OVER THE TE LEAD. WITH THE SB RELAY OPERATED THIS LEAD IS OPENED & THE T RELAY RELEASES.
- NOTE 5 IF ALL SENDERS ARE BUSY THE SELECTOR WILL CONTINUE TO RIDE UP UNTIL THE BRUSHES REACH THE TOP OF THE COMM. WHERE THE X SEGMENT WITH GROUND ON IT WILL OPERATE THE SW RELAY TO STOP THE UP-DRIVE & ENERGIZE THE DOWN-DRIVE MAGNET. WHEN THE SELECTOR HAS REACHED THE BOTTOM THE Y SEGMENT WITH GROUND WILL SHUNT DOWN THE SW RELAY AND ENERGIZE THE UP-DRIVE MAGNET AGAIN.

Idle SENDER
R&S 2100 ohm on TMS
OFF NORMAL GRD
(HD-1) OPR OR ANY
SEQ SW OFF NORMAL




SEQUENCE CHART



SEQ SW
R₁ - TIMING
R₂ - Selection
R₃ - P₂ 1

S.D. 21193-011-012-013 SUB. SDR. CCT.
S.D. 20294-011 LINK CCT.
S.D. 21077-011 LINE, FIND. & DIST. CCT.
PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
SEIZING A SENDER
PANEL SYSTEM
BATTERY CUT-OFF
OS-319



SEQUENCE CHART

RELAYS USED FOR INC. BRUSH SEL

THOUS.	INC	EVEN	ODD
0-1	1B-0	-	1S
2-3	1B-1	DB-1	1S DB-1
4-5	1B-2	DB-2	DB-3
6-7	1B-3	DB-3	DB-1
8-9	1B-4	1S DB-1	DB-2
		DB-3	DB-3

← will op. DG-2

NOTE-2
DG

* POSITION #11 IS FOR CABLE DIS-CHARGE


PLANT SCHOOL FOR TRAINING PURPOSES ONLY

INCOMING BRUSH & INCOMING GROUP

PANEL SYSTEM BATTERY-CUT-OFF

05-321

SHEET 1 OF 2




BRUSH STRAP

INC BANK	
GRP 3	
GRP 2	
GRP 1	
GRP 0	
INC FRAME	
BANK 4	2000 NO.
BANK 3	2000 NO.
BANK 2	2000 NO.
BANK 1	2000 NO.
BANK 0	2000 NO.
10,000 NO'S IN PANEL OFFICE	

NOTES-


1. GROUND ON [A] COMM. SHUNTS STP FOR INCOMING BRUSH SELECTIONS AND CONTROLS RELEASE OF L RELAY.
2. HT OPERATES AFTER HUNDREDS DIGIT HAS BEEN REGISTERED.
3. GROUND ON [B] COMM. SHUNTS STP FOR INCOMING GROUP SELECTIONS AND CONTROLS RELEASE OF L RELAY.
4. GROUND ON [Z][C] CONTROLS RELEASE OF T RELAY FOR BRUSH CENTERING. FOR O GROUP OMIT [Z].
5. WHEN A OR B COMM. HITS INSULATED SEGMENT, SHUNT IS REMOVED FROM STP AND IT OPERATES.



INCOMING SWITCH POS.


1. NORMAL (YELLOW STRIPE)
2. BRUSH SELECTIONS
3. ANTG SENDER-TRIP
4. GROUP SELECTION
5. ANTG. T RELAY
6. TRUNK HUNTING

USED DURING FINAL SELECTIONS TO SHUNT (STP)




TO SHEET 2






SEQUENCE CHART



Note 1: When C Comm. Brush makes on insulation T relay releases.

CHECK (To) INT IF INC. STAYS IN POS 8
BECAUSE FINAL SELECTIONS ARE DELAYED -
SENDS CALL TO OVFL.
SEE HANDOUT ON P. 45

THRU LINK & DIST.
TO INC.
SEE OS # 321





Pos 11 in SDR = DISCHARGE CABLE
SO (STP) WON'T OPR FALSELY

S.D. 21115-01 INC. SEL. CCT.
S.D. 21193-011-012-013 SUBS. SDR. CCT.
PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
INCOMING TRUNK HUNTING
CABLE DISCHARGE
PANEL SYSTEM
BATTERY CUT-OFF **OS-322**

SENDER

SEQUENCE CHART







PUTS POTENTIAL TO CABLE
TO CHARGE CABLE CAPACITY SO WHEN
IS APPLIED IT WILL NOT FALSE
OPR IN P32 12

SEQUENCE CHART






FINAL TENS



STRAPPING



OG5 OG4 OG2 OG1



SENDER

SHEET 2 OF 2


S.D. 21200-01 FINAL SEL. CCT.
S.D. 21193-011-012-013 SUBS. SDR. CCT.
PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
FINAL TENS AND UNITS SELECTION
PANEL SYSTEM BATTERY CUT-OFF
OS-324

SENDER

IF SDR FAILS TO
RECEIVE REV BATT
POS. 17

CHECK FOR POSSIBLE F/C
RING SPR IN DIST TO
SHUNT BATT IN POS 10

INCOMING






INCOMING

FINAL

(TK) will be OPR 1/10 IF
(S) IS RELEASED


SEQUENCE CHART

26



NOTES :

1. D RELAY IS SLOW RELEASE TO GIVE TIME FOR SENDER RELAYS TO OPERATE BEFORE IT OPENS FUND. CIRCUIT.
2. IN POS. 9 INC. WE HAVE REVERSED BATT AND GRD, WILL OPERATE OF AND STP IN SERIES
3. IN POS. 8 FINAL WE HAVE GRD ON R AND T TO INC. WHICH WILL OPERATE L AND T RELAYS IN INC.
4. T RELAY WILL LOCK UP IN POS. 8 AND 9 TO MAKE SURE THE SWITCH MOVES IN CASE THE L RELEASES.
5. D STAYS OPERATED IN POS. 8. TO POS. 9. OF INC. UNTIL (T) OPER. POS. 9



S.D. 21200-011 FINAL CCT.
S.D. 21115-011 INC. CCT.
S.D. 21193-011 SUBS. SDR. CCT.


PLANT SCHOOL FOR TRAINING PURPOSES ONLY

INCOMING ADVANCE


**PANEL SYSTEM
BATTERY CUT-OFF**

OS-325


SENDER R2 TO 1




LINK R TO 6 OR 15




SEQUENCE CHART



SENDER




DISTRICT



LINK


SENDER TIME SW. R1 TO 1



LINK SW. POS.


- | | |
|------|--|
| 1-10 | AWTG. CALL |
| 2-11 | HUNT SDR. |
| 3-12 | AWTG. SDR |
| 4-13 | PASS BY |
| 5-14 | CUT THRU |
| 6-15 | RETURN FROM LAST 20 SDR TERM OR PASS BY. |
| 7-16 | HUNT DIST OR OUT OF SER. |
| 8-17 | AWTG. DIST. |
| 9-18 | AWTG. ALLOTMENT |

SENDER



LINK R TO POS 9

AFTER IDLE DIST FOUND





- NOTES:
1. ALL LEADS OPEN TO SDR. WHEN LINK LEAVES POS. 5.
 2. LAST SOURCE OF OFF NOR. GRO. REMOVED.

S.D. 20294-011 LINE TRIP START & LINK C.T.
S.D. 21077-011 LINE FIND & DIST. C.T.
S.D. 21193-011-012-013 SUB. SDR. C.T.
PLANT SCHOOL FOR TRAINING PURPOSES ONLY
RELEASE OF SENDER 32
PANEL SYSTEM BATTERY CUT-OFF **OS-326**


1. MEASURES TIME TO DIAL FIRST DIGIT. 30/60 SEC. POS. 2/3 POS. 4 PERM. SIGNAL.
2. MEASURES TIME TO DIAL UNITS DIGIT. 30/60 SEC. POS. 5/6 POS. 7 PARTIAL DIAL SIGNAL.
3. MEASURES TIME TO DIAL STATIONS DIGIT. 4 SEC. POS. 8/11.
4. MEASURES TIME TO COMPLETE CALL. POS. 12/14 PASS BY POS. 15/17 AWTG. RELEASE. POS. 18 STUCK SENDER. FULL MECH. CALL 30/60 SEC. P.C.I. & T.W. OFFICE CALLS 60/90 SEC.

SEQUENCE CHARTS


50



SENDER




DISTRICT



3(P) & 3(Q) MAKING FALSELY
ON OPR TYPE CALLS CAN PREVENT
DROPPING OF TB IN TRUNK CKT
CAUSING D.T.A. IN SOME DISTRICTS

SD 6D-21077
GRO FROM REPEAT COIL IN PDS 16

TRUNK EQUIPMENT



TO OS
308 & 348 p 3

BATT & GRD
FROM OPR PLUG OPR
(CS) IN DIST


HOLDS (L)
IN DIST
FROM POS 15 1/4 TO 16

PLUG
OPR'S (CO) &
SENDS REV BATT
& GRD TO DIST


TO OGT
TST. AND
MB JK.

TO MACHINE
AUD. RING

"A" BOARD



SEQUENCE CHART



SD 21193 SD 21077
PAR 74 PAR 14
P. 87

S.D. 21000-011 S.S.O. TRUNK C.T.
S.D. 21077-011 LINE, FIND & DIST C.T.
S.D. 21103-011-012-013 SUBS. SDR. C.T.

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY



DIAL ZERO CALL 47

PANEL SYSTEM
BATTERY CUT-OFF OS-328


AUX SDR LINE

SAME AS HOLD MAG


ST - Relays



STUCK SENDER



SECOND TRIAL



S.D.21193-011-012-013 SUBS.SDR.CCT.

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

STUCK SENDER 51
SECOND TRIAL


PANEL SYSTEM BATTERY CUT-OFF OS-329

DIAL ZERO


611
411

SD-21193
Rev. 89
P. 41


SEQUENCE CHART



SENDER




DISTRICT



DIST & LF MUST BOTH BE NORMAL BEFORE LR-1 WILL OPERATE


FULL MECHANICAL SENDER

DISTRICT




- NOTES:
- SDR. COMPLETES WHATEVER IS LEFT OF OFFICE TEST, OFF. GP. AND TRK. TEST.
 - INC. OR FINAL TO TELL-TALE BECAUSE LR OPENS COUNTING RLY. CIRCUIT.

SEQUENCE CHART



ABANDONED CALL

S.D. 21077-011 LINE, FIND. & DIST. CCT.
S.D. 21193-011-012-013 SUBS. SDR. CCT.
PLANT SCHOOL FOR TRAINING PURPOSES ONLY
LATE RELEASE
FULL MECH. & OPR. CALLS
PANEL SYSTEM BATTERY CUT-OFF **OS-330**



PCI TRUNK CIRCUIT

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

PCI IMPULSES

PANEL SYSTEM
BATTERY CUT OFF

OS-331






REG. RELAY CIRCUIT

NOTES

- #2 & #3 Springs make 1/4 before & after Pos. indicated.
- #3 Spring makes 1/2 before & after Pos. indicated.
- #2 Spring makes 1/2 after Pos. indicated.
- FP & FPI releases when R3 leaves Pos. 10 on 2nd rev.
- SP operates from C1 relay.
- LR & LRI operates abandoned calls.
- + & - sent over tip, - & = sent over ring.
- ⓵ Furnishes - 2nd period ⓶ Furnishes = 2nd & 4th period.
⓷ Furnishes - 4th period ⓸ Furnishes + 1st period ⓹ Furnishes + 3rd period.
- + Pulses are never sent in both 1st & 3rd periods.
- Pulses are sent in both 2nd & 4th period regardless of reg. relays.
= IS superimposed in 2nd & 4th period by Reg. relays.

PULSE CHART

Pulse Code Chart for 3 digit senders						
Sta.	Thou	Other	Pulses			
			1st	2nd	3rd	4th
0	0	0	-	-	-	-
1	2	1	+	-	-	-
W	4	2	-	-	-	-
R	6	3	+	-	-	-
J	8	4	-	-	+	-
M	1	5	-	-	-	-
	3	6	+	-	-	-
	5	7	-	-	-	-
	7	8	+	-	-	-
	9	9	-	-	+	-
1st CYCLE STA			16 3/4 1/4	17 1/2 1/8 1/2	18 3/4 1/3 1/4	19 1/2 1/20 1/4
2nd " TH			20 1/4 1/4	1 1/2 1/2 1/2	2 3/4 3/4	3 1/2 1/2
3rd " H			4 3/4 5/4	5 1/2 6/2	6 3/4 7/4	7 1/2 8/2
4th " T			8 3/4 9/4	9 1/2 10/2	10 3/4 11/4	11 1/2 12/2
5th " U			12 3/4 13/4	13 1/2 14/2	14 3/4 15/4	15 1/2 16/2
Final Heavy pulse			17 3/4 18 1/4 (2nd Rev.)			



SEE OS-320
FOR R3
W/ MAX SDR.

R3
P67

SEE 48 B

S.D. 21193-011-012-013 SENDER

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY


PCI IMPULSE

48

PANEL SYSTEM
BATTERY CUT-OFF

OS-331

SHEET 2 OF 4



NOTES

OT - POSSIBLE {STA DELAY}	A	ABOVE AND PARTYS - NONE
	B	ABOVE AND NO PARTYS - SD
OT - IMPOSSIBLE {STA DELAY}	C	BELOW AND NO PARTYS - SD, SDI
	D	BELOW AND PARTYS - SDI

2. 33CAM ADVANCES SW FROM 3 TO 4/4 ON TAN.

3. 83CAM ADVANCES SW FROM 6 TO 16/4 ON DIRECT

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY


P.C.I. IMPULSES

PANEL SYSTEM
BATTERY CUT-OFF OS-331


SHEET 3 OF 4

SEE NOTE 3


STATIONS
W




THOUSANDS
2





HUNDREDS
3



TENS
7



CSTA
UNITS
5



- NOTE 1. HEAVY POSITIVE ON "FT" TO ADVANCE P.C.I. CONTROL.
- NOTE 2. FP NORMAL AT POS. 11 GRD. 17/18 1/4 FROM T3 ON "FR."
- NOTE 3. ALL CAMS HAVE 1/4 POS. OVERLAP EXCEPT AT STARTING POINTS WHICH HAVE 1/2 POS. OVERLAP.

NOTE 1

NOTE 2

S.D. 21193-011-012-013 SUBS. SDR. C.C.T.


PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

LINE PULSE CHART 486


PANEL SYSTEM BATTERY CUT-OFF OS-331

SHEET 4 OF 4


AUX SNOR LINK



AP AP B Relays




SEQUENCE CHART







(SS) will op (Lower can op)
HIGHEST (SF) will op IF MORE THAN 1 (SS) op
(DS) (Lower can op)
HIGHEST (DF) " " IF MORE THAN 1 (DS) op.

NOTE 1 - THE CB RELAY DOES NOT OPERATE IN THE DECODER CONNECTOR IN USE ON THIS CALL. THE CB RELAYS ASSOCIATED WITH THE DECODER IN USE ARE OPERATED IN ALL OTHER CONNECTORS.



S.D.21193-011-012-013 SUBS SDR. CCT.
S.D.21187-011-012 DECODER CONN. CCT.
PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
SEIZING A DECODER
PANEL SYSTEM BATTERY C.T. OFF OS-332





IF CK1, CK2 LEADS GROUNDED
CK1 & CK2 WILL NOT RELEASE

DATA RELAYS
WILL BE GROUNDED
IF SDR RELAYS

Continuity ✓
OF DEC LEADS

NOTES

1. IN K.P. SDRS. RELAYS PS, FT, AND FR ARE OMITTED. LEADS PS, DI, D2 ARE STRAPPED TO CK1. LEAD KS IS CONNECTED TO GRD. LEAD D3, IS CONNECTED TO CK1 OR TO GRD. AS REQUIRED FOR CLASS INDICATION.
2. WHEN CK2 OPERATES, ALL DECODER RELAYS ASSOCIATED WITH NONOPERATED SENDER RELAYS RELEASE.
3. D3A RELAY FURNISHED IF REQUIRED
4. WHEN ANY OF RELAYS DI, D2, D3, OR D3A ARE OMITTED, LOOP LEADS AT POSITION OF THESE RELAYS.

NOTE 3

S.D. 21193-011-012-013 SUBS. SDR. CCT.
S.D. 21187-011-012 DECODER CONN. CCT.
S.D. 21277-011/019 DECODER CCT.



PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

DECODER
REGISTRATION RELAYS AND
TEST OF RECEIVING LEADS

PANEL SYSTEM
BATTERY C.T. OFF


OS-233

ISSUE
11-3-50



S.D.21277-011/019 DECODER CCT.

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY 7DECODER
HA-HB, TA-TB RELAY OPERATION
FOR GROUNDING CODE PT.PANEL SYSTEM
BATTERY CUT-OFF OS-334




S.O. 21277-011/109 DECODER C.C.T.

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY


DECODER
GROUNDING A CODE POINT

PANEL SYSTEM
BATTERY CUT-OFF

OS-335



SEQUENCE CHART



- 1. LETTERS IN PARENTHESIS DENOTE OPTIONAL APPARATUS
- 2. APPARATUS (A),(B),(C),(D),(E),(F),(G),(H),(J),(K),(L), AND (M) ARE FURNISHED AS REQUIRED TO DISTINGUISH THE VARIOUS CLASSES OF SERVICE SERVED BY THE OFFICE
- TYPICAL USAGE OF RELAYS D1, D2, & D3 (FOR 5 CLASSES)
- CLASS OF SERVICE D-RELAY OPERATED SA-RELAY OPERATED
- ELITE RATE Non-Coin NONE SA1 - Non-Coin
- MESSAGE RATE Coin D1 "FT" GRD FROM LINK SA2 - Coin
- PUBLIC COIN D2 "FR" GRD FROM LINK SA3
- SEMI PUBLIC D1, D2 SA4
- OPERATOR D3 SA5
- 3. WHEN ANY OF APPARATUS (A),(B),(C), OR (D) IS NOT FURNISHED, LOOP LEADS AT THE POSITIONS OF THE RELAYS NOT FURNISHED AS FOLLOWS.

APPARATUS OMITTED	A	B	C	D
LOOP LEADS DESIGNATED	K	E,&F	G,&H	J,&L

SA1 & SA2 ARE USED ONLY ON SPECIAL CODES
IE; OPR - CAME - ETC - VAC

OPR'S ONLY ON COIN CALLS FROM OPR'D (FT) IN SDR

OPR'S ON ALL CALLS FROM CK3 LEAD

S.D. 21177-011/019 DECODER C.C.T.


PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

DECODER
CLASS OF SERVICE RELAYS

PANEL SYSTEM
BATTERY COT-OFF




9

OS-336



TS ⊗ FOR DIST POS 14 TLK CHG POS
DBP ⊗ TALK SEL-1

CODE GROUP
OR CODE
POINT TERMS




NOTE 1

722

878




FOR TRAINING ONLY



CLASS OF SERVICE

SA-1 NON-COIN } USED ONLY ON SPECIAL CODES
SA-2 COIN } SUCH AS CAMA - OPR - VAC
- OTHERWISE CODE POINT WILL BE
WIRED TO (R) INSTEAD OF SA's.



TO PREVENT GRD FROM FEEDING BACK
TO OTHER CODE POINT

NOTES

1. R RELAYS ARE STRAPPED IN GROUPS OF 5 PER E PUNCHING.
2. OPERATING CIRCUIT OF SA-RELAY SHOWN ON OS 336
3. DOTTED LINES ARE CROSS CONNECTIONS.
4. FOR OTHER CROSS CONNECTION DATA SEE BSP SECT. A 362.007

BSP 215-141-301

S.D. 21277-011/D19 DECODER

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

OPERATION OF
ROUTE RELAYS

PANEL SYSTEM
06-337

ISSUE
H-3-50


SENDER

DECODER
CONNECTOR

SEE OS 6N
OR
11 B

DECODER

11 A



CLP 10
CLX 0.3
OPR'S WHEN TROUBLE
CLS & CLP BOTH OPR.
OR 2 SEC
AND/OR 2 PRI ARE OPR.

S.D. 21277-011/019 DECODER C.C.T.
PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
DECODER 11-A
TRANSMITTING CLASS INFORMATION
PANEL SYSTEM BATTERY CUT-OFF **OS-338**

SEE OPPOSITE P. 11A

OS-308 # 20

DECODER


(MTG) FOR PANEL, X-BAR, FULL SELECTOR
\$ FOR X-BAR, TRUNK WHERE LOOP $\Omega = 1300 \Omega$ OR LESS

(TG) IS USED ON ALL PANEL & X-BAR TRUNK GROUPS
WHILE LOOPS ARE OVER 1300 Ω AND ALL OTHER
TRUNK GROUPS REGARDLESS OF RES. BSP 215-141-301 P. 2.75 & 2.76

SENDER

DECODER
CONNECTOR

MTG
FOR TT
CR5



S.D.21277-011/019 DECODER CCT.
PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
DECODER
TRANSMITTING COMPENSATING
RESISTANCE INFORMATION
PANEL SYSTEM
BATTERY CUT-OFF
OS-339


ISSUE
11-6-50

DECODER



DECODER CONNECTOR

SENDER

ISSUE 11-3-50



NOTE 1
WINDING RES-
ISTANCE OF RELAYS
DB-1-DB3
R-1322 P1000 S2000
or
R-1968 P1000 S2500





DB0-DB5
PRI. WINDING-390
SEC. WINDING-390

NEEDED TO OPER
(TS) FOR TALKING
SEL SEE #17

S.D. 21277-011/019 DECODER C.C.T.
PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
DECODER
TRANSMITTING DISTRICT BRUSH
PANEL SYSTEM
BATTERY CUT-OFF
OS-340


ISSUE 11-3-50






Note 1: Winding resistance
at relays TS & TSI
E6451 P1000 S1500
or
R1066 P1000 S2500

S.D. 21277-011/019 DECODER COT.	
PLANT SCHOOL FOR TRAINING PURPOSES ONLY	
DECODER TRANSMITTING TALK SELECTION INFORMATION	
PANEL SYSTEM BATTERY CUT-OFF	OS-344



NOTE:
▲ CONN. TO TROUBLE INDICATOR

S.D.21277-011/012 DECODER CCT.
PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
DECODER
CHECK OF TRANSMITTING LEADS
AND RELEASE
PANEL SYSTEM
BATTERY CUT-OFF
OS-345



4 CONDITIONS OF CALLED LINE



1. IDLE IND OR PARTY S(O) C-
2. IDLE P.B.X. LINE S(O) C-
3. BUSY IND. OR PARTY S(O) CX (DD)
4. BUSY P.B.X. LINE S(NO) CX (UP)

"S." RELAY VALUES

OPERATE	.0134	12.7 ma
NOI-OPERATE	.012	

NOTES - (C STILL OPERATED POS. 12 BUSY BACK)

1. "C" RELEASES WHEN SWITCH PASSES 10 1/4.
2. "S" OPER. ON AL IDLE ILO OR IDLE
LAST LINE OF P.B.X. ONLY
3. IF AL IDLE LINE IS FOUND C RELEASES.



SLV CONDITIONS


SO 48V IDLE LINE
 GRD + 3V = BSY PBX (S)
 GRD + 8V = BSY IND (S)

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

LINE TESTING



PANEL SYSTEM BATTERY CUT-OFF	OS-347
---------------------------------	--------

INCOMING




NOTES:

1. WHEN SUB. ANSWERS
2. "C" FLASHES ON B.B. SIGNAL
3. "CS" OPERATES ON REV. BATT. FROM TRK. CKT.




**BUSY
LINE**

NO CHG
IN DISC




**IDLE
LINE**

ENG in DIST



FINAL

Sup 1 5400T # 22



1 PER SIDE OF FRAME
DETECTS FALSE GRID
ON SWEEPING CONT
OF LB INT


S.D. 21115-011 INC. CCT.
S.D. 21200-01 FINAL CCT

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY


RINGING AND TRIPPING 30

PANEL SYSTEM BATTERY CUT-OFF	OS-348
---------------------------------	--------


INCOMING




FINAL



INCOMING





FINAL



✓ NOTES:-
 I.C. OPERATES IN POS. 15/15 1/4
 AND LOCKS TO POS. 17 IF R.O.H. ← OFF
 OTHERWISE C RELEASES IN
 POS. 16

S.D. 21115-011 INC. CCT.
 S.D. 21200-01 FINAL CCT.
PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
 RELEASE OF INCOMING 35
 AND FINAL
 PANEL SYSTEM
 BATTERY CUT-OFF **OS-349**

ISSUE
 11-6-50






S.D. 20294-011 LINE, START, TRIP & LINK CCT.
S.D. 21115-011 INC. CCT.
S.D. 21077-011 LINE, FINO, & DIST. CCT.

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

INCOMING OVERFLOW AND⁴⁵
LINE FINDER OVERFLOW




PANEL SYSTEM BATTERY CUT-OFF	OS-350
---------------------------------	--------




NOTE 1. IF FINAL TELL-TALE OCCURS DURING P.B.X. HUNTING, SDR. WILL HAVE COMPLETED FINAL SELECTIONS AND RECEIVED REGULAR INC. ADV. SIG. THEREFORE SDR. WILL MAKE REG. TALK SELECTION AND SUB. WILL RECEIVE REG. BUSY BACK. GIVES BUSY BACK

S.D. 21200-01 FINAL CCT.
PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
FINAL TELL TALE 46
PANEL SYSTEM BATTERY CUT-OFF OS-351

ATTACH ONE SIDE OF DOUBLE CONNECTION LAMP TO DIST (E) CAM } (DEPENDING ON DIST)
 GRD OTHER SIDE OF LAMP
 LIFT (E) 3 SPRING AWAY FROM THE CAM



IND 4 (B) CAM
 PRY 3 (E) CAM




WHEN TESTING GO TO 24V W/TEST REC TO SPRING ATTACHED TO SLV - W/ PROBE LIFT SPRING

CLICK ON CAM = NO DEL
 NO CLICK ON CAM = DEL

SEQUENCE CHART

SENDER

OFFICE GROUP & TRUNK SEL.



OVER FLOW
TALL TALE




G
 O
 S
 T
 R

B, Y
 A, Z, X
 C

3.ON SKIP OFFICE CALL SO HOLDS FOI LOCKED
UP & MOVES R2 SWITCH TO #7 FOR TRUNK TEST.

21

08 307




3. DIST. GROUP
4. OFFICE TEST
5. OFFICE BRUSH
6. OFFICE GROUP
7. TRUNK TEST

PANEL SYSTEM BATTERY CUT-OFF	OS-352
---------------------------------	--------

SHEET 2 OF 2


OS-352




SHEET 1 OF 1

ISSUE
JAN. 1950

TO SHEET 1
C




NOTE 1: ALL IDLE COIN CONTROLS
ON SAME SIDE OF FRAME.



USE SD-21078
FOR COIN
THIS DRAWING
NO GOOD

SD. 21350-01 COIN DISTRICT
PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
COIN DISTRICT CALLED PARTY
ANSWER, TIMING CONNECTION
TO COIN CONTROL
PANEL SYSTEM
BATTERY CUT-OFF
OS-353


SHEET 2 OF 2



PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
COIN DISTRICT
RETURN TO NORMAL
PANEL SYSTEM
BATTERY CUTOFF


110V- BAT THRU NORMAL C NO CHARGE
TO T&R COIN RETURN

SHEET 1 OF 2



OLD OPTION
IF COIN STILL
IN BOX
T A R
GRD.


ISSUE I
JAN. 1950




S.D. 21350-011 COIN DISTRICT
PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
COIN DISTRICT 40
RETURN TO NORMAL
PANEL SYSTEM BATTERY CUT-OFF OS-354

SHEET 2 OF 2

FAILURE TO
COLLECT OR REFUND
ON DISCONNECT





S.D. 21350-01 COIN DISTRICT
 PLANT SCHOOL
 FOR TRAINING PURPOSES ONLY
 LINE TEST
 TALKING TO OPERATOR
 PANEL SYSTEM
 BATTERY CUT-OFF

OS-355

SHEET 2 OF 2

SD-96479-01 AUX SDR
SD-96483-01 AUX SDR LINK

HEAVY NEGATIVE & LIGHT POSITIVE

48B

REG. RELAY CIRCUIT

NOTES

- #2 & #3 Springs make 1/4 before & after Pos. indicated. 3P
- #3 Spring makes 1/2 before & after Pos. indicated. 3F
- #2 Spring makes 1/2 after Pos. indicated. 2S
- FP & FPI releases when R3 leaves Pos. 10 on 2nd rev.
- SP operates from C1 relay.
- LR & LRI operates abandoned calls.
- + & - sent over tip, - & = sent over ring.
- ① Furnishes - 2nd period ② Furnishes - 2nd & 4th period.
③ Furnishes - 4th period ④ Furnishes + 1st period ⑤ Furnishes + 3rd period
- + Pulses are never sent in both 1st & 3rd periods.
- Pulses are sent in both 2nd & 4th period regardless of reg. relays.
= IS superimposed in 2nd & 4th period by Reg. relays.

IF NO DIGITS DIALED
INTO STATIONS A
0 IS SENT

PULSE CHART

Pulse Code Chart for 3 digit senders						
Sta.	Thou	Other	1st	2nd	3rd	4th
0	0	0	-	-	-	-
1	2	1	+	-	-	-
W	4	2	-	-	-	-
R	6	3	+	-	-	-
J	8	4	-	-	+	-
M	1	5	-	-	-	-
	3	6	+	-	-	-
	5	7	-	-	-	-
	7	8	+	-	-	-
	9	9	-	+	-	-
1st CYCLE STA	16 3/4	17 1/2	18 1/4	19 1/4	20 1/4	21 1/4
2nd " TH	20 1/4	21 1/4	22 1/4	23 1/4	24 1/4	25 1/4
3rd " A H	24 1/4	25 1/4	26 1/4	27 1/4	28 1/4	29 1/4
4th " B T	28 1/4	29 1/4	30 1/4	31 1/4	32 1/4	33 1/4
5th " C U	32 1/4	33 1/4	34 1/4	35 1/4	36 1/4	37 1/4
Final Heavy pulse	37 1/4	38 1/4	39 1/4	40 1/4	41 1/4	42 1/4






(FP) REL 1st 2nd Rev
(TAN) ROTORS 17 1st Rev

R₃ SW Rotations

(OT) ⁰	(OT) ¹	(OT) ²
7 DG	10 DG	TAN
AUX SDR	AUX SDR	PCI
1st 2nd	1st 2nd	1st 2nd
TH	A	STA
H	B	TH
A	T	X
B	U	O
C	STA	X
	H	C
	U	FD

TENS & DMS
INTO
AUX SDR

10 DG	11	X	D	X	A	B	C	TH	H	TU
REGISTER	A	B	C	TH	H	T	U	STA	1st	AUX



R₃ Switch

Pos 17 PCI DIR STA-TH-H-T-U-FP
5 TAN PCI A-B-C-STA-TH-H-T-U-FP
5 7 DG AUX A-B-C-TH-H-T-U-STA
5 10 DG AUX X-D-X-A-B-C-TH-H-T-U-STA

(AS)⁰ (AS-1)⁰ (AS-2)⁰ (OT)⁰ = SEND DIGITS IN ORDER DIALED

ED-21193-01 APR 103.17

PAR. 63-73



















S.D. 21193-011-012-013 SENDER

PLANT SCHOOL
FOR TRAINING PURPOSES ONLY

PCI IMPULSE 48B


PANEL SYSTEM
BATTERY CUT-OFF OS-32

SHEET 2 OF 4




CD-21193
Rev. 3.31
FOR OVERFLOW

SKETCH 16



TRUNK TEST PATH →
(TG) HOLDING PATH - - - →




PANEL SYSTEMS 48 D
DDD FEATURES


SHEET 2 OF 2

OS-64


OS 64, SKETCH 1




OS 64, SKETCH 2



OS 64, SKETCH 12




OS 32 SHEET 3




○ = LEADS TO AUX SDR LINK

Subs. 3dr., SD 21193-01
DDD Modifications using
RCO relay per Fig. BV. 48F
Panel System,
Battery Cut-off OS 64-A




FAILURE TO
COLLECT OR REFUND
ON DISCONNECT



PLANT SCHOOL
FOR TRAINING PURPOSES ONLY
LINE TEST
TALKING TO OPERATOR
PANEL SYSTEM
BATTERY SYSTEM

06-355



SHEET 1 OF 2






48 —  — 11

PANEL SYSTEM BATTERY CUT-OFF	OS- 6L ¹⁸
---------------------------------	----------------------


BALANCED CIRCUIT
 OPTION J
 LONG LOOP
 POSITIVE SHUNTING OF (STP)
 ALL INC & FINAL SELECTIONS






"GA" LOOPS THRU
ANY SWITCHES UNTIL
ONE IS FOUND IN POS 1

1 & 4 OF (P)
MADE ALWAYS
2 & 3 OF (P)
MADE 2/9
11/8



GA/CB LEAD SIMILAR
EXCEPT P & N CAMS USED
SEE

STA / STB
STA LEAD LOOPS
THRU ANY SS NOT
IN POS 1 TIL A
LINK SW IN POS 1
IS FOUND.
ONLY 1 LINK POS
#1




3 & 4 (U) MADE
ALWAYS
1 & 2 (U) NOT MADE
POS 1

APPENDIX A

BASIC CIRCUITS

1 CONTACTS

(A) REGULAR CONTACTS FOR RELAYS ETC.




(B) ARMATURE FOR RELAYS ETC.



CIRCLE INDICATES PIVOT POINT.

(C) NORMALLY CLOSED CONTACTS.




(D) NORMALLY OPEN CONTACTS.



2. CORE

CORE FOR RELAYS, MAGNETS, ETC.




3. INDUCTANCE

REPEATING COIL OR INDUCTION COIL WINDING.



4. WINDING

(A) INDUCTIVE WINDING FOR RELAYS ELECTROMAGNETS, ETC.



(B) NONINDUCTIVE WINDING



(C) INNER END FOR WINDING.




5 LINE CONVENTIONS

(A) JUMPER



(B) LEADS FOR SHOWING DETAILS OF ONE CIRCUIT ON ANOTHER CIRCUIT.




(C) TALKING




(D) FUNDAMENTAL CIRCUIT




(E) SEQUENCE SW ROTARY MAGNET LEAD



(F) SIGNALLING CONTROL



(G) HIGHWAY CONNECTION



6. METHOD OF SHOWING LEADS

(A) CROSSED WIRES (NO METALLIC CONNECTION)



(B) JOINED WIRES (CONNECTION BETWEEN WIRES)



(A) 48 VOLT BATTERY (POSITIVE SIDE GROUNDED)



(B) 24 VOLT BATTERY (POSITIVE SIDE GROUNDED)



7. BATTERIES


8. CAPACITOR

FIXED CAPACITOR




CIRCULAR PLATES USUALLY GO TO LOW VOLTAGE SIDE.


9. CLUTCH MAGNETS




10. DIAL (SIMPLE SYMBOL)



11. COMMUTATOR, COMMUTATOR SPRING, MULTIPLE BRUSH SPRING, MULT. BANK TERM.




12. GROUND




13. INDUCTORS

(A) INDUCTION COIL



(B) REPEATING COIL



14. HAND-TYPE RECEIVER



15. RELAYS

(A) RELAY WITH NON-INDUCTIVE WINDING



(B) RELAY SHOWING SPECIFIC OPERATING FEATURE




"SR" DENOTES "SLOW RELEASE"


16. RESISTOR




17. ROTARY-TYPE SELECTOR



18. SEQUENCE SWITCH



19. SWITCH-HOOK



20. TERMINAL

(A) APPARATUS

(B) TERMINAL PUNCHING



21. TONE ALTERNATOR



22. TRANSMITTER



SCHEMATIC CONVENTIONS
FUNDAMENTAL CIRCUITS

1. A CONTACT SPRING IS DESIGNATED THE SAME, WHETHER THE APPARATUS IS VIEW FROM THE CONTACT SIDE, OR THE TERMINAL SIDE
2. THE UPPER AND LOWER RELAY CONTACTS AND WINDING TERMINALS OF ALL RELAYS ARE DESIGNATED "T"(TOP) AND "B"(BOTTOM) EXCEPT AS NOTED


(A) ALL ARMATURE TERMINALS THAT ARE NOT IN ALIGNMENT WITH OTHER TERMINALS ARE DESIGNATED "A"

(B) THE LETTERS "L" AND "R" INDICATE THE LEFT AND RIGHT SIDE, FACING THE FRONT OR CONTACT SIDE OF THE RELAY. FACING THE REAR OR TERMINAL SIDE OF THE RELAY AN "L" TERMINAL WILL BE ON THE RIGHT AND AN "R" TERMINAL WILL BE ON THE LEFT.


3. E TYPE RELAYS

(A) THE CONTACT SPRINGS ARE NUMBERED LEFT TO RIGHT FACING THE CONTACT SIDE OF THE RELAY AND FROM RIGHT TO LEFT FACING THE TERMINAL SIDE OF THE RELAY.

(B) WHERE A WINDING TERMINAL IS DESIGNATED BY TWO LETTERS AS RT, RB, LT OR LB IT IS AN INDICATION THAT CONNECTION IS TO BE MADE FROM THE FRONT OF THE RELAY AS SHOWN IN THE FIGURE BELOW




(C) WHERE A WINDING TERMINAL IS DESIGNATED BY A NUMERAL AND TWO LETTERS AS SHOWN IN THE FIGURE BELOW, IT IS AN INDICATION THAT THE CONNECTION IS TO BE MADE FROM THE REAR OR TERMINAL SIDE OF THE RELAY, THE NUMERAL IS THE SAME AS THAT OF THE CONTACT TERMINAL SIDE OF THE RELAY AND INDICATES THE POSITION OF THE WINDING TERMINAL WITH RESPECT TO THE CONTACT TERMINAL




- (D) THE FIRST LETTER "R" OR "L" OF THE WINDING TERMINAL DESIGNATION INDICATES ON WHICH SIDE OF THE RELAY CORE FRAME THE WINDING TERMINAL IS ASSEMBLED FACING THE CONTACT SIDE OF THE RELAY. THE LETTER "L" INDICATES LEFT AND "R" RIGHT

- (E) WHEN THE NUMERAL FOLLOWS THE LETTERS, IT IS ALWAYS "1" AND INDICATES EITHER THAT THE WINDING TERMINAL IS LOCATED AT THE EXTREME RIGHT END POSITION IN A ROW OF TERMINALS LOOKING AT THE TERMINAL SIDE OF THE RELAY OR THAT IT IS LOCATED IN A ROW OF WINDING TERMINALS ONLY. SEE FIGURE BELOW




4 B. TYPE RELAYS

THESE RELAYS ARE ARRANGED WITH THREE ROWS OF TERMINALS. THE WINDING TERMINALS ARE LOCATED IN THE MIDDLE ROW AND ARE NUMBERED CONSECUTIVELY FROM RIGHT TO LEFT FACING THE TERMINAL SIDE OF THE RELAY WITH A SUFFIX "M" TO INDICATE THE MIDDLE ROW OF TERMINALS. THE CONTRACT TERMINALS ARE LOCATED IN THE UPPER ROW AND ARE NUMBERED CONSECUTIVELY FROM RIGHT TO LEFT FACING THE TERMINAL SIDE OF THE RELAY AND ARE NOT GIVEN ANY LETTER DESIGNATION. THE ARMATURE TERMINAL WHICH IS ELECTRICALLY CONNECTED TO THE RELAY FRAME IS DESIGNATED "A" SEE FIGURE BELOW




- ## 5. L TYPE RELAYS

THE WINDING AND CONTACT TERMINALS ARE NUMBERED FOLLOWING THE SCHEME FOR E TYPE RELAYS. SEE FIGURE BELOW





ISSUE	1	2	4-6-55	LEB
DATE	2-12-55	NAS		
BY				


6. 207 TYPE RELAYS
THE ARMATURE (FRAME TERMINAL) IS INDICATED BY "A" AND THE FRONT CONTACT OR "MAKE CONTACT" BY "1" SEE FIGURE BELOW.



7. 149 AND 178 TYPE RELAYS
THE CONTACT TERMINALS ARE NUMBERED CONSECUTIVELY FROM RIGHT TO LEFT FACING THE TERMINAL SIDE OF THE RELAY THE RELATIVE LOCATION OF THE WINDING TERMINALS AS VIEWED FROM THE TERMINAL SIDE AS SHOWN BELOW.




8. 208 TYPE RELAYS
THE FRONT CONTACT OR "MAKE CONTACT" IS INDICATED BY "1", THE ARMATURE BY "A" AND THE BACK CONTACT OR "BREAK CONTACT" BY "2" SEE FIGURE BELOW.



9. SEQUENCE SWITCH SPRINGS
(A) THE 4 SPRINGS OF A SEQ. SW. CAM ARE KNOWN AS LEFT OUTER, LEFT INNER, RIGHT OUTER, RIGHT INNER ACCORDING TO THEIR POSITION AS VIEWED FROM THE CAM SIDE. THE LEFT SIDE OF THE CAM IS THE SIDE NEAREST THE DRIVE OR "R" MAGNET AND THE SPRINGS ON THAT SIDE OF THE CAM ARE THE LEFT SPRINGS, THE 2 SPRINGS NEAREST THE CAM SPINDLE ARE THE INNER SPRINGS.


- (B) THE SPRINGS FOR CAMS OTHER THAN THE "A" CAM ARE NUMBERED AS FOLLOWS
1 IS LEFT INNER
2 IS LEFT OUTER
3 IS RIGHT OUTER
4 IS RIGHT INNER




- (C) THE "A" CAM HAS NO SPRINGS ON THE LEFT SIDE.
1 IS RIGHT INNER
2 IS RIGHT OUTER




- (D) THE SEQ. SW. SPRING TERMINAL NUMBERING FROM REAR OF SWITCH FOR OTHER THAN "A" CAMS.



- (E) THE SEQ. SW. SPRING TERMINAL NUMBERING FROM REAR FOR "A" CAMS.



10. CLUTCH AND TRIP MAGNET TERMINAL DESIGNATIONS



11. 200 TYPE SELECTORS
(A) FACING THE FRONT, OR ADJUSTING END, THE INTERRUPTER CONTACT SPRINGS ARE NUMBERED FROM 1 UP FROM FRONT TO REAR.
(B) FACING THE FRONT END, THE WINDING CONNECTIONS ARE NAMED, "INNER END" THE TERMINAL AT THE FRONT AND "OUTER END" THE TERMINAL AT THE REAR.

WINDING & SPRING
DESIGNATIONS
FUNDAMENTAL CIRCUITS

FUNDAMENTALS RM. 000.002 2 SHEETS, SHEET 2

SEQUENCE CHARTS (SC)

- RELAY OR OTHER APPARATUS OPERATIONS AND RELEASES ONLY ARE SHOWN.
- VERTICAL PROGRESSION DOWNWARD SHOWS RELATIVE TIME PHASE OF RELAY OR OTHER APPARATUS MOVEMENTS (OPERATION OR RELEASE)
- COORDINATES ARE USED TO LOCATE THE POSITION OF APPARATUS ON SC'S. THE HORIZONTAL COORDINATE IS ALPHABETICALLY DESIGNATED THE VERTICAL COORDINATE IS NUMERICALLY DESIGNATED STARTING WITH 101 ON SHEET 1, 201 ON SHEET 2, ETC. THUS D 304 MEANS VERTICAL COLUMN D, SHEET 3, HORIZONTAL LINE 4.

- THE FOLLOWING TABLE SHOWS, ON A LINE BASIS, THE OPERATE AND RELEASE TIMES WHICH ARE USED FOR THE APPARATUS.

APPARATUS	OPERATE	RELEASE
(A) ALL RELAYS EXCEPT SLOW RELEASE	1 LINE EXAMPLE: LINE 101 X IMPULSER 4 & 5 102 X L	1 LINE EXAMPLE: IMPULSER 4 & 5 L
(B) SLOW RELEASE RELAYS	1 LINE EXAMPLE: LINE 101 L 102 X RA 103	2 LINES (MIN) EXAMPLE: EXPLANATION X L SR "SR" DENOTES SLOW RELEASE RA
(C) TIMED APPARATUS	2 LINES (MIN) EXAMPLE: LINE 101 X UP 102 X A 0 103	2 LINES (MIN) EXAMPLE: EXPLANATION X DD NO DEFINATE TIME INDICATED. BRUSH "3" RESETS
5. OPERATE SYMBOLS	EXAMPLE: X RA	EXPLANATION RA RELAY OR OTHER APPARATUS COMES TO FULLY OPERATED CONDITION.
6. RELEASE SYMBOLS	EXAMPLE: + RA	EXPLANATION RA RELAY OR OTHER APPARATUS COMES TO FULLY RELEASED CONDITION.

- SEQUENCE CHARTS ON OPERATIONAL SKETCHES THE DESIGNATION OF ALL APPARATUS FOR WHICH THE OPERATING PATHS ARE SHOWN ON THE OS ARE INDICATED LARGER AND HEAVIER THAN DESIGNATIONS IDENTIFYING OTHER APPARATUS SEE 9 FOR EXAMPLE


OTHER APPARATUS DESIGNATIONS	EXAMPLE:	EXPLANATION	EXAMPLE:	EXPLANATION	EXAMPLE:	EXPLANATION
DIAL 4 & 5	X	THE 4 & 5 CONTACTS OF THE DIAL OPEN	X A 0	A COMMUTATOR BRUSH MAKES CONTACT WITH "0," A SEGMENT	X R 2	SEQ. SW. MOVES TO POSITION 2.
DIAL 4 & 5	X	THE 4 & 5 CONTACTS OF THE DIAL CLOSE	+ A 0	A COMMUTATOR BRUSH BREAKS FROM "0," A SEGMENT.	X UP	UP DRIVE ENERGIZED.
	+ H STEP 1		+ H STEP 1	H ROTARY TYPE SELECTOR STEPS AND ITS BRUSHES ARE MAKING CONTACT WITH TERMINAL "1."	+ UP	UP DRIVE DE-ENERGIZED.
	X H STEP		X H STEP	H ROTARY TYPE SELECTOR ENERGIZED.	X DOWN	DOWN DRIVE ENERGIZED.
					X TRIP	TRIP MAGNETS ENERGIZED.

8. CONNECTING LINES

- VERTICAL LINES ARE USED TO LINK CAUSES WITH EFFECTS ON SUCCEEDING LINES AS:
EXAMPLE: EXPLANATION
LINE 101 L
102 X RA
"RA" RELAY HAS OPERATED ON LINE 102 AS A RESULT OF RELAY "L" RELEASING ON LINE 101.
- HORIZONTAL AND VERTICAL LINE COMBINATIONS ARE USED AS FOLLOWS:
EXAMPLE: EXPLANATION
+
CONNECTION BETWEEN LINES.
- HORIZONTAL LINES ARE USED TO CONNECT MULTIPLE CAUSES PRODUCING A COMMON EFFECT OR TO CONNECT MULTIPLE EFFECTS PRODUCED BY THE SAME CAUSE AS:
EXAMPLE: EXPLANATION
LINE 101 L
102 X UP X R
THE UP DRIVE HAS RELEASED AND THE SEQ. SW. HAS ADVANCED TO POSITION "7" ON LINE 102 AS A RESULT OF THE "L" RELAY RELEASING ON LINE 101.
- APPARATUS FUNCTIONAL OPTIONS ARE SHOWN BY A BREAK IN THE HORIZONTAL AND VERTICAL CONNECTING LINES.
EXAMPLE: EXPLANATION
LINE 101 X R 5
LINE 102 X L (SEL) X STP
THE "L" AND "STP" RELAYS ON LINE 102 HAVE OPERATED AS A RESULT OF EITHER THE "5" RELAY RELEASING ON LINE 101 OR THE SEQ. SW. ADVANCING TO POSITION "5" ON LINE 101.

- THE CIRCUIT MOST FREQUENTLY USED IN A PARTICULAR SEQUENCE CHART IS IDENTIFIED BY AN ASTERISK OPPOSITE ITS NAME IN THE LIST OF CIRCUITS ABOVE THE TITLE BLOCK. NO CIRCUITS ABBREVIATIONS ARE SHOWN ON THE SEQUENCE CHART NEXT TO RELAYS ASSOCIATED WITH THIS CIRCUIT. THE CIRCUITS IN WHICH ALL OTHER RELAYS APPEAR ARE SHOWN IN BRACKETS ADJACENT TO THE RELAY DESIGNATIONS ON THE SEQUENCE CHART.

EXAMPLE:



* SENDER FUNDAMENTAL CIRCUIT
SELECTOR FUNDAMENTAL CIRCUIT

SEQUENCE CHARTS FOR FUNDAMENTAL CIRCUITS

THE SYMBOLS AND DESIGNATIONS USED IN THE OPERATIONAL SKETCHES FOR THE "FUNDAMENTAL CIRCUITS" ARE TAKEN FROM BELL SYSTEM PRACTICES SECTION A 128.801, SECTION 950 701.01 AND SECTION A 804 002 AND APPEAR BELOW

OPERATIONAL SKETCHES (OS)

THE SYMBOLS AND CONVENTIONS USED ARE THE SAME AS THOSE USED ON STANDARD CIRCUIT SCHEMATIC DRAWINGS (SD-) WITH THE FOLLOWING EXCEPTIONS.

1. A SYMBOL MAY BE TURNED IN ANY DIRECTION WITHOUT AFFECTING ITS MEANING.

SYMBOL MEANING

SPRING 2 SPRING 1 3 SPRING 4 SPRING

SPRING 3 SPRING 2 4 SPRING 1 SPRING

SPRING 4 SPRING 3 1 SPRING 2 SPRING

SPRING 1 SPRING 2 SPRING 4 SPRING 3 SPRING

2. BATTERY (SD) SYMBOL (OS) SYMBOL MEANING

-48 NEGATIVE SIDE OF 48 VOLT POSITIVE GROUNDED BATTERY

-24 NEGATIVE SIDE OF 24 VOLT POSITIVE GROUNDED BATTERY.

3. MAKE CONTACTS (SD) SYMBOL (OS) SYMBOL MEANING

CONTACTS ARE CLOSED WHEN RELAY IS OPERATED.
CONTACTS ARE OPEN WHEN RELAY IS UNOPERATED.
RELAY HAS TOP AND BOTTOM SPRING PILE-UPS.

CONTACTS ARE CLOSED WHEN RELAY IS OPERATED.
CONTACTS ARE OPEN WHEN RELAY IS UNOPERATED.
RELAY HAS ONLY 1 AND 2 SPRING CONTACTS.

4. BREAK CONTACTS

(SD) SYMBOL

(SD) SYMBOL

5. TRANSFER CONTACTS

(SD) SYMBOL

6. OTHER CONTACTS

(SD) SYMBOL (SWITCH-HOOK)

7. ROTARY TYPE SWITCH OR SELECTOR (SIMPLE SYMBOL)

(SD) SYMBOL

8. SEQUENCE SWITCH CAMS

(SD) SYMBOL

1-2-3-4-5-6-8

9.

THIS INDICATES COMPLETE OR PORTION OF OTHER CIRCUIT IN ORDER TO MAKE CIRCUIT PATH COMPLETE AND TO GIVE A GENERAL UNDERSTANDING OF THE CIRCUITS.

10. RELAY WINDINGS

RELAY WINDINGS ARE NOT SHOWN.

(OS) SYMBOL

(OS) SYMBOL

(OS) SYMBOL

(OS) SYMBOL

(OS) SYMBOL

(OS) SYMBOL

(OS) SYMBOL

(OS) SYMBOL

(OS) SYMBOL

-48

MEANING

CONTACTS ARE CLOSED WHEN RELAY IS UNOPERATED.

CONTACTS ARE OPEN WHEN RELAY IS OPERATED.

RELAY HAS TOP AND BOTTOM SPRING PILE-UPS.

MEANING

CONTACTS ARE CLOSED WHEN RELAY IS UNOPERATED.

CONTACTS ARE OPEN WHEN RELAY IS OPERATED.
RELAY HAS ONLY 1 AND 2 SPRING CONTACTS

MEANING

THE SINGLE NUMBER IS SHOWN FOR THE FIXED SPRING.

NO DOT IS SHOWN AT THE JUNCTION POINT.

THE RELAY DESIGNATION IS AT THE JUNCTION POINT.

MEANING

NO DOT IS SHOWN AT THE JUNCTION POINT.
THE APPARATUS DESIGNATION IS AT THE JUNCTION POINT.

THE CONTACT SEQUENCE IS COVERED IN A NOTE.

MEANING

THE ARROW IS THE ROTAR BRUSH - "H" IS THE ROTARY SELECTOR - "2" IS THE ARC OF THE ROTARY SELECTOR THE CIRCLE IS THE TERMINAL AND "1" INDICATES THE TERMINAL NUMBER.

MEANING


THE "A" CAM BRUSH "2" IS SHOWN IN THE "OS" SYMBOL WHEN IT MAKES WITH THE CAM TO ADVANCE THE SEQ. SW. OUT OF A PASS BY POSITION.

OPERATIONAL SKETCHES
FUNDAMENTAL CIRCUITS

FUNDAMENTALS RM 000.004 1 SHEET, SHEET 1

SC 000-001

ISSUE	1	2
DATE	2-5-55	4-6-55
BY	NAS	LEB



S.C. 000.001

ISSUE	1	2		
DATE	2-9-55	4-6-55		
BY	N.A.S.			

A	B	C	D	E	F	G	H	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	
	CONTINUED FROM P 336					CONTINUED FROM B 436																	
401	X	STEP				X	STEP															401	
402		T	7				RC	9														402	
403	X	STEP				X	STEP															403	
404		T	8				RC	10														404	
405	X	STEP				X	STEP															405	
406		T	9				RC	N														406	
407	X	STEP					STEP															407	
408		T	10																			408	
409	X	STEP																				409	
410		T	N																			410	
411	X	STEP					H															411	
412		H	4																			412	
413	X	STEP					H															413	
414		H	5																			414	
415	X	STEP					H															415	
416		H	6																			416	
417	X	STEP					H															417	
418		H	7																			418	
419	X	STEP					H															419	
420		H	8																			420	
421	X	STEP					H															421	
422		H	9																			422	
423	X	STEP					H															423	
424		H	10																			424	
425	X	STEP					H															425	
426		H	N																			426	
427	X	STEP					RC															427	
428		RC	4																			428	
429	X	STEP					RC															429	
430		RC	5																			430	
431	X	STEP					RC															431	
432		RC	6																			432	
433	X	STEP					RC															433	
434		RC	7																			434	
435	X	STEP					RC															435	
436		RC	8																			435	
437		STEP																					
438	CONTINUED AT G 401																						
	A	B	C	D	E	F	G	H	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X

SEQUENCE CHART
FOR
SENDER CKT.


FUNDAMENTALS


S.C. 000-001 4 SHEETS, SHEET 4

SEQUENCE CHART FOR SENDER CKT.	
FUNDAMENTALS	S.C. 000-001 4 SHEETS, SHEET 4

OS 000.001

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100





RELAY TYPE

L	L
S	E
STP	207
RA	178
RLS	149
Or 9	208
1ro 9	208
BO	208
FO	208

- SELECTOR SEQUENCE SWITCH**
- 1- AWAITING SENDER
 - 2- BRUSH SELECTION
 - 3- AWAITING SENDER
 - 4- TENS SELECTION
 - 5- AWAITING SENDER
 - 6- UNITS SELECTION
 - 7- PASS BY & OPERATE (L)
 - 8- TALKING
 - 9/17- PASS BY
 - 18- OPERATE DOWN DRIVE

- SENDER SEQUENCE SWITCH**
- 1- NORMAL
 - 2- BRUSH SELECTION
 - 3- PASS BY
 - 4- TENS SELECTION
 - 5- PASS BY
 - 6- UNITS SELECTION
 - 7/18- PASS BY

FUNDAMENTAL CIRCUITS
 SIMPLE PANEL DIAL CIRCUITS
 ARRANGED FOR SELECTING
 ONE OF 500 SUBSCRIBERS LINES

OS 000.002

OS 000 002

ISSUE	1	2			
DATE	2-25-55	4-6-55			
BY	NAS.	LEB			

SEQUENCE CHART - TENS DIGIT 6

SEQUENCE CHART - UNITS DIGIT 9

SUB. MOVES DIAL OFF-NORMAL IN ORDER TO DIAL 6

SUB. MOVES DIAL OFF-NORMAL IN ORDER TO DIAL 9

DIAL PULSE 9 U DIGIT

DIAL

4 5

DIAL

4 5

L (SDR)

L (SDR)

SR

RA (SDR)

RC (SDR)

STEP 3 (SDR)

S (SDR)

STP (SDR)

SW-HOOK

2 3

REC.CCT.

OPEN

SW-HOOK

1 2

D (SEL)

SUB. REPLACES RECEIVER ON SWITCH-HOOK

SW-HOOK

2 3

REC.CCT.

OPEN

SW-HOOK

1 2

D (SEL)

SUBSCRIBER SET

DIALING TENS DIGIT 6

DIALING UNITS DIGIT 9

RESTORING RECEIVER TO SWITCH-HOOK





FUNDAMENTALS

O.S. 000-003



2 SHEETS, SHEET 2

O.S. 000.003

ISSUE	1	2			
DATE	2-3-55	4-6-55			
BY	N.S.				



- ### NOTES
1. THE RLS RELAY IS A SLOW RELEASE TYPE RELAY AND STAYS OPERATED BY ITS SLOW RELEASE FEATURE DURING DIALING WHEN THE "L" RELAY IS RELEASED.
 2. THE "RA" RELAY IS A SLOW RELEASE TYPE RELAY AND STAYS OPERATED BY ITS SLOW RELEASE FEATURE WHEN THE "L" TYPE RELAY IS OPERATED DURING THE DIALING OF A DIGIT, BUT RELEASES IN BETWEEN THE DIALING OF DIGITS AND AFTER THE LAST DIGIT IS DIALED.
 3. THE "H" AND "RC" MAGNETS WHEN ENERGIZED WILL NOT CAUSE THE "H" AND "RC" SWITCHES TO STEP TO THE NEXT SET OF TERMINALS.
 4. THE "H" AND "RC" MAGNETS WHEN DEENERGIZED WILL CAUSE THE "H" AND "RC" SWITCHES TO STEP THE SWITCH TO THE NEXT SET OF TERMINALS.
 5. THE PRIME COUNTER DOES NOT OPERATE AS IT IS SHUNTED.
 6. THE PRIME COUNTERS DO NOT OPERATE AS THEY ARE SHUNTED
 7. THE "5" OPERATES BECAUSE THE "TENS" DIGIT IS NOT DIALED THE "5" OPERATED OPENS THE "FT" LEAD AND NO GROUP SELECTION CAN BE MADE UNTIL THE "TENS" DIGIT IS DIALED.




**SENDER
RECEIVING H. DIGIT 3, DIAL PULSES
BRUSH SELECTION**

05 000.005

ISSUE	1	2
DATE	2-17-55	4-6-55
BY	N.A.S.	LEB


SENDER



NOTES


1. THE "RA" IS A SLOW RELEASE RELAY AND STAYS OPERATED BY ITS SLOW RELEASE FEATURE WHEN THE "L" RELAY IS OPERATED DURING THE DIALING OF A DIGIT, BUT RELEASES IN BETWEEN THE DIALING OF DIGITS AND AFTER THE LAST DIGIT IS DIALED.
2. THE "T" "U" AND "RC" MAGNETS WHEN ENERGIZED WILL NOT CAUSE THE "T" "U" AND "RC" SWITCHES TO STEP TO THE NEXT SET OF TERMINALS.
3. THE "T" "U" AND "RC" MAGNETS WHEN DE-ENERGIZED WILL CAUSE THE "T" "U" AND "RC" SWITCHES TO STEP TO THE NEXT SET OF TERMINALS.
4. THE "S" RELAY RELEASES BECAUSE THE "TENS" DIGIT IS DIALED
5. THE "S" RELAY RELEASES BECAUSE THE "UNITS" DIGIT IS DIALED.

SEQUENCE CHARTS UNITS DIGIT 9



CONTINUED ABOVE UPPER LEFT




SEQUENCE CHART - TENS DIGIT 6



SENDER
RECEIVING T DIGIT 6
RECEIVING U DIGIT 9

FUNDAMENTALS 05 000-005

ISSUE	1	2			
DATE	2-18-55	4-6-55			
BY	NAS	LEB			




**SENDER
GROUP OR TENS SELECTION**

FUNDAMENTALS	05 000.006
--------------	------------


10000007

ISSUE	1	2			
DATE	12-31-54	4-6-55			
BY	N.S.	LEB			





05 000-008

ISSUE	1	2		
DATE	2-11-55	4-6-55		
BY	N.S.	LEB		





05000-009

ISSUE	1	2		
DATE	12-31-50	4-6-55		
BY	N.S.	LEB		



- NOTES:
1. WHEN THE "L" RELAY OPERATES IT LOCKS TO GROUND ON THE "FT" LEAD COMING FROM THE SENDER. THIS IS THE "L" RELAY'S FIRST LOCKING PATH.
 2. WHEN THE "A" COMMUTATOR BRUSH MAKES ON AN "A" SEGMENT THE "L" RELAY HAS A SECOND LOCKING PATH.
 3. WHEN THE "A" COMMUTATOR BRUSH BREAKS FROM AN "A" SEGMENT THE "L" RELAY LOSES ITS SECOND LOCKING PATH.
 4. WHEN THE SELECTOR SEQ. SW. ADVANCES TO 2 THE "L" RELAY LOSES ITS OPERATING PATH BUT STAYS OPERATED BY ITS LOCKING PATH ONE.
 5. WHEN THE "BO" RELAY OPERATES IN THE SENDER CKT THE "FT" LEAD IS OPENED AND THE "L" RELAY LOSES ITS FIRST LOCKING PATH. WHEN THE "A" COMMUTATOR BRUSH GETS ON INSULATION THE "L" RELAY LOSES ITS SECOND LOCKING PATH AND RELEASES.
 6. THE #3 TRIP FINGER ENGAGES THE #3 MULTIPLE BRUSHES TRIP LEVER.
 7. WHEN THE SELECTOR SEQ. SW. ADVANCES TO 4 THE "L" RELAY LOSES ITS OPERATING PATH BUT STAYS UP BY LOCKING PATH ONE.
 8. WHEN THE "B" COMMUTATOR BRUSH MAKES ON A "B" SEGMENT THE "L" RELAY HAS A SECOND LOCKING PATH.
 9. WHEN THE "B" COMMUTATOR BRUSH BREAKS FROM A "B" SEGMENT THE "L" RELAY LOSES ITS SECOND LOCKING PATH.
 10. THE "L" RELAY RELEASES WHEN THE "BO" OPERATES IN THE SENDER AND THE "B" COMMUTATOR BRUSH GETS ON INSULATION.
 11. IF THE "TENS" DIGIT IS DIALED THE "STP" AND "L" OPERATE WITH THE SEL. SEQ. SW. IN 3 AND THE SENDER SEQ. SW. IN 4.




**SELECTOR
BRUSH SELECTION
GROUP OR TENS SELECTION**


FUNDAMENTALS

05 000-009



ISSUE	1	2				
DATE	2-22-55	4-6-55				
BY	N.A.S.	LEB				



1. RELAY OR OTHER APPARATUS OPERATIONS AND RELEASES ONLY ARE SHOWN.
2. VERTICAL PROGRESSION DOWNWARD SHOWS THE TIME PHASE OF RELAY MOVEMENTS (OPERATIONS OR RELEASES)
3. OPERATE SYMBOLS:

- (A)  A INDICATES A RELAY COMES TO FULLY OPERATED CONDITION AT THIS POINT. FOR POLARIZED RELAYS, THE ARMATURE HAS MOVED TO FRONT OR LEFT CONTACT.
- (B)  (B) CHG INDICATES INTERRUPTER CHG HAS CLOSED ITS BACK CONTACT.
- (C)  ² LK INDICATES LINK SEQUENCE SWITCH HAS ADVANCED TO POSITION 2.
- (D)  ^S LK INDICATES LINK SENDER SELECTOR UP-DRIVE MAGNET IS OPERATED.

4. RELEASE SYMBOLS:

- (A)  B INDICATES B RELAY COMES TO FULLY RELEASED CONDITION AT THIS POINT. FOR POLARIZED RELAYS, THE ARMATURE HAS MOVED TO BACK OR RIGHT CONTACT.
- (B)  (F) DISC INDICATES INTERRUPTER DISC HAS OPENED ITS FRONT CONTACT.
- (C)  (D) LK INDICATES LINK CIRCUIT DISTRICT SELECTOR UP-DRIVE MAGNET IS RELEASED.

5. SYMBOL NOTATION:

- (A)  SS- INDICATES ONE OR MORE OF THE RELAYS DESIGNATED SSATO SSK HAVE OPERATED.
- (B)  AI-5 INDICATES ALL OF THE RELAYS DESIGNATED A1 TO A5 HAVE OPERATED.
- (C)  GA, SW INDICATES BOTH GA AND SW RELAYS HAVE OPERATED FROM THE SAME CAUSE.
- (D)  A/B INDICATES THAT EITHER ONE OF THE RELAYS HAS OPERATED.


6. CONNECTING LINES:

- (A) VERTICAL LINES ARE USED TO LINK CAUSES WITH EFFECTS ON SUCCEEDING LINES AS:


LINE 1  L INDICATES THAT THE L1 RELAY ON LINE 2 HAS OPERATED AS A RESULT OF L RELAY OPERATING ON LINE 1.

LINE 2  L1

- (B) HORIZONTAL OR OBLIQUE LINES ARE USED TO CONNECT MULTIPLE CAUSES SO AS TO INDICATE THEIR COMMON EFFECT OR TO CONNECT MULTIPLE EFFECTS TO INDICATE THEIR COMMON CAUSE AS:




INDICATES THAT THE C RELAY HAS OPERATED ON LINE 2 AS A RESULT OF BOTH A AND B OPERATION ON LINE 1. NEITHER A NOR B OPERATION ALONE IS SUFFICIENT TO OPERATE C RELAY.



INDICATES THAT THE D RELAY HAS OPERATED ON LINE 2 AS A RESULT OF EITHER A, B, OR C RELAY OPERATION ON LINE 1.


7. ARROWHEADS:

ARROWHEADS ARE USED TO SHOW THE PRECISE MEANING TO BE ATTACHED TO THE CONNECTING LINE.
(A) IF ARROWHEAD IS ON A HORIZONTAL LINE AND IS LOCATED BETWEEN TWO VERTICAL LINES, IT GIVES THE HORIZONTAL LINE DIRECTION INsofar AS CAUSE TO EFFECT IS CONCERNED. FOR EXAMPLE:




INDICATES Z AND SW WILL NOT OPERATE UNTIL BOTH THE LF AND CLA HAVE OPERATED BUT THE FLA WILL OPERATE INDEPENDENTLY OF THE LF.

(B) IF ARROWHEAD IS ON A HORIZONTAL ADJOINING A VERTICAL LINE THE EFFECT OF THE ARROWHEAD IS LIMITED TO THE OPERATION SHOWN DIRECTLY BELOW: FOR EXAMPLE:




INDICATES SW IS OPERATING FROM LF ONLY; THE Z FROM THE LF AND CLA; AND THE FLA FROM THE CLA ONLY.

INDICATES TIME INTERVAL



PLANT SCHOOL FOR TRAINING PURPOSES ONLY	
RECEIVER OFF THE HOOK TO SENDER SEIZURE	
PANEL SYSTEM BATTERY CUT-OFF	SC-301



NOTES

1. WHEN "CK3" OPERATES, "A," "B," "C," "D" RELAYS RELEASE EXCEPT THOSE HELD BY SENDER RELAYS.
2. "A," "B," "C" RELAYS HELD OPERATED AFTER "CK3" OPERATES, OPERATE "HA," "HB," "TA," "TB" "D" RELAYS OPERATE "SA," "SB."
3. WHEN "RL1(S)" OPERATES ALL CONNECTOR RELAYS RELEASE OPENING ALL LEADS TO DECODER.

<u>CIRCUIT</u>	<u>DRAWING</u>	<u>ISSUE</u>
LINE - TRIP - START & LINK CIRCUIT	SD-20294-01	31D
LINE FINDER & DISTRICT CIRCUIT	SD-21077-011	20D
" " " "	-012	18D
DECODER CONNECTOR CIRCUIT	SD-21187-011	15D
" " "	-012	"
" " "	-013	"
" " "	-014	"
DECODER CIRCUIT	SD-21277-011	25D
" "	-012	"
" "	-013	"
" "	-014	"
" "	-015	"
" "	-016	"
" "	-017	"
" "	-018	"
" "	-019	"
INCOMING SELECTOR CIRCUIT FROM PANEL-LOCAL OR TANDEM	SD-21115-011	24D
" " " " " " " "	-012	"
3-WIRE OFFICE SELECTOR CIRCUIT	ES-240252	9D
FINAL SELECTOR CIRCUIT	SD-21200-01	12D
LINE FINDER-DISTRICT SELECTOR CIRCUIT 2-PARTY	SD-21079-011	18D
" " " " " "	-012	17D
" " " " " "	-013	"
LINE FINDER-DISTRICT & COIN CONTROL CIRCUIT	SD-21350-011	19D
" " " " " "	-012	"
" " " " " "	-013	"
SUBSCRIBERS SENDER CIRCUIT	SD-21193-0101	53D
" " "	-0102	"
" " "	-0103	"
" " "	-0104	"
" " "	-0105	"
" " "	-0106	"
" " "	-0107	"
" " "	-0108	"

PLANT SCHOOL FOR TRAINING PURPOSES ONLY	
S.D.DRAWINGS AND ISSUES	
PANEL SYSTEM BATTERY CUT-OFF	LISTING