DROP AND BLOCK WIRING

FASTENING AND EQUIPPING FIRST ATTACHMENTS FOR

DROP WIRE RUNS ON BUILDINGS

1. GENERAL

1.001 This Addendum supplements Section 462-350-213.

1.002 This Addendum is being issued to revise methods of fastening and equipping first attachments to agree with requirements in Massachusetts.

3. RULES

The following changes apply to Part 3 of the Section.

- (a) 3.01(a)(2) revised
- 3.01 (a) (2) In states except Massachusetts NP, C and E Drop Wires and B and C Multiple Drop Wires working out of metal sheath cable shall be supported on <u>uninsulated</u> building attachments on all types of building walls. (Where station protection is required, the B and C Multiple Drop Wire shall be <u>fully</u> protected in accordance with Bell System Practices and N.E.T.&T. Co. Addenda covering Station Protection.)

In Massachusetts NP, C and EDrop Wires and B and C Multiple Drop Wires working out of metal sheath cable shall be supported on <u>insulated</u> building attachments on flammable building walls. (Where station protection is required, the B and C Multiple Drop Wire shall be <u>fully</u> protected in accordance with Bell System Practices and N.E.T.&T. Co. Addenda covering Station Protection.)