Connections Inside Desk Stand Type Candlestick with 581A Subset

(Using terminals inside a Deco-Tel AA-4100 Base)

Note 1: The terminal(s) listed are GTE/AE designations.

Note 2: The cord used to interconnect the 581A subset and Candlestick Desk-stand is a 8 conductor cord.*

*the standard interconnect cord is a D6AA {6 conductor} or D10R {10 conductor} cord.

1. Switch-hook connections:

White lead to (1), Black lead to (8), Red to (10), Green to (3)

Taped and stored switch-hook leads:

Slate, Brown, Yellow, Blue, and Orange

2. Dial Connections: {WE 6U}

Black lead to (9), 1st White lead to (10), Red lead to (5), 2nd White lead to (8)

3. 8 cond. cord connections between desk-stand and 581A subset:

Note: For D6AA and D10R cords, refer to appropriate schematic.

Blue lead to (1), Yellow lead to (10), Green lead to (3), Brown lead to (6)**, Slate lead to (6)**, Red lead to (2), Black lead to (5), White to (11)

4. Receiver and Transmitter connections:

Receiver: White lead to (11), White lead to (9) **Transmitter:** Black lead to (9), Red lead to (5)

5. Jumper Straps:

Run one from Terminal 8 to 9 and one from terminal 10 to 11.

^{**}Brown and Slate leads taped and stored.