

SEPARATION AND MECHANICAL PROTECTION  
FOR WIRE AND CABLE

1. GENERAL

1.01 This addendum is issued to provide instructions concerning the use of drop wire attachments on buildings of flammable construction in Massachusetts.

1.02 This is a partial revision and cancels Addendum C23.007. The word "flammable" has been substituted for "wooden" in connection with building construction.

1.03 In Massachusetts, insulated attachments should be used to properly insulate drop wires on all buildings whether fused or fuseless protection is used.

1.04 To properly insulate drop wires on all buildings of flammable construction in Massachusetts, insulated screw eyes, or "C" knobs shall be used instead of drive rings, staples or cable clamps.

1.05 Clearance and mechanical protection requirements for wires run outside of buildings will remain the same.