# STATION SETS

## LOCAL BATTERY

### SELECTION FOR GENERAL USE

#### 1.00 INTRODUCTION

This section covers the selection of local battery talking common battery signaling, dial and manual station sets for general use. It also includes information on message rate service and selection of colored sets.

#### 2.00 GENERAL

- 2.01 Information is contained in tabular form and includes the following:
  - Selection by class of service as furnished by Western Electric Company.
  - Indication of sets which require modification.
  - Indication of sets to be used under particular station conditions.
- 2.02 Local battery sets are normally used in Zone L and the 6-type dial should be used in this zone.

- Choice of network for these sets is included in the section entitled Transmission Zoning.
- Ringer limitations are included in the section entitled Ringing Bridge Limitations.
- F4 or F5 handsets should be used with local battery sets.

#### 3.00 MESSAGE RATE SERVICE

Local battery sets may be used for individual and 2-party line manual message rate service, but they cannot be used for tip-party identification on dial service.

### 4.00 SELECTION OF COLORED SETS

Selection information concerning colored sets is contained in Table A.

TABLE A
SELECTION OF LOCAL BATTERY COLORED SETS

Color	Full	Two-tone	307A 307C	357A 357C
Ivory	-50	-50A	•	
Green	-51	-51A	•	
Gray	-52	-52A	•	
Red	-53	-53A	•	
Prown	-54	-54A	•	
Beige	-55	-55A	•	
Yellow	-56	-56A	•	
Blue	-57	-57A	•	
Ivory	- 4			•

TABLE B

SELECTION OF DIAL OR MANUAL LOCAL BATTERY SETS FOR GENERAL USE IN ZONE L

Class of Service			Flat Rate				
Type of Service		Individual or Bridged	Ring Party  1, 3, 5, 7,		Tip Party (See 3.00)		
Party Positions					2, 4, 6, 8, or 10	2, 4, 6, or 8 (+) and ()	
Type Full Selective		1 party	2 party	4 party	2 party	4 party	
of	Semis	elective		4 party	8 party	4 party	8 party
Ringing	Code	Div Code		multi-party		multi-party	
Combined	Desk T	уре					
	Dial	Manual					
307	С	A	•	•		•	
307	G*	E*	•	•		•	
309	С	A			•		•
Combined	Wall T	ype					
357	С	A					
Tv Hand Tel !	vo-piece Set	Sets Subset					
Dial Ma	anual				<del></del>		
201 C	A ]						
202 F I	H						
206 C	A*	634BB *	•	•		•	
207 C	A*	634Y ‡	•	•		•	
211 G	E‡	634YD ‡	•	•		•	
212 L†		634YT ‡			•		•
213B	E§	634YDT‡			•		•
215 C	A§						

<sup>\*</sup>Used when transmitter battery for more than one station is provided from a common source. See BSP on power supply filter for this condition.

<sup>†</sup>Requires modification when used as a manual station.

<sup>‡</sup>Requires modification only when used at stations having a common source of battery supply.

<sup>§</sup>Used when two or more hand telephone sets are connected to a common subscriber set.

<sup>•</sup>Sets as furnished by Western Electric Company for this service.