

Civil Defense Warning System — Bell and Lights Receiving Station

ACTUAL WARNING

AUTHENTICATION SIGNAL BELL and BLUE LIGHT

3 Short Bells — repeated —
30 Second Signal

This signal always precedes an Alert or Take Cover Signal

ALERT SIGNAL (Strategic Warning) BELL and YELLOW LIGHT

2 Short Bells — repeated
3 Minute Signal
Preceded by 30 Second Blue Signal

TAKE COVER SIGNAL (Attack Imminent or in Progress) BELL and RED LIGHT

Continuous short bells
3 Minute Signal
Preceded by 30 Second Blue Signal

TEST WARNING

These Tests Will Be Made Daily At 9:30 A.M.*
Codes Will Be Tested In The Following Order:

1. **WHITE** — About 15 seconds
2. **YELLOW** — About 10 seconds
3. **BLUE** — About 10 seconds
4. **RED** — About 10 seconds
5. **WHITE** — About 15 seconds

*NOTE — Occasionally, drills in addition to the 9:30 A.M. daily equipment test, will be held as announced by CD authorities. On such drills the "White" signal only will be transmitted for about 30 seconds.

WHAT TO DO

ALERT SIGNAL - BELL and YELLOW LIGHT

Sound Public Warning Devices, 3 to 5 minute steady blast on sirens, whistles or horns.
Turn on AM Radio - Tune to Emergency Broadcast System Station serving your area for information and instructions from Civil Defense authorities.

TAKE COVER SIGNAL - BELL and RED LIGHT

Sound public warning devices, 3 minute wailing or warbling or a series of short blasts of 3 minute duration on sirens, whistles or horns.
Turn on AM Radio - Tune to Emergency Broadcast System Station serving your area for information and instructions from Civil Defense authorities.

TO REPORT TROUBLE

Call Telephone Company Repair Service:

"This is receiving station _____"