



- NOTES:
- 1- "X" CONTACTS TO BREAK LAST.
 - 2- IF BELL TAPPING IS ENCOUNTERED WHEN DIALING FROM ANOTHER TELEPHONE ON A BRIDGED LINE, MAKE THE FOLLOWING WIRING CONNECTIONS AT TERMINALS 9 AND 10 OF TRANSMISSION BOARD.
 - 3- WIRING FOR DESK INSTRUMENT (WITH LINE CORD AND CONNECTING BLOCK) SHOWN FOR METALLIC (BRIDGED) RINGING. WIRING OF WALL INSTRUMENT (WITH LINE CORD AND CONNECTING BLOCK) SHOWN FOR GROUND (DIVIDED) RINGING.
 - 4- REQUIRED LEAD FOR FIELD CONVERSION TO TIP PARTY IDENTITY.
 - 5- WHEN MESSAGE WAITING LAMP IS USED CONNECT ACROSS TERMINALS 8 AND 10 OF TRANSMISSION BOARD.
 - 6- LINE CORD AND CONNECTING BLOCK PROVIDED WITH DESK INSTRUMENT ONLY.
 - 7- "Y" CONTACTS ON COMMON SWITCH BREAK FIRST.
 - 8- EXTENSION TELEPHONES WITHOUT RINGERS USED WITH TIP PARTY IDENTIFICATION WILL REQUIRE THE USE OF A SEPARATE INDUCTOR FOR IDENTIFICATION.

Type 192A Telephone Set (NB-920 Series) with Touch Calling Unit, Schematic and Wiring Diagrams.