

NOTE 301
OPERATE KEYS AS SHOWN BELOW FOR TRIP AND PRETRIP CONDITION.

NOTE 301
OPERATE KEYS AS SHOWN BELOW FOR TRIP AND PRETRIP CONDITION.

KIND OF RINGING	MAX. EXT. SUB LOOP (OHMS)	TYPE OF		TRIP BAT. VOLTS	FOR	OPR. KEYS	RESISTANCE VALUES (Ω)			
		CONNECTORS	SUBSETS FOR 4 OR 8 PARTY				PRETRIP		TRIP	
							RING PERIOD	SILENT PERIOD	RING PERIOD	SILENT PERIOD
AC - DC	1000 OR 1115	1 RING 2 RING 10 PTY. T.PL.* 10 PTY. T.P.S.	-	48.5- 50	TEST	1000A		2200		1196
	TEST				1400A		2200		1606	
	ADJ				1400A ADJ		2200		1800	
SUP	1000	1, 2, 4 OR 8 PARTY	4 PTY. - INV. & TUBE 8 PTY. - TUBE ONLY	60-75	TEST	1000B	1440		1080	
					ADJ	1000B ADJ	1315		1160	
	1000 OR 1115		TUBE ONLY	48.5- 50	TEST	1000A		2200		1196
		10 PTY. T.PL.* 10 PTY. T.P.S.	-	48.5- 50	TEST	1000A		2200		1196
	1000 OR 1115	1, 2, 4 OR 8 PARTY	TUBE ONLY	48.5- 50	TEST	1400A	.	2200		1606
					ADJ	1400A ADJ		2000		1800
				66-75	TEST	1400B		3200		1920
					ADJ	1400B ADJ		2790		2200
		10 PTY. T.PL.* 10 PTY. T.P.S.	-	48.5- 50	TEST	1400A		2200		1606
					ADJ	1400A ADJ		2000		1800

* WHEN TESTING THE TRIP RELAY IN 10 PARTY T.P.L. CONNECTORS OPERATE THE (RT) KEY WHEN A TIP PARTY CODE IS DIALED.