

300-MEGABYTE MOVING HEAD DISK DRIVE

KS-22072,L1

PREVENTIVE MAINTENANCE

3B20D MODEL 1 PROCESSOR

	CONTENTS	PAGE
1. GENERAL	1
Tables		
A. Preventive Maintenance Services	1

1. GENERAL

1.01 This section is a cover sheet for manufacturer operating and service manuals for the KS-22072,L1 moving head disk. This moving head disk is a component of the 3B20D Model 1 processor. Copies of manufacturer manuals are supplied with each moving head disk. Additional copies can be ordered from parts lists by part number.

1.02 Whenever this section is reissued, the reasons for reissue will be listed in this paragraph.

1.03 Descriptive, theory of operation, installation, and operating information and maintenance instructions for the moving head disk are given in the manufacturer's manuals.

1.04 Preventive maintenance services required by the manufacturer are provided in the manual and are recapitulated in Table A. Where a conflict exists, the preventive maintenance services in the manufacturer's manual shall take precedence.

TABLE A

PREVENTIVE MAINTENANCE SERVICES

TEST	TITLE	FREQUENCY
1	Clean Primary Air Intake Filter	3 Months
2	Check +5 Volt and -5 Volt Outputs	3 Months
3	Clean Shroud and Spindle	6 Months
4	Clean and Lubricate Lockshaft	6 Months
5	Clean Carriage Rails and Bearings	6 Months
6	Replace Absolute Air Filter	1 Year

NOTICE

Not for use or disclosure outside the Bell System except under written agreement