## SUBSCRIBER SETS AND EXTERNALLY MOUNTED RINGERS SELECTION FOR GENERAL USE

## 1. GENERAL

mounted ringers for all classes and types of services as shown in Table A.

1.01 This section covers selection of subscriber sets (used as ringers only) and externally

**1.02** This section is reissued to revise Table A.

TABLE A
RINGER AND SUBSCRIBER SET APPLICATION

APPARATUS OR CLASS OF SERVICE	L1AMP RINGER*	S1AM RINGER†	E1CM RINGER‡	687B SUB SET §	687A SUB SET
Coin Stations	•	•	•		•
Individual Line	•	•	•		
2-Party Selective Flat Rate	•	•	•		
2-Party Selective Message Rate	•		•		
4-Party Selective	•			•	
4-Party Semiselective	•	•	•		
8-Party Semiselective	•			•	
750 PBX Station (Keyless)	•		•		·
755 PBX Station (Keyless)	•		•		
Divided Code Ringing	•	•	•		
Nonselective Party Line	•	•	•	<u> </u>	

<sup>\*</sup>L1AMP ringer is a modular loud ringing bell used in factories, garages and outdoor locations (waterproof housing available, see Section 463-130-100).

NOTICE

This document is either AT&T - Proprietary, or WESTERN ELECTRIC - Proprietary

Pursuant to Judge Greene's Order of August 5, 1963, beginning on January 1, 1984, AT&T will cease to use "Bell" and the Bell symbol, with the exceptions as set forth in that Order. Pursuant thereto, any reference to "BELL" and/or the BELL symbol in this document is hereby deleted and "expunged".

<sup>†</sup>S1 AM ringer is a modular tone ringer used in indoor locations.

<sup>‡</sup>E1CM ringer is a modular ringer to be used when an extension ringer is required (not waterproof).

<sup>§687</sup>B subscriber set is an auxiliary signal for 4 party selective and 8 party semiselective service (nonmodular).

 $<sup>\</sup>P$ 687A subscriber set is an auxiliary signal for coin telephone lines only (nonmodular).