

LOCAL WIRING (6 PR. I.W. CA.)

TERMINAL BOARD

RELAY
(KS-19/32, L1 OR EQUIV)

C4A RINGER
SEE NOTES 4B5

425D NETWORK

SEE NOTE 1

SEE NOTE 2

LOCAL WIRING (6 PR. I.W. CA.)

NOTE 1: CONNECT TO ONE OF THE FOLLOWING:
A. HAND TELEPHONE SET CIRCUIT.
B. HAND TELEPHONE SET USED WITH PLUG-IN HANDSET.
C. TELEPHONE JACK STATION CIRCUIT.
(FOR USE WITH HAND TELEPHONE SET FOR JACK STATION OR A HANDSET FOR JACK STATION).

NOTE 2: CONNECT TO KEY TELEPHONE SYSTEM OR TELEPHONE CIRCUIT FOR 2 AND 4 WIRE LINES.

NOTE 3: CONNECT TO ONE OF THE FOLLOWING:
A. HAND TELEPHONE SET CIRCUIT.
B. HAND TELEPHONE SET USED WITH PLUG-IN HANDSET.
C. AMPLIFIER CIRCUIT FOR JACK STATION (687D SUBSCRIBER SET).

NOTE 4: TO MAKE THE VOLUME CONTROL ARM OPERATIVE, REMOVE COVER AND REMOVE RIVET IN THE BASE PLATE.

NOTE 5: TO SILENCE RINGER, REFER TO THE SECTION THAT COVERS THE C-TYPE RINGERS.

Fig. 1 - Connections for Key Telephone System or Telephone Circuit for 2- and 4- Wire Lines Using Separately Mounted Keys