

STATION DIALS SUPPLIES

1. GENERAL

1.01 This section is reissued to convert it to letter size and to incorporate material from the addendum in its proper location. In the process of this conversion, marginal arrows have been omitted.

2. SUPPLIES

2.01 Supplies for station dials are contained under sub-headings for each type of dial.

<u>INDEX</u>	<u>ORDERING INFORMATION AND USE</u>		
7-type Dial			
Assembly (Cardholder Frame)	P-298106, CARDHOLDER FRAME ASSEMBLY.	Nut (Finger Wheel)	P-153996, FINGER WHEEL NUT.
Assembly (Finger Wheel)	P-43A342, FINGER WHEEL ASSEMBLY. Plastic.	Plates (Number)	PLATE, NUMBER, 158B. Red figures and black letters. An outside number plate for use with coin collectors equipped with 6-type dial and 63A dial adapter.
Assemblies (Ring)	P-17A422, RING ASSEMBLY. Gray rubber gasket for use with colored dials. P-347300, RING ASSEMBLY. Black rubber gasket for use with black dials.	Screw	PLATE, NUMBER, 164A. Red figures and black letters.
Finger Wheel	P-349543, FINGER WHEEL. Metal.	Washer (Finger Wheel)	PLATE, NUMBER, 164B. Blank; for use with coin collectors.
Nut (Finger Wheel)	P-153996, FINGER WHEEL NUT.	4- and 5-type Dials	
Plates (Number)	P-17A971, NUMBER PLATE. Gray P-17A972, NUMBER PLATE. Red. P-17A973, NUMBER PLATE. Yellow. P-17A974, NUMBER PLATE. Blue. P-19B819, NUMBER PLATE. Ivory. P-19B820, NUMBER PLATE. Green. P-19B821, NUMBER PLATE. Brown. P-19B822, NUMBER PLATE. Beige. P-349755, NUMBER PLATE. Black.	Assembly (Cardholder Frame)	P-298106, CARDHOLDER FRAME ASSEMBLY.
	P-160875, SCREW. For mounting dial.	Assembly (Finger Wheel)	P-43A212, FINGER WHEEL ASSEMBLY. Plastic.
	P-459447, FINGER WHEEL WASHER.	Finger Wheel	P-153971, FINGER WHEEL. Metal.
		Nut (Finger Wheel)	P-153996, FINGER WHEEL NUT.
		Plates (Number)	PLATE, NUMBER, 147A*. Black figures only. An outside number plate for use with coin collectors and on 320-type telephone sets at hazardous locations.
			PLATE, NUMBER, 147B*. Red figures and black letters. An outside number plate for use with coin collectors and on 320-type telephone sets at hazardous locations.
			PLATE, NUMBER, 147E*. Black figures with the letters J, M, R, and W above 5, 6, 7, and 9, respectively. An outside number plate for use with coin collectors and on 320-type telephone sets at hazardous locations.
			* When ordering for hazardous locations, specify "For Use With 320-type Telephone Sets."
6-type Dial			
Assembly (Cardholder Frame)	P-298106, CARDHOLDER FRAME ASSEMBLY.		
Assembly (Finger Wheel)	P-43A342, FINGER WHEEL ASSEMBLY. Plastic.		
Finger Wheel	P-349543, FINGER WHEEL. Metal.		

SECTION C34.102

INDEX

ORDERING INFORMATION
AND USE

4- and 5-type Dials (Contd)

Plates (Number) (Contd)

PLATE, NUMBER, 150A.

Black figures only.

PLATE, NUMBER, 150E.

Black figures with the letters
J, M, R, and W above 5, 6, 7,
and 9 respectively.

PLATE, NUMBER, 164A.

Red figures and black letters.

INDEX

ORDERING INFORMATION
AND USE

4- and 5-type Dials (Contd)

Plates (Number) (Contd)

PLATE, NUMBER, 164B.

Blank; for use with coin col-
lectors.

PLATE, NUMBER, 164C3.

Black plate with white dots at the
finger hole positions.

P-131556, SCREW.

For mounting dial.

Screw

**P-459447, FINGER WHEEL
WASHER.**

Washer (Finger Wheel)