




CONNECTIONS FOR SPECIAL 1248-W TELEPHONE.
RINGER CODES A, B, S.



NOTES:

1. GROUND IS NOT TO BE CONNECTED ON INDIVIDUAL AND CODE RINGING LINES.
2. WHEN "S" RINGER IS USED REMOVE STRAP "A".

RINGER CONNECTIONS 2 AND 4 PARTY SELECTIVE.



NOTES:

1. REMOVE STRAP "B".
2. + PARTY LINE 1- RED OF RINGER TO 1. BLACK TO G.
3. + PARTY LINE 2- RED OF RINGER TO 2. BLACK TO G.
4. - PARTY LINE 1- BLACK OF RINGER TO 1. RED TO G.
5. - PARTY LINE 2- BLACK OF RINGER TO 2. RED TO G.