


WIRING AND CONNECTIONS 1243A-1243S-1243E-1243F-1243G-1243H TELEPHONE SETS

F 1G,1




BOVE CONNECTIONS ARE FOR M PARTY (-TIP)
FOR R PARTY (-RING), CONNECT TUBE AND
RINGER LEADS AS SHOWN ABOVE AND
REVERSE RED AND GREEN OF LINE CORD
AT TERMINALS L1 AND L2.

ABOVE CONNECTIONS ARE FOR "PARTY (+TIP)
FOR W PARTY (+RING), CONNECT TUBE AND
RINGER LEADS AS SHOWN ABOVE AND
REVERSE RED AND GREEN OF LINE CORD
AT TERMINALS LI AND L2.

RINGER AND 333A VACUUM TUBE CONNECTIONS
1243TA
TELEPHONE SET

FIG.2



ABOVE CONNECTIONS ARE FOR EVEN NUMBERED STATIONS - RING SIDE OF LINE TO GROUND.

FOR ODD NUMBERED STATIONS — TIP SIDE OF LINE TO GROUND, REVERSE RED AND GREEN OF LINE CORD AT TERMINALS L1 AND L2.

WIRING-LINE, RINGER AND RELAY CONNECTIONS 1243VE-1243VF-1243VG-1243VH-1243VN TELEPHONE SETS

F1G,3