## **Stromberg-Carlson Frequency Ringer Designations**

The code is usually engraved on bottom of ringer where it's "boss post" goes into the hookswitch frame, and is visible through a round hole in S-C 500/2500 bases.

NOTE: S-C 12 Series are similar to the SC-C4A1, but have capacitor across the slate/red and slate points on the coil. S-C 20 Series are a single gong ringer; Stromberg frequency versions are marked with the series number, "W" plus the suffix letter shown below.

R: 16 Hz.

E: 16-2/3 Hz.

I: 20 Hz.

N: 25 Hz.

K: 30 Hz.

F: 33-1/3 Hz.

O: 40 Hz.

L: 42 Hz.

G: 50 Hz.

M: 50 Hz.,

M: 54 Hz.

J: 60 Hz.

P: 66 Hz.

H: 66-2/3 Hz.