## STROMBERG-CARLSON CORPORATION S-C 1500 DI TELEPHONE WIRING DIAGRAM S-C 425E NETWORK | HANDSET STRIP ST. LINE RINGER HOOKSWITCH MOUNTING CORD S-C 35A3 DIAL MAKES & S-W G (TIP)+ S-RI BREAKS LAST Y (GRD) ВК RECEIVER S TRANSMITTER 8ĸ S-R R (RING)-0-BK 16,162,20,25 CYCLE RINGERS ONLY 40,42,50,54,60,66,662/3 CYCLE RINGERS ONLY 30833/3 CYCLE RINGERS ONLY G (TIP) + G (TIP)+ G(TIP)+ Y (GRD) Y (GRD) Y (GRD) R (RING)-R (RING) -R(RING) -900 ISSUE NO.3 missing

TABLE OF CONNECTIONS																									
CLASS OF	CONNECTIONS AT						CONNECTIONS AT NETWORK																		
SERVICE	CONNECTING			_	MTG. CD.			MTG. CORD		STRAIGHT LINE RINGER LEADS				30 & 33½RINGER LEADS			ALL OTHER FREQ. LEADS				HOOKSWITCH		LEADS		
	RING	TIP	GND			Y		G		R	BK	S		R		K	S	S-R	R	BK EL	S	S-R	s	s-w	S-BR
BRIDGED	R	G	Υ	R	G	G	L2	LI	G	L2	G	К	Α	Li	2 (	G	Α	Α	L2	G	К	Α	L2	F	С
RING PARTY	R	G	Y	R	G	Y	L2	Li	G	L2	G	K	Α	L	2	G	Α	Α	L2	G	K	Α	L2	F	С
TIP PARTY NO IDENT TO GRD.	R	G	Y	R	G	Y	L2	LI	G	LI	G	к	A	L	1	G	A	A	LI	G	к	A	L2	F	С
TIP PARTY 1000^IDENT TO GRD.	R	G	Y	G	R	Y	L2	LI	G	к	G	В	В	Α	, (		8	В	к	G	В	В	Α	С	F
TIP PARTY 2650^IDENT TO GRD.	R	G	Y	G	R	Y	L2	LI	G	В	В	к	G	-		_	_	_	-	_	_	_	А	С	F
FOUR PARTY IDENTIFICATION	R	G	Y		EE )TE I	Y	L2	LI	G	-		_	_	Α	(	G	SE NOT	E I	к	G	SI NOT	EE E I		SEE NOTE	1

## NOTES:

- I-FOR FOUR PARTY IDENTIFICATION SERVICE (WITH FREQUENCY RINGER ONLY) CONNECT IDENTIFICATION ASSEMBLY BETWEEN NETWORK TERMINAL (B) AND S-R AND S LEADS OF RINGER. IDENTIFICATION ASSEMBLY AND INSTRUCTIONS MAY BE FOUND IN PACKAGE ASSEMBLY 206287-841.
- 2-TO PERMANENTLY SILENCE RINGERS:
  - A-FOR ALL SERVICES EXCEPT TIP PARTY IDENTIFICATION TO GROUND TRANSFER BK RINGER LEAD TO (A) TERMINAL OF NETWORK.
  - B-FOR TIP PARTY 1000 IDENTIFICATION TO GROUND TRANSFER S-R RINGER LEAD TO (K) TERMINAL OF NETWORK. BK LEAD TO (G) AND S LEAD TO (B) MUST REMAIN CONNECTED FOR PARTY IDENTIFICATION.
  - C-FOR TIP PARTY 2650 IDENTIFICATION TO GROUND WITH STRAIGHT LINE RINGER, TRANSFER BK RINGER LEAD TO (K) TERMINAL OF NETWORK. S-R LEAD TO (G) AND R LEAD TO (B) MUST REMAIN CONNECTED FOR PARTY IDENTIFICATION.
  - D-FOR FOUR PARTY IDENTIFICATION, TRANSFER S-R RINGER LEAD TO (K) TERMINAL OF NETWORK. BK LEAD TO (G) AND S LEAD TO IDENTIFICATION ASSEMBLY MUST REMAIN CONNECTED FOR PARTY IDENTIFICATION.