

STROMBERG-CARLSON CORP 1704-6B TELEPHONE WIRING DIAGRAM

NOTES:

1. When a COMMON SIGNAL is required using standard ringing voltage, the following options are available.
 - A. S-C series 20 straight line ringer. Order package assembly 702100-244, and wire as shown. Exception—when capacitor is required to block D.C. from ringer, connect red ringer wire to network terminal K and strap terminal 26 to network terminal A.
 - B. S-C series 20 ringer for 60 Hz. Order package assembly 702100-260. Connect black wire to terminal 47 and red wire to terminal 26. Do not wire in capacitor A-K.
 - C. Tone ringer. Order package assembly 202100-621 and wire per instruction sheet in package assembly using terminals 26 and 47.
 - D. S-C #2 A buzzer. Order package assembly 206014-621. Connect red wire to terminal 47 and brown wire to terminal 26.
2. When an INTERCOM BUZZER is required, the following options may be used.
 - A. Type 7 (A.C. or D.C.) buzzer. Requires mounting plate package assembly 206289-671.
 - B. "Q" buzzer. Mounted per instruction sheet 300981-191.
 - C. #0-E buzzer (10 to 20 volt D.C.). Order package assembly 206289-681, #0-E buzzer (S-C part no. 212709-000) may also be mounted with type 7 buzzer using package assembly 206289-671.
3. For INTERCOM BUZZER to be audible when off-hook, move buzzer lead from terminal 25 to 21.
4. When telephone is used with W.E. BUSY LAMP FIELD, move slate-green hookswitch wire from terminal 24 to 1 and add 1 IN1694 diode (S-C part no. 202852-138) as shown.
5. When telephone is used with S-C IA2 BUSY STATION NUMBER DISPLAY, order diode package assembly 206286-451 and change wiring per instruction sheet in package assembly.
6. When "B" LEADS are NOT REQUIRED, "B" lead wires may be used as spares or multiplied together as A1 leads on terminals 19 and 20.
7. When a KEY POSITION is used as a SIGNALING POSITION, remove screw from key plunger to make key position non-locking and make the following wiring change.
 - A. Position 1 - move white wire from terminal 51 to 52.
 - B. Position 2 - move orange wire from terminal 51 to 52.
 - C. Position 3 - move brown wire from terminal 50 to 52.
 - D. Position 4 - move green wire from terminal 49 to 52.
 - E. Position 5 - move slate wire from terminal 49 to 52.
8. To use telephone with 6K-1 SYSTEM.
 - A. Strap terminals IC1 and IC2.
 - B. When position 5 is used as line 5 connect BK-BR to H5. When position 5 is used as a signaling position connect to 10V (60~NI) and remove screw from key plunger to make key position non-locking.
 - C. To provide intercom with all buttons released, connect T-I-C and R-I-C to T and R respectively of the line intercom circuit for manual intercom. Connect T-I-C, R-I-C, C-I-C and L-I-C to T, R, C and L respectively of dial intercom circuit for dial intercom.
9. In S-C IA2 or W.E. IA2 SYSTEM, to provide intercom with all buttons released, connect T, R, A, L and LG to dial or manual intercom circuit as shown.
10. To convert telephone for use with S-C 6K or W.E. 1A SYSTEMS, the following changes are required. (No changes are required for S-C 6K-1 or W.E. IA1 systems).

<ol style="list-style-type: none">A. Remove all wires from terminals 19 and 20 and store.B. Move slate-yellow hookswitch wire from terminal F to 19.C. Move white key wire from terminal GN to 20.	<ol style="list-style-type: none">D. Move black-white key wire from terminal GN to F.E. Move black key wire from terminal 50 and store.F. Move red-white key wire from terminal R to 50.
--	--
11. To use telephone with S-C 4-20 DIAL INTERCOM SYSTEM.
 - A. Move black wire from terminal 50 to 52.
 - B. Add IN1694 Diode between terminals as shown.
 - C. Connect brown-yellow cable wire to "S" of the 4-20 system.
 - D. Connect T-I-C and R-I-C to tip and ring respectively of the 4-20 system.
 - E. Connect SZ cable wire to R-I-C.
12. When MANUAL EXCLUSION feature is desired, order package assembly 206289-781 and wire as shown. Use terminals 27, 28 and 29 for exclusion on line 1; 32, 33 and 34 for exclusion on line 2; 37, 38 and 39 for exclusion on line 3; 42, 43 and 44 for exclusion on line 4; or 8, 9 and 10 for exclusion on line 5. Connect BL-V, V-BL and V-O conductors of cable to excluded line of excluded stations.

S-C 9-2C DIAL

S-C 4010B NETWORK

HANDSET

TERMINAL BOARDS

HOOKEWITCH (ON HOOK)

SIGNALS

KEY & CONNECTOR

TELEPHONE CONNECTOR

TERMINAL BOARDS

CONNECTOR

TEL LINE CORD

WIRING FOR 6K OR 6A SYSTEMS NOTE-10

WIRING FOR S-C 1A2 OR W.E. 1A, 1A1, 1A2 & 6A SYSTEMS NOTE-10

