

R-2761 SKINNING KNIFE

DESCRIPTION AND USE

1. GENERAL

1.01 This Section is issued to provide information concerning the description and safe use of the R-2761 Skinning Knife.

1.02 This section is reissued to include the option of wearing Whizard® mesh gloves, or leather gloves, when using the R-2761 Skinning Knife.

2. DESCRIPTION

2.01 The R-2761 Skinning Knife has a 2 inch blade with a "sheepfoot point", and a 4 inch insulated handle. It is provided with a leather sheath for storage.

3. USE

3.01 The R-2761 Skinning Knife may be used in the preparation of any polyethylene sheath.

4. PRECAUTIONS

4.01 When using the R-2761 Skinning Knife, the following precautions shall be practiced: wear leather gloves or Whizard® mesh gloves and eye protection; keep the other hand away from the direction in which force is being applied; don't use on items held between knees or legs; keep the knife sharp; don't use the knife if the cutting point is rounded.