



Note: If filter is not provided connect brown-yellow lead from the switch contacts to Y of dial instead of to filter bracket terminal. Terminals Y-BK, SR and W-BB are on the manual set apparatus blank.

Fig. 1—D-173487 (3-Conductor), 302E, F, G and H Telephone Sets—Connections

1 Line and Ringer Connections: Connections to the line are made by the mounting cord and connections for this cord at the telephone set are considered line connections. The red conductor of the mounting cord is the ring side of the line and the green conductor of the cord is the tip side of the line. On grounded ringing lines a three-conductor mounting cord is used and the third conductor (yellow) is used to bring a ground into the telephone set.

2 The 302E, F, G and H sets are provided with a three-conductor cord and come wired for tip party stations as shown in Fig. 1. The 302A, B, C and D sets were provided with a two-conductor cord and came wired for bridged ringing.