

B ADHESIVE CLIP

1. GENERAL

- 1.01 This section is reissued to show B adhesive clip rated (MD).
- 1.02 The B adhesive clip (Fig. 1) is used to fasten station wiring where it is undesirable to mar surfaces.
- 1.03 Best adhesion is obtained on a clean, smooth surface.



High temperature may deteriorate B adhesive clips during storage; therefore, those not used before date on container should be tested for tackiness.




Fig. 1—B Adhesive Clip (MD)

2. INSTALLATION

- 2.01 Attach B adhesive clip as follows:

- (1) Thoroughly moisten adhesive surface with trichloroethylene.
- (2) Allow sufficient time for adhesive to become tacky, about the consistency of fly paper.
- (3) Press clip to bonding surface for about 5 seconds.
- (4) Allow clip to set for 15 minutes.
- (5) Place station wire in clip and form tabs over wire.