SUBSCRIBER SETS

RINGER AND RELAY TYPES - POLARIZED RINGING

531C, 534DT, 592C, 687B

COMMON AND LOCAL BATTERY - CONNECTIONS





Fig. 1 - 531C or 687B Subscriber Set Connections
Positive Parties - No Induction



NOTE 1: FOR NEGATIVE STATIONS IN OFFICES WITHOUT ANI, R LEAD FROM 426A TUBE MAY BE CONNECTED TO GRD IF RINGER IS MARGINAL.

Fig. 2 - 531C or 687B Subscriber Set Connections Negative Parties - No Induction




Fig. 3 - 531C or 687B Subscriber Set Connections Negative Parties - Average Induction




Fig. 4 - Modified 531C or 687B Subscriber Set Connections Negative Parties - Severe Induction




Fig. 5 - Modified 531C or 687B Subscriber Set Connections
Positive Parties - Average to Severe Induction

PARTY	NEGATIVE (-) ON RING	NEGATIVE (-) ON TIP	POSITIVE (+) ON RING	POSITIVE (+) ON TIP	NOTE 1: FOR NEGATIVE STATIONS IN OFFICES WITH- OUT ANI, R LEAD FROM 426A TUBE MAY BE CONNECTED TO GRD IF RINGER OPERATION IS MARGINAL.
POSITION	I AND 5	2 AND 6	3 AND 7	4 AND 8	
LEAD	RING (R)	TIP (GN)	GRD (Y)	GRD (Y)	L2 (Y)
INSIDE WIRE FROM PROTECTOR OR LINE					(R) (BK)

Fig. 6 - 534DT Subscriber Set Connections

PARTY	NEGATIVE	NEGATIVE	POSITIVE (+)	POSITIVE (+)	NOTE 1: FOR NEGATIVE STATIONS IN OFFICES WITH OUT ANI, R LEAD FROM 426A TUBE MAY BE CONNEC- TED TO GRD IF RINGER OPERATION IS MARGINAL.
POSITION	ON RING	ON TIP	ON RING	ON TIP	
LEAD	RING	TIP	GRD	GRD	Y (Y)
INSIDE WIRE FROM PROTECTOR OR LINE	(R)	(GN)	(Y)	(Y)	(BK)
LEAD	(Y)	(Y)	(R)	(GN)	(R) (BK) K
	NOTE I	NOTE I		L	

Fig. 7 - 592C Subscriber Set Connections