# **ALTEC LANSING**

# **SECTION 1**

## AMPLIFIERS for TELEPHONE SERVICE

- 129A DISTRIBUTION AMPLIFIER
- 447B TELEPHONE REPEATER TYPE (issue 3)
- 453B 600/900 TELEPHONE REPEATER TYPE (issue 2)
- 453B TELEPHONE REPEATER TYPE (issue 4)
- 453BX TELEPHONE REPEATER TYPE (issue 3)
- 455B 600/900 TELEPHONE REPEATER TYPE (issue 2)
- 455B TELEPHONE REPEATER TYPE (issue 4)
- 455BX TELEPHONE REPEATER TYPE (issue 2)
- 456B TELEPHONE REPEATER TYPE
- 460A TELEPHONE REPEATER TYPE
- 460B TELEPHONE TYPE COMPRESSOR AMPLIFIER
- 461A TELEPHONE REPEATER TYPE
- 469A TELEPHONE REPEATER TYPE (issue 2)
- 479A TELEPHONE REPEATER TYPE
- 480A TELEPHONE REPEATER TYPE
- 481A EQUALIZING AMPLIFIER
- 489A COMBINATION PREAMPLIFIER/POWER AMPLIFIER
- 2227A TELEPHONE REPEATER TYPE (WECo 227 EQUVELENT)

# 129A DISTRIBUTION AMPLIFIER






Figure 1. ALTEC 129A Distribution Amplifier

#### SPECIFICATIONS

Type: Power amplifier (with accessories for

program bridge operation)

Gain: 40 dB

Input Sensitivity: 0.78 volt for full-rated output power

(without input transformer)

Power Output: 6 watts at less than 5.0% THD from 100

Hz to 15 KHz

With 13151 Distribution Board, +15 dBm at less than 2.0 THD from 100 Hz to 15 KHz from each of 20 outputs terminated

by 600 ohms

47,000 ohms Input Impedance:

Source Impedance: 500/600, 250/300, 125/150, 30/50

ohms with 4665 Plug-in Transformer

Load Impedance: 4, 8, or 16 ohm, or 20, 600 ohm lines

with 13151 Distribution Board

Frequency Response: ±1 dB from 30 to 15,000 Hz

Controls: Volume Control with audio taper, Power

Switch, four test jacks to permit circuit

alignment and measurements Power Supply: 117 volts, 60 Hz, 85 watts Dimensions: 5-7/32" H x 19" W x 6" D

Finish: Panel - Dark Green

Chassis - Dichromate dip

Weight: 13 lb.

ALTEC 4665 Transformer Requisite Accessory:

Optional Accessories: ALTEC 17224 Equalizer (8 KHz) or

ALTEC 17249 Equalizer (15 KHz) ALTEC 13151 Distribution Board

#### DESCRIPTION

The ALTEC 129A Amplifier is a rack-mounted, ac-operated, three-stage power amplifier. When equipped with the ALTEC 13151 Distribution Board, it will provide up to twenty outputs for distribution over telephone or intercommunication lines. The 129A provides mounting facilities for the 13151 Board as an accessory, as well as both of the equalizers and the ALTEC 4665 Plug-in Transformer. The 13151 Distribution Board, an accessory, contains resistors which build out the twenty outputs from the four-ohmsecondary winding of the output transformer. The distribution may be sectionalized with each section connected to a different secondary tap, and the range of output

levels of +2, +5 and +8 dBm may be obtained . This feature may prove useful when lines are to be fed which present different transmission equivalents. Each output is balanced, and provides a source impedance of 300 ohms. The 13151 Board is an optional accessory since the amplifier may be used to feed a single load.

The unit occupies three units of rack space (5-7/32 inches) and has a hinged front panel on which are mounted the power switch, pilot light, gain control, and four circuit test jacks. All circuitry is accessible for installation and servicing when the front panel is open.

An optional accessory, the 17224 (8 KHz) or the 17249 (15 KHz) Equalizer, permits equalization to be effected at the high frequencies and thereby offsets telephone cable losses.

## APPLICATION

The ALTEC 129A Amplifier is designed to permit specially recorded messages to be relayed to telephone subscribers to advise of a change in an exchange code or a subscriber's number. Also, it may be used for time signals, weather and athletic events; and, in general, to feed any type of program material over telephone lines to places such as supermarket chains, wired music subscribers, etc.

## INSTALLATION AND OPERATION

The 129A Amplifier will always be installed at the central offices of a telephone system, and mounted on an equipment rack. The source of input signal is connected to the terminal block at the rear of the chassis, and the output signals are obtained at the resistor-network distribution board located within the unit, access to which may be obtained by lowering the front panel. The board, which mounts forty resistors (twenty balanced outputs), is wired so that all the outlets are connected to the four-ohm secondary winding of the output transformer. If required, the outlets may be sectionalized by cutting strapping connections. Each section may deliver a different output level and may be connected respectively to the four-, eight-, and sixteen-ohm secondary windings of the output transformer. These appear at a terminal strip inside and to the extreme lower right of the unit. The black lead is common and the orange, yellow, and green leads are the four-, eight-, and sixteenohm taps, respectively. It should be noted that the highest



degree of loop loss between the outlets is achieved when the lowest source impedance is used at the transducer.

In some installations the amplifier may feed a low impedance source such as a loudspeaker, and the resistor board will not be required. Four test jacks are provided to facilitate alignment and level checks when used with transmission measuring equipment. The line loop may be checked at the LINE jacks; the equalizer may be checked at the EQUALIZER jack (or disconnected by a dummy plug); and an input signal may be applied directly to the amplifier at AMP IN. The MONITOR jack permits the output level to be determined when the unit is in operation, the level indicated being the level normally fed to a line. The VOLUME (gain) control and the POWER switch are located on the front panel. If an ALTEC 17224 (8 KHz) or 17249 (15 KHz) Equalizer is used to correct the frequency/amplitude characteristic of an incoming telephone line, lowering the front panel will provide access for alignment. Alignment is accomplished by sending signals from the remote end of the line over the frequency range concerned and adjusting the equalizer potentiometer and the gain control of the amplifier until the desired frequency characteristic and transmission equivalent is obtained. Refer to the operating instructions of the 17224 or 17249 Telephone Cable Equalizers in the Equalizer

section of the Telecommunication Products Catalogue.

These equalizers mount at the rear of the chassis, through the holes provided and are fastened by 6-32 nuts. Wired connections must be made between the two terminals of the equalizer and the two-way terminal strip which is located nearby.

## SERVICING

All circuitry is completely exposed for service when the hinged front cover is opened and lowered. All routine servicing may be done by means of voltage and resistance checks.

The ALTEC 13151 Board mounts inside the chassis on the lower panel and may be fixed in place by inserting three 6-32 screws through the side panel and into the threaded inserts on the board. Wire connections between the board and the secondary winding of the output transformer are made at the seven-way terminal strip located at the extreme right of the lower panel. The board may be wired to give a single level, or a range of levels, at the numbered output terminals. The MONITOR jack feed may be wired to any one of the three transformer impedances to suit the requirements of the installation.




Figure 2. Schematic 129A Distribution Amplifier




Figure 1. 447B Amplifier

#### **SPECIFICATIONS**

Frequency Response:

Gain:

Distortion:

Maximum Power Input: Maximum Power Output:

Output Noise Level: Input Gain Control:

Operating Voltage:

Operating Current: Impedance, Output: Impedance, Input:

Monitor Facilities:

Mounting Socket: Dimensions:

Finish:

Weight: Accessories:  $\pm 1.0$  dB from 200 to 6000 Hz 39  $\pm 1.0$  dB (matched load)

1.5% THD (at +10 dBm 200 to 6000

Hz)

-22 dBm (at maximum gain)

+17 dBm -70 dBm

Varies gain from -2.0 dB to maximum

of 39 dB 20V dc

50 milliamperes 600 ohms

600 ohms

 $11\pm1.5$  dB below amplifier output available at test jacks on front panel and connector J1 when bridged by

600 ohms

11-pin socket (Amphenol 78-S11) 1-5/8" H  $\times$  1-5/8" W  $\times$  5" D C admium plate with dichromate

inish

14 ounces

ALTEC 7305A Mounting Panel (mounts twelve 447B Amplifiers)

ALTEC 12910 Mounting Panel (mounts ten 447B Amplifiers for standard 19" rack mounting)

ALTEC 12962 or ALTEC 13227 Mounting Assembly (mounts single 447B Amplifier for 105 type Appa-

ratus Box)

ALTEC 14115A Assembly (mounts two 447B Amplifiers in a KTU-15A type

frame)

## DESCRIPTION

The ALTEC 447B Transistor Amplifier is a two-stage, plug-in unit, designed for use in voice frequency circuits and used as a direct replacement for the 408A tube-type amplifier. The amplifier can be operated from a 20 volt central office or battery supply. Telephone repeater systems can be assembled using this amplifier and other additional plug-in items of equipment.




Figure 2. Dimensional Drawing

With a maximum gain control setting, the amplifier is capable of receiving 1.0 milliwatt input without harmful effects to the transistors. Negative feedback is utilized to reduce distortion and to stabilize gain within 0.3 dB for a 25 percent reduction of supply voltage. When the ambient temperature increases from 75 to 110 degrees Fahrenheit; the gain decreases 0.2 dB. Output capacity is adequate for a maximum +10 VU level of the transmitting toll switchboard and other equipment having a similar signal level. The input and output longitudinal balance is sufficiently high so that normal noise requirements are met without use of a mid-point ground.

#### INSTALLATION AND OPERATION

The ALTEC 447B Amplifier is dependent upon the polarity of the power supply for its operation. Prior to installation, make certain that the positive side of the supply is at pin 9, and the negative at pin 8, of the 11-pin socket of the mounting. The amplifier should be inserted into its socket carefully to prevent possible damage to the pins of the connector plug.


In order to adjust the gain control, which has a range of approximately 40 dB, the locknut located on the front panel must be released. The level of the monitor pins on the front panel (bridged by 600 ohms) is approximately 11 dB below the output level of the unit. After adjustment is completed, carefully retighten the locknut and recheck the gain settings to make certain that the control shaft has not been disturbed in the tightening operation.

Please refer to the ALTEC Telephone Engineering Department if information is desired in reference to gain versus temperature, change in gain versus output power, phase shift characteristics and envelope delay and distortion characteristics.

## MAINTENANCE

In the event of a malfunction, use the ALTEC 13204 or 13903 Extractor Tool to remove the unit from its mounting. Use of a replacement amplifier will permit quick restoration of service. The amplifier may be serviced locally or returned to the manufacturer for repair. If it is necessary to remove the unit from its protective cover, remove the two screws and plate from the rear (plug end), then withdraw the unit from the front.





|  | F. MEE WESTSTONS - 5 W OWE  | 233 011   | TERWISE INDICATED.   |                        |   |
|--|---|---|--|------------------------|---|
| C1<br>C2<br>C3<br>C4<br>C5<br>C6<br>J1<br>Q1<br>Q2<br>R1<br>R2<br>R3 | Capacitor, 8 mfd, 6V (Sprague 40D126A1) Capacitor, 10 mfd, 12V (Sprague 40D146A1) Capacitor, 50 mfd, 3V (Sprague 40D112A1) Capacitor, 0.2 mfd, 200V (Hopkins P22D) Capacitor, 200 mfd, 3V (Sprague 40D116A1) Capacitor, 20 mfd, 50V (Sprague 40D195A1) Plug, 11-pin (Amphenol 86-CP-11) Transistor (G.E. 2N191) Transistor (G.E. A2N188A) Resistor, $12\Omega \pm 10\%$ , $1/2W$ Resistor, $100K\Omega \pm 5\%$ , $1/2W$ Resistor, $10K\Omega \pm 5\%$ , $1/2W$ | R4<br>R5<br>R6<br>R7<br>R8<br>R9<br>R10<br>R11<br>R12 | Resistor, $4.7 \text{K}\Omega \pm 5\%$ , $1/2 \text{W}$<br>Resistor, $1 \text{K}\Omega \pm 5\%$ , $1/2 \text{W}$<br>Resistor, $120 \Omega \pm 5\%$ , $1/2 \text{W}$<br>Resistor, $820 \Omega \pm 5\%$ , $1/2 \text{W}$<br>Resistor, $5.6 \text{K}\Omega \pm 5\%$ , $1/2 \text{W}$<br>Resistor, $12 \text{K}\Omega \pm 1\%$ , $1/2 \text{W}$<br>(Dalohm DC1/2 or equivalent)<br>Resistor, $82 \Omega \pm 5\%$ , $1/2 \text{W}$<br>Resistor, $390 \Omega \pm 5\%$ , $1/2 \text{W}$<br>Resistor, $820 \Omega \pm 5\%$ , $3 \text{W}$ (Sprague 242E8215 or $1 \text{Tr} - 0 \text{hm} \text{VAL } 3-820$ )<br>Resistor, $27 \Omega \pm 5\%$ , $1/4 \text{W}$ | R14<br>R15<br>T1<br>T2 | Resistor, $5.1K\Omega \pm 5\%$ , $1/2W$<br>Potentiometer, $2K\Omega$ , $Z$ taper (Clarostat CM22782)<br>Transformer (ALTEC 4729)<br>Transformer (ALTEC 16483) |

Figure 3. Schematic 447B Transistor Amplifier

# 453B 600/900 TRANSISTOR AMPLIFIERS TELEPHONE REPEATER TYPE (ISSUE 2)




Figure 1. 453B 600/900 Transistor Amplifier

## **SPECIFICATIONS**

Frequency Response:

Gain:

Distortion:

Maximum Power Input: Maximum Power Output:

Output Noise Level:

Input Gain Control:

Operating Voltage:

Operating Current: Impedance, Input:

Impedance, Output:

Monitor Facilities:

Simplex:

Mounting Socket: Dimensions:

Finish:

Weight:

Accessories:

±1.0 dB from 200 to 6000 Hz  $39 \pm 1.0$  dB (matched to load)

1.5% THD (at +10 dBm, 200 to 6000

-22 dBm (at maximum gain)

+17 dBm -70 dBm

Varies gain from -2.0 dB to maximum

of 39 dB 24 to 26V dc

20 milliamperes 600 or 900 ohms

600 or 900 ohms 11.0 ±1.5 dB below amplifier output

is available at test jacks on the front panel when bridged by 600 ohms

100 milliamperes maximum with 5.0 milliamperes maximum out-of-bal-

11-pin socket (Amphenol 78-S11) 1-5/8" H x 1-5/8" W x 5" D

Cadmium plate with dichromate

finish

14 ounces

ALTEC 7305A Mounting Panel (mounts up to twelve 453B 600/900

Amplifiers)

ALTEC 7316A Mounting Panel (mounts up to ten 453B 600/900 Amplifiers)

ALTEC 12962 or ALTEC 13227 Mounting Assembly (mounts single 453B 600/900 Amplifier for type 105

Apparatus Box)

ALTEC 14115A Assembly (mounts two 453B 600/900 Amplifiers in KTU-15A

type frame)

## DESCRIPTION

The ALTEC 453B 600/900 Transistor Amplifier is a two-stage, plug-in unit designed for use in voice frequency circuits. It can be operated from a 24 to 26V central office or battery supply. Telephone repeater systems can be assembled using these amplifiers and additional ALTEC plug-in items of equipment. The ALTEC 453B 600/900 Amplifier provides dual input and output impedances of 600 and 900 ohms, internally selected.



Figure 2. Dimensional Drawing

With a maximum gain control setting, the amplifier is capable of receiving 1 milliwatt input without harmful effects to the transistors. Negative feedback is utilized to reduce distortion and to stabilize gain within 0.3 dB for a 25 percent reduction of supply voltage. When the ambient temperature increases from 75 to 110 degrees Fahrenheit, the gain decreases 0.2 dB. Output capacity is adequate for a maximum+10 VU level of the transmitting to 11 switchboard and equipment having a similar signal level. Center taps are furnished on input and output transformers for a maximum simplex current of 100 milliamperes, with a permissible five milliampere out-of-balance current. The input and output transformer longitudinal balance is sufficiently high that normal noise requirements can be met without the use of a mid-point ground.

Please refer to the ALTEC Telephone Engineering Department if information is desired in reference to gain versus temperature, change in gain versus output power, phase shift characteristics and envelope delay and distortion characteristics.

## INSTALLATION AND APPLICATION

The ALTEC 453B 600/900 Transistor Amplifier is dependent upon the polarity of the power supply for its operation. Prior to installation, make certain that the positive side of the supply is at pin 9, and the negative at pin 8, of the 11-pin socket of the mounting. The amplifier should be inserted carefully into its socket to prevent possible damage to the pins of the connector plug.

The ALTEC 453B 600/900 Amplifier (24 to 26V dc) is shipped wired for 600 ohm operation. If the amplifier is to be used in 900 ohm facilities, the input and output pair must be removed from terminals 1 and 2 of the terminal strips (TS1 and TS2, Figure 3) and transferred to terminals 3 and 4.




Figure 3



A Division of GTV Ling Altec, Inc

To change the input impedance from 600 to 900 ohms, proceed as follows:

- 1. Unsolder the orange wire from terminal 1 (TS1, Figure 3) and resolder the wire to terminal 3.
- Unsolder the black-white wire from terminal 2 and resolder the wire to terminal 4.

To change the output impedance from 600 to 900 ohms, proceed as follows:

- Unsolder the green-white wire from terminal 1 (TS2, Figure 3), and resolder it to terminal 3.
- 2. Unsolder the brown wire from terminal 2 and resolder it to terminal 4.

## NOTE

When changing input and output impedances, transfer only those wires connected to the 11-pin plug (J1) of the amplifier. Do not transfer the wiring from transformers T1 or T2.

In order to adjust the gain control, which has a range of approximately 40 dB, the lock nut, located on the front panel, must be released. The level at the monitor pins on the front panel (bridged by 600 ohms) is 11 dB below the output level of the unit. After adjustment is completed, carefully re-tighten the lock nut and recheck the gain settings to make certain that the control shaft has not been disturbed in the tightening process.

## MAINTENANCE

In the event of a malfunction, use the ALTEC 13204 or 13903 Extractor Tool to remove the unit from its mounting. Use of a replacement amplifier will permit quick restoration of service. The unit may be serviced locally or returned to the manufacturer for repair. If it is necessary to remove the unit from its protective cover, remove the two screws and plate from the rear (plug end), then withdraw the unit from the front.




Figure 4. Schematic 453B 600/900 Transistor Amplifier



Figure 1. 453B Transistor Amplifier

## SPECIFICATIONS

±1.0 dB from 200 to 6000 Hz Frequency Response: Gain:

 $39 \pm 1 \, dB \, (matched to load)$ Distortion: 1.5% THD (at 10 dBm, 200 to

6000 Hz)

-22 dBm (at maximum gain) Maximum Power Input:

Maximum Power Output: +17 dBm Output Noise Level: -70 dBM

Input Gain Control: Varies gain from -2.0 dB to maxi-

mum of 39 dB

Operating Voltage: 24 to 26V dc Operating Current: 20 milliamperes Impedance, Input: 600 ohms

Impedance, Output: 600 ohms Simplex:

100 milliampere maximum with 5 milliamperes maximum out-of-

balance

Monitor Facilities: 11 ±1.5 dB below amplifier output is

available at test jacks on front panel when bridged by 600 ohms 11-pin socket (Amphenol 78-S11) 1-5/8" H x 1-5/8" W x 5" D

Cadmium plate with dichromate finish

Weight: 14 ounces

Mounting Socket:

Dimensions:

Finish:

Accessories: ALTEC 7305A Mounting Panel

(mounts twelve 453B Amplifiers) ALTEC 7316A Mounting Panel (mounts up to ten 453B Amplifiers) ALTEC 12910 Mounting Panel (mounts ten 453B Amplifiers for

standard 19" rack mounting.) ALTEC 12962 or ALTEC 13227 Mounting Assembly (mounts single 453B Amplifier for 115 type appa-

ratus box)

ALTEC 14115A Assembly (mounts two 453B Amplifiers in KTU-15A type

frame)

#### DESCRIPTION

The ALTEC 453B Transistor Amplifier is a two-stage, plug-in unit designed for use in voice frequency circuits and can be operated from 24 to 26 volt central office or battery supply.



Figure 2. Dimensional Drawing

Telephone repeater systems may be assembled by using the 453B Amplifier and other ALTEC plug-in items.

With a maximum gain control setting, the 453B Amplifier is capable of receiving 1.0 milliwatt input without harmful effects to the transistors. Negative feedback is utilized to reduce distortion and to stabilize gain within 0.3 dB for a 25 percent reduction of supply voltage. When the ambient temperature increases from 75 to 110 degrees Fahrenheit, the amplifier gain decreases 0.2 dB. Output capacity is adequate-for a maximum +10 VU level of the transmitting toll switchboard and other equipment having a similar signal level. The input and output longitudinal balance is sufficiently high so that normal noise requirements are met without use of a mid-point ground.

## INSTALLATION AND OPERATION

The ALTEC 453B Amplifier is dependent upon the polarity of the power supply for its operation. Prior to installation, make certain that the positive side of the supply is at pin 9, and the negative at pin 8, of the 11-pin socket of the mounting. The amplifier should be inserted into its socket carefully to prevent damage to the pins of the connector plug.

In order to adjust the gain control, which has a range of approximately 40 dB, the locknut located on the front panel must be released. The level of the monitor pins on the front panel (bridged by 600 ohms) is approximately 11 dB below the output level of the unit. After adjustment is completed, carefully retighten the locknut and recheck the gain settings to make certain that the control shaft has not been disturbed in the tightening operation.

Please refer to the ALTEC Telephone Engineering Department if information is desired in reference to gain versus temperature, change in gain versus output power, phase shift characteristics and envelope delay and distortion characteristics.

## MAINTENANCE

In the event of a malfunction, use the ALTEC 13204 or 13903 Extractor Tool to remove the unit from its mounting. Use of a replacement amplifier will permit quick restoration of service. The unit may be serviced locally or returned to the manufacturer for repair. If it is necessary to remove the unit from its protective cover, remove the two screws and plate from the rear (plug end), then withdraw the unit from the front.






Figure 3. Schematic 453B Transistor Amplifier

T2

Transformer (ALTEC 16495)

**R8** 

R9

R10

R11

Resistor,  $5.6K\Omega \pm 5\%$ , 1/2W

(Dalohm DC1/2 or equivalent)

Resistor,  $12K\Omega \pm 1\%$ , 1/2W

Resistor,  $82\Omega \pm 5\%$ , 1/2W

(Clarostat CM22782)

Resistor,  $680\Omega \pm 5\%$ , 1/2W

Potentiometer, 2KΩ, Z taper

Resistor,  $5.1K\Omega \pm 5\%$ , 1/2W

C1

C6

Jī

Q1

Q2

R1

R2

**R3** 

Capacitor, 20 mfd, 50V (Sprague 40D195A1)

Plug, 11-pin (Amphenol 86-CP-11)

Transistor (G.E. 2N191)

Transistor (G.E. A2N188A)

Resistor,  $12\Omega \pm 10\%$ , 1/2W

Resistor,  $100K\Omega \pm 5\%$ , 1/2W

Resistor,  $10K\Omega \pm 5\%$ , 1/2W

# 453BX TRANSISTOR AMPLIFIER TELEPHONE REPEATER TYPE (ISSUE 3)




Figure 1. 453BX Transistor Amplifier

## SPECIFICATIONS

Frequency Response:

Gain: Distortion:

Maximum Power Input:

Maximum Power Output: Output Noise Level:

Input Gain Control:

Operating Voltage: Operating Current:

Impedance, Input: Impedance, Output: Monitor Facilities:

Simplex:

Mounting Socket: Dimensions: Finish:

Weight: Accessories: ±1.0 dB from 200 to 6000 Hz  $39 \pm 1.0 \, dB \, (matched \, load)$ 

1.5% THD (at +10 dBm, 200 to 6000

-22 dBm (at maximum gain) +17 dBm

-70 dBm

Varies gain from -2.0 dB to maximum

of 39 dB 24 - 26V dc 20 milliamperes

600 ohm 600 ohm

11.0  $\pm$ 1.5 dB below amplifier output is available at test jacks on the front panel when bridged by 600 ohm

100 milliamperes maximum with 5.0 milliamperes maximum out-of-

balance

11-pin socket (Amphenol 78-S11) 1-5/8" H x 1-5/8" W x 5" D Cadmium plate with dichromate

finish

14 ounces

ALTEC 7305A Mounting Panel (mounts up to twelve 453BX Ampli-

ALTEC 7316A Mounting Panel (mounts up to ten 453BX Amplifiers) ALTEC 12910 Mounting Panel (mounts up to ten 453BX Amplifiers) ALTEC 12962 or ALTEC 13227 Mounting Assembly (mounts single 453BX Amplifier for type 105 Apparatus Box)

ALTEC 14115A Assembly (mounts two 453BX Amplifiers in KTU-15A type

frame)

## DESCRIPTION

The ALTEC 453BX Transistor Amplifier is a two-stage, plug-in unit designed for use in voice frequency circuits. The amplifier can be operated from a 24 to 26V dc central office or battery supply. Telephone repeater systems can be assembled using the 453BX Amplifier with additional ALTEC plug-in units.



Figure 2. Dimensional Drawing

With a maximum gain control setting, the amplifier is capable of receiving 1 milliwatt input without harmful effects to the transistors. Negative feedback is utilized to reduce distortion and to stabilize gain within 0.3 dB for a 25 percent reduction of supply voltage. When the ambient temperature increases from 75 to 110 degrees Fahrenheit, the gain decreases 0.2 dB. Output capacity is adequate for a maximum +10 VU level of the transmitting toll switchboard and equipment having a similar signal level. Center taps are furnished on input and output transformers for a maximum simplex current of 100 milliamperes, with a permissible five milliampere out-of-balance current. The input and output transformer longitudinal balance is sufficiently high that normal noise requirements can be met without the use of a mid-point ground.

Please refer to the ALTEC Telephone Engineering Department if information is desired in reference to gain versus temperature, change in gain versus output power, phase shift characteristics and envelope delay and distortion characteristics.

## INSTALLATION AND OPERATION

The ALTEC 453BX Transistor Amplifier is dependent upon the polarity of the power supply for its operation. Prior to installation, make certain that the positive side of the supply is at pin 9, and the negative at pin 8, of the 11-pin socket of the mounting. The amplifier should be inserted carefully into its socket to prevent possible damage to the pins of the connector plug.

In order to adjust the gain control, which has a range of approximately 40 dB, the lock nut located on the front panel must be released. The level at the monitor pins on the front panel (bridged by 600 ohms) is 11 dB below the output level of the unit. After adjustment is completed, carefully re-tighten the lock nut and recheck the gain settings to make certain that the control shaft has not been disturbed in the tightening operation.


## MAINTENANCE

In the event of a malfunction, use the ALTEC 13204 or 13903 Extractor Tool to remove the unit from its mounting. Use of a replacement amplifier will permit quick restoration of service. The unit may be serviced locally or returned to the manufacturer for repair. If it is necessary to remove the unit from its protective cover, remove the two screws and plate from the rear (plug end), then withdraw the unit from the front.



Specifications and components subject to change without notice. Overall performance will be maintained or improved.

Litho in USA



X1,2 Thyrector (G.E. 6RS5SP1B1)

Figure 3. Schematic 453BX Transistor Amplifier

C5

C6

JI

Q1

Q2

R1

R2

R3

Capacitor, 200 mfd, 3V (Sprague 40D116A1)

Capacitor, 20 mfd, 50V (Sprague 40D195A1)

Plug, 11-pin (Amphenol 86-CP-11)

Transistor (G.E. 2N191)

Transistor (G.E. 2N188A)

Resistor,  $12\Omega \pm 10\%$ , 1/2W

Resistor,  $100K\Omega \pm 5\%$ , 1/2W

Resistor,  $10K\Omega \pm 5\%$ , 1/2W

**R8** 

R9

R10

R11

R12

R13

Resistor, 5.6K $\Omega$  ± 5%, 1/2W

Resistor,  $12K\Omega \pm 1\%$ , 1/2W

Resistor,  $82\Omega \pm 5\%$ , 1/2W

Resistor,  $680\Omega \pm 5\%$ , 1/2W

(Clarostat CM 22782)

Potentiometer, 2KΩ, Z taper

Resistor,  $5.1K\Omega \pm 5\%$ , 1/2W

(Dalohm DC1/2 or equivalent)

# 455B 600/900 TRANSISTOR AMPLIFIER TELEPHONE REPEATER TYPE (ISSUE 2)




Figure 1. 455B 600/900 Transistor Amplifier

## SPECIFICATIONS

Frequency Response: Gain:

Distortion:

Maximum Power Input:

Maximum Power Output: Output Noise Level:

Input Gain Control:

Operating Voltage: Operating Current: Impedance, Input: Impedance, Output:

Monitor Facilities:

Simplex:

Mounting Socket: Dimensions: Finish:

Weight: Accessories: ±1.0 dB from 200 to 6000 Hz  $39 \pm 1.0$  dB (matched to load)

1.5% THD (at +10 dBm, 200 to 6000 Hz)

-22 dBm (at maximum gain)

+17 dBm -70 dBm

Varies gain from -2.0 dB to maximum

of 39 dB

48 to 52V dc 20 milliamperes 600 or 900 ohms 600 or 900 ohms

11  $\pm 1.5$  dB below amplifier output is available at test jacks on the front panel when bridged by 600 ohms

100 milliamperes maximum with 5.0 milliamperes maximum out-of-bal-

11-pin socket (Amphenol 78-S11) 1-5/8" H × 1-5/8" W × 5" D Cadmium plate with dichromate

finish

14 ounces

ALTEC 7305A Mounting Panel (mounts up to twelve 455B 600/900

Amplifiers)

ALTEC 7316A Mounting Panel (mounts up to ten 455B 600/900 Amplifiers)

ALTEC 12910 Mounting Panel (mounts up to ten 455B 600/900 Amplifiers)

ALTEC 12962 or ALTEC 13227 Mounting Assembly (mounts single 455B 600/900 Amplifier for type 105 Apparatus Box)

ALTEC 14115A Assembly (mounts two 455B 600/900 Amplifiers in KTU-15A type frame)

DESCRIPTION

The ALTEC 455B 600/900 Transistor Amplifier is a two-stage, plug-in unit designed for use in voice frequency circuits. It can be operated from a 48 to 52V central office or battery supply. Telephone repeater systems can be assembled using



Figure 2. Dimensional Drawing

these amplifiers and additional ALTEC plug-in items of equipment. The ALTEC 455B 600/900 Amplifier provides dual input and output impedances of 600 and 900 ohms, internally selected.

With a maximum gain control setting, the amplifier is capable of receiving 1.0 milliwatt input without harmful effects to the transistors. Negative feedback is utilized to reduce distortion and to stabilize gain within 0.3 dB for a 25 percent reduction of supply voltage. When the ambient temperature increases from 75 to 110 degrees Fahrenheit, the gain decreases 0.2 dB. Output capacity is adequate for a maximum +10 VU level of the transmitting toll switchboard and equipment having a similar signal level. Center taps are furnished on input and output transformers for a maximum simplex current of 100 milliamperes, with a permissible five milliampere out-of-balance current. The input and output transformer longitudinal balance is sufficiently high that normal noise requirements can be met without the use of a mid-point ground.

Please refer to the ALTEC Telephone Engineering Department if information is desired in reference to gain versus temperature, change in gain versus output power, phase shift characteristics and envelope delay and distortion characteristics.

## INSTALLATION AND APPLICATION

The ALTEC 455B 600/900 Transistor Amplifier is dependent upon the polarity of the power supply for its operation. Prior to installation, make certain that the positive side of the supply is at pin 9, and the negative at pin 8, of the 11-pin socket of the mounting. The amplifier should be inserted carefully into its socket to prevent possible damage to the pins of the connec-

The ALTEC 455B 600/900 Amplifier (48 to 52V dc) is shipped wired for 600 ohm operation. If the amplifier is to be used in 900 ohm facilities, the input and output pair must be removed from terminals 1 and 2 of the terminal strips (TS1 and TS2, Figure 3) and transferred to terminals 3 and 4.




Figure 3



To change the input impedance from 600 to 900 ohms, proceed as follows:

- Unsolder the orange wire from terminal 1 (TS1, Figure 3) and resolder the wire to terminal 3.
- 2. Unsolder the black-white wire from terminal 2 and resolder the wire to terminal 4.

To change the output impedance from 600 to 900 ohms, proceed as follows:

- Unsolder the green-white wire from terminal 1 (TS2, Figure 3) and resolder it to terminal 3.
- Unsolder the brown wire from terminal 2 and resolder it to terminal 4.

#### NOTE

When changing input and output impedances, transfer only those wires connected to the 11-pin plug (J1) of the amplifier. Do not transfer the wiring from transformers Tlor T2.

In order to adjust the gain control, which has a range of approximately 40 dB, the lock nut, located on the front panel, must be released. The level at the monitor pins on the front panel (bridged by 600 ohms) is 11 dB below the output level of the unit. After adjustment is completed, carefully re-tighten the lock nut and recheck the gain settings to make certain that the control shaft has not been disturbed in the tightening process.

#### MAINTENANCE

In the event of a malfunction, use the ALTEC 13204 or 13903 Extractor Tool to remove the unit from its mounting. Use of a replacement amplifier will permit quick restoration of service. The unit may be serviced locally or returned to the manufacturer for repair. If it is necessary to remove the unit from its protective cover, remove the two screws and plate from the rear (plug end), then withdraw the unit from the front.




Figure 4. Schematic 455B 600/900 Transistor Amplifier




Figure 1. 455B Transistor Amplifier

#### SPECIFICATIONS

Frequency Response:

Gain: Distortion:

Maximum Power Input:

Maximum Power Output: Output Noise Level:

Input Gain Control:

Operating Voltage:
Operating Current:

Impedance, Input:
Impedance, Output:

Monitor Facilities:

Simplex:

Mounting Socket: Dimensions: Finish:

Weight: Accessories:  $\pm 1.0$  dB from 200 to 6000 Hz 39  $\pm 1.0$  dB (matched to load) 1.5% THD (at +10 dBm, 200 to 6000

Hz)

-22 dBm (at maximum gain)

+17 dBm -70 dBm

Varies gain from -2.0 dB to maximum

of 39 dB

48 to 52V dc 20 milliamperes 600 ohms 600 ohms

11.0 ±1.5 dB below amplifier output is available at test jacks on the front panel when bridged by 600 ohms 100 milliamperes maximum with 5.0 milliamperes maximum out-of-bal-

ance

11-pin socket (Amphenol 78-S11) 1-5/8" H  $\times$  1-5/8" W  $\times$  5" D C admium plate with dichromate

finish 14 ounces

ALTEC 7305A Mounting Panel (mounts up to twelve 455B Amplifiers) ALTEC 7316A Mounting Panel (mounts up to ten 455B Amplifiers) ALTEC 12910 Mounting Panel (mounts up to ten 455B Amplifiers) ALTEC 12962 or ALTEC 13227 Mounting Assembly (mounts single 455B Amplifier for type 105 Appa-

ratus Box) ALTEC 14115A Assembly (mounts two 455B Amplifiers in KTU-15A type

frame)

## DESCRIPTION

The ALTEC 455B Transistor Amplifier is a two-stage, plug-in unit designed for use in voice frequency circuits. It can be operated from a 48 to 52V dc central office or battery supply. Telephone repeater systems can be assembled using these amplifiers and additional ALTEC plug-in items of equipment.




Figure 2. Dimensional Drawing

With a maximum gain control setting, the amplifier is capable of receiving 1.0 milliwatt input without harmful effects to the transistors. Negative feedback is utilized to reduce distortion and to stabilize gain within 0.3 dB for a 25 percent reduction of supply voltage. When the ambient temperature increases from 75 to 110 degrees Fahrenheit, the gain decreases 0.2 dB. Output capacity is adequate for a maximum +10 VU level of the transmitting tollswitchboard and equipment having a similar signal level. Center taps are furnished on input and output transformers for a maximum simplex current of 100 milliamperes, with a permissible five milliampere out-of-balance current. The input and output transformer longitudinal balance is sufficiently high that normal noise requirements can be met without the use of a mid-point ground.

Please refer to the ALTEC Telephone Engineering Department if information is desired in reference to gain versus temperature, change in gain versus output power, phase shift characteristics and envelope delay and distortion characteristics.

## INSTALLATION AND APPLICATION

The ALTEC 455B Transistor Amplifier is dependent upon the polarity of the power supply for its operation. Prior to installation, make certain that the positive side of the supply is at pin 9, and the negative at pin 8, of the 11-pin socket of the mounting. The amplifier should be inserted carefully into its socket to prevent possible damage to the pins of the connector plug.

In order to adjust the gain control, which has a range of approximately 40 dB, the lock nut, located on the front panel, must be released. The level at the monitor pins on the front panel (bridged by 600 ohms) is 11 dB below the output level of the unit. After adjustment is completed, carefully re-tighten the lock nut and recheck the gain settings to make certain that the control shaft has not been disturbed in the tightening process.


## MAINTENANCE

In the event of a malfunction, use the ALTEC 13204 or 13903 Extractor Tool to remove the unit from its mounting. Use of a replacement amplifier will permit quick restoration of service. The unit may be serviced locally or returned to the manufacturer for repair. If it is necessary to remove the unit from its protective cover, remove the two screws and plate from the rear (plug end) then withdraw the unit from the front.



Litho in USA

ANSING



- Capacitor, 50 mfd, 3.0V (Sprague 40D112A1) C4 Capacitor, 0.2 mfd, 200V (Hopkins P22D) C5 Capacitor, 200 mfd, 3V (Sprague 40D116A1) Capacitor, 20 mfd, 50V (Sprague 40D195A1) Plug, 11-pin (Amphenol 86-CP-11) Jl Q1 Transistor, (G.E. 2N191) Q2 Transistor, (G.E. A2N188A) R1 Resistor,  $12\Omega \pm 10\%$ , 1/2WResistor,  $100K\Omega \pm 5\%$ , 1/2WResistor,  $10K\Omega \pm 5\%$ , 1/2W
- R6 Resistor,  $120\Omega \pm 5\%$ , 1/2W**R7** Resistor,  $820\Omega \pm 5\%$ , 1/2W**R8** Resistor, 5.6K $\Omega \pm 5\%$ , 1/2W R9 Resistor,  $12K\Omega \pm 1\%$ , 1/2W(Dalohm DC1/2 or equivalent) Resistor,  $82\Omega \pm 5\%$ , 1/2WResistor,  $2K\Omega \pm 5\%$ , 3W (Sprague 242E2025, Tru-ohm VAL 3-2000 or equivalent) R12 Potentiometer, 2KΩ, Z taper (Clarostat CM22782)
- TI Transformer (ALTEC 4733) Transformer (ALTEC 16495)



# 455BX TRANSISTOR AMPLIFIER TELEPHONE REPEATER TYPE (ISSUE 2)



Figure 1. 455BX Transistor Amplifier

## **SPECIFICATIONS**

Frequency Response:

Gain:

Distortion:

Maximum Power, Input:

Maximum Power, Output: +17 dBm Output Noise Level:

Input Gain Control:

Operating Voltage: Operating Current:

Impedance, Input: Impedance, Output:

Monitor Facilities:

Simplex:

Mounting Socket: Dimensions:

Finish:

Accessories:

Weight:

±1.0 dB from 200 to 6000 Hz  $39 \pm 1.0 \, dB \, (matched to load)$ 

1.5% THD (at +10 dBm, 200 to 6000

-22 dBm (at maximum gain)

-70 dBm

Varies gain from -2.0 dB to maximum

of 39 dB 48 to 52V dc

20 milliamperes 600 ohms 600 ohms

11 ±1.5% dB below amplifier output is available at test jacks on the front

panel when bridged by 600 ohms 100 milliamperes maximum with 5.0

milliamperes maximum out-of bal-

11-pin socket (Amphenol 78-S11) 1-5/8" H x 1-5/8" W x 5" D

Cadmium plate with dichromate

finish

14 ounces

ALTEC 7305A Mounting Panel

(mounts up to twelve 455BX Amplifiers)

ALTEC 7316A Mounting Panel (mounts up to ten 455BX Amplifiers) ALTEC 12910 Mounting Panel (mounts up to ten 455BX Amplifiers) ALTEC 12962 or ALTEC 13227 Mounting Assembly (mounts single 455BX Amplifier for type 105 Appa-

ratus Box)

ALTEC 14115A Assembly (mounts two 455BX Amplifiers in KTU-15A frame)

## DESCRIPTION

The ALTEC 455BX Repeater Type Transistor Amplifier is a twostage, plug-in unit designed for use in voice frequency circuits. The amplifier can be operated from a 48 to 52 volt central office or battery supply. Telephone repeater systems can be assembled using this amplifier and additional ALTEC plug-in items of equipment.




Figure 2. Dimensional Drawing

With maximum gain control settings, the amplifier is capable of receiving 1.0 milliwatt input without harmful effects to the transistors. Negative feedback is utilized to reduce distortion and to stabilize gain within 0.3 dB for a 25 percent reduction of supply voltage. When the ambient temperature increases from 75 to 110 degrees Fahrenheit, the gain decreases 0.2 dB. Output capacity is adequate for a maximum of +10 VU level of the transmitting toll switchboard and equipment having a similar signal level. Center taps are furnished on input and output transformers for a maximum simplex current of 100 milliamperes, with a permissible five milliampere out-of-balance current. The input and output transformer longitudinal balance is sufficiently high that normal noise requirements can be met without the use of a midpoint ground.

The 455BX Amplifier is provided with protective devices (Thyrectors) which minimize the effect of extraneous static, lightning, or power line surges.

Please refer to the ALTEC Telephone Engineering Department if information is desired in reference to gain versus temperature, change in gain versus output power, phase shift characteristics and envelope delay and distortion characteristics.

## INSTALLATION AND APPLICATION

The ALTEC 455BX Amplifier is dependent upon the polarity of the power supply for its operation. Prior to installation, check to ascertain that the positive side of the supply is at pin 9, and the negative at pin 8, of the 11-pin socket of the mounting. The amplifier should be inserted carefully into its socket to prevent possible damage to the pins of the connector plug.

In order to adjust the gain control, which has a range of approximately 40 dB, the lock nut, located on the front panel, must be released. The level at the monitor pins on the front panel (bridged by 600 ohms) is 11 dB below the output level of the unit. After adjustment is completed, carefully re-tighten the lock nut and recheck the gain settings to make certain that the control shaft has not been disturbed in the tightening process.

## MAINTENANCE

In the event of a malfunction, use the ALTEC 13204 or 13903Extractor Tool to remove the unit from its mounting. Use of a replacement amplifier will permit quick restoration of service. The unit may be serviced locally or returned to the manufacturer for repair. If it is necessary to remove the unit from its protective cover, remove the two screws and plate from the rear (plug end), then withdraw the unit from the front.

Specifications and components subject to change without



## PARTS LIST - 455BX (ISSUE 2) - ALTEC SCHEMATIC NUMBER 8334-1

```
C1
        Capacitor, 8 mfd, 6 v (Sprague 40D126A1)
                                                                              Resistor,
                                                                                           1000 \Omega \pm 5\%, 1/2 w
                                                                      R5
C2
        Capacitor, 10 mfd, 12 v (Sprague 40D146A1)
                                                                      R6
                                                                                            120 \Omega \pm 5\%, 1/2 w
                                                                              Resistor,
C3
        Capacitor, 50 mfd, 3 v (Sprague 40D112A1)
                                                                      R7
                                                                                            820 \Omega \pm 5\%, 1/2 w
                                                                              Resistor,
C4
       Capacitor, 0.2 mfd, 200 v (Hopkins P22D)
                                                                      R8
                                                                              Resistor.
                                                                                           5600 \Omega \pm 5\%, 1/2 w
C5
       Capacitor, 200 mfd, 3 v (Sprague 40D116A1)
                                                                      R9
                                                                              Resistor, 12,000 \Omega \pm 1\%, 1/2 w (Dalohm DC1/2)
       Capacitor, 20 mfd, 50 v (Sprague 40D195A1)
C6
                                                                      R10
                                                                              Resistor,
                                                                                             82 \Omega \pm 5\%, 1/2 w
JI
       Plug, 11-pin (Amphenol 86-CP-11)
                                                                                           2000 \Omega \pm 5\%, 3 w (Sprague 242E 2025)
                                                                      R11
                                                                              Resistor,
Q1
       Transistor (G. E. 2N191)
                                                                      R12
                                                                              Potentiometer, 2000 \Omega, Z taper (Clarostat)
Q2
       Transistor (Altec AL 2N188A)
                                                                      R13
                                                                                           5100 \Omega \pm 5\%, 1/2 w
                                                                              Resistor,
RI
       Resistor.
                      12 \Omega \pm 10\%, 1/2 w
                                                                      R14
                                                                                             47 \Omega \pm 5\%, 1/2 w
                                                                              Resistor.
R2
       Resistor, 100,000 \Omega \pm 5\%, 1/2 w
                                                                      Tl
                                                                              Transformer (Altec 4733)
R3
       Resistor, 10,000 \Omega \pm 5\%, 1/2 w
                                                                      T2
                                                                              Transformer (Altec 16495)
R4
        Resistor,
                    4700 \Omega \pm 5\%, 1/2 w
                                                                   X1,X2
                                                                              Thyrector (G. E. 6RS5SP1B1)
```




Figure 3. Schematic 455BX Transistor Amplifier

# 456B TRANSISTOR AMPLIFIER TELEPHONE REPEATER TYPE



Figure 1. 456B Transistor Amplifier



Frequency Response: ±1 dB, 200 - 6,000 Hz

Distortion: Below 1% THD (at +10 d B m , 200 -

6,000 Hz)

Maximum Power Input: -22 dBm (at maximum gain)

Maximum Power Output: +17 dBm Output Noise Level: -70 dBm

Input Gain Control: Varies gain from -2 dB to maximum

of 39 dB

Operating Voltage: 24 or 48 V dc (Selected by moving

screw, accessible on bottom of am-

plifier case)

Input Impedance: 600 ohms
Output Impedance: 600 ohms

Current Drain: 20 mA (at 25 and 50V dc, when

selector screw is in proper position)

Max. Simplex Current: 100 m/

Max. Out-of-Balance

Simplex Current:

Monitor Facilities:

5 mA

11 ± 1.5 dB below amplifier output is available at test jacks on front panel

and pins 7 and 10 on J1 when bridged

by 600 ohms

Dimensions:  $1-5/8" \text{ H} \times 1-5/8" \text{ W} \times 5" \text{ D}$ 

Finish: Cadmium plated/dichromate finish

Weight: 13 ounces

## DESCRIPTION

The 456B Amplifier is an all-transistor unit, utilizing three silicon transistors and a printed circuit for maximum uniformity of production and minimum variation in operational characteristics when subjected to ambient temperatures as great as 140°F. Operating voltage of the 456B is selectable (24 - 26 or 48 - 52V dc) by moving the small screw on the bottom of the amplifier case, to one of the two positions indicated as shown on the above illustration and on the schematic. This acts as a strap, connecting the B+, (pin 9), to either R10, 270 ohms, for 24 - 26 volt operation or to R11, 1500 ohms, for 48 - 52 volt operation.

The circuitry of the 456B Amplifier has been designed to minimize RF radiation from nearby relays, stepping switches, battery supply spikes, etc., in order that relatively high speed data




Figure 2. Dimensional Drawing

may be passed through the amplifier without excessive signal mutilation. The 456B will meet all published specifications for the ALTEC 453B and the 455B Repeater Amplifiers when operated within the proper voltage limits. With the gain control set at the maximum position, the ALTEC 456B is capable of receiving an input level of 1 milliwatt without damage to the transistors. Negative feedback is utilized to reduce distortion and to stabilize gain within 0.3 dB for a 25% reduction of supply voltage. When the ambient temperature increases from 100° to 140°F, the output impedance undergoes an insignificant variation of only -1.5%.

The output carrying capacity is adequate for a maximum +10 VU level of the transmitting toll switchboard and equipment having a similar level. The input and output longitudinal balance is sufficiently high, so that normal noise requirements are met without the use of a mid-point ground.

In-and-out center taps are provided for simplex operation; the maximum simplex current is 100 mA; maximum out-of-balance simplex current is 5 mA.

## **APPLICATIONS**

The 456B Amplifier is used in voice frequency communication circuits. A telephone repeater system can be assembled on the ALTEC 7300/7306A Telephone Repeater Terminating Unit, using these amplifiers and additional plug-in items of equipment.

## INSTALLATION AND OPERATION

The 456B depends upon the polarity of the repeater station supply voltage for proper operation. Prior to inserting the amplifier, it should be determined that the positive side of the supply is at pin 9; the negative side at pin 8 (of the 11-pin socket mounted on the repeater rack). The amplifier should be inserted carefully to prevent possible damage to the locating pin of the 11-pin plug connector; removal of the 456B is accomplished by means of the 13204 or 13903 extractor tool.

The gain control affords a range of approximately 40 dB. In order to adjust the gain, the lock nut on the control must be loosened. The level at the monitor pins on the front panel, bridged by 600 ohms, is 11 dB below the output level of the am-



plifier. After adjustment is completed, carefully tighten the locking nut and recheck the gain setting to ascertain that the control shaft is not disturbed in the tightening operation.

## MAINTENANCE

All 456B Amplifiers are of the plug-in type. In the event of a malfunction, the 13204 or 13903 extractor tool is used to remove the amplifier from the mounting panel. A replacement amplifier may then be installed, enabling rapid restoration to normal service. The defective amplifier may be serviced locally or returned to the manufacturer for repair. Should it become necessary to remove the amplifier from its protective cover,

remove the two screws and plate from the rear (plug end), then withdraw the unit from the front.

## SUPPORT EQUIPMENT

| PANEL  | CAPACITY      | LOCATION                        |
|--------|---------------|---------------------------------|
| 7305A  | 12 Amplifiers | 19-inch relay rack              |
| 7316A  | 10 Amplifiers | 19-inch relay rack              |
| 12910  | 10 Amplifiers | 19-inch relay rack              |
| 12962  | 1 Amplifier   | Type 105 apparatus box or equal |
| 13227  | 1 Amplifier   | Type 105 apparatus box or equal |
| 14115A | 2 Amplifiers  | KTU-15A type frame or equal     |

| C1<br>C2<br>C3<br>C4<br>C5,6<br>C7,8<br>CR1<br>J1<br>Q1,2<br>R1<br>R2 | Capacitor, 5 mfd, 25V (Sprague 40D176A1 or Callins ASDP 5-25, insulated) Capacitor, 10 mfd, 25V (Sprague 40D146A1 or Callins ASDP 10-12, insulated) Capacitor, 50 mfd, 25V (Sprague 40D506GO25DC3 or Callins ASDP 50-25, insulated) Capacitor, .002 mfd $\pm$ 20%, Z5U or Z5F ceramic disc Capacitor, .001 mfd $\pm$ 20%, Z5U or Z5F, ceramic disc Capacitor, .005 mfd $\pm$ 20%, Z5U or Z5F, ceramic disc Capacitor, .005 mfd $\pm$ 20%, Z5U or Z5F, ceramic disc Diode, 1N456A per dwg, 8668-1 Plug, 11-pin (Amphenol 86-CP-11) 3 Transistor (ALTEC 2712) Potentiometer, 1.68K $\Omega$ (ALTEC 14395-1) Resistor, $12\Omega \pm$ 10%, $1/2W$ (A.B.) | R3 Resistor (selected) $\pm$ 10%, 1/2W (A.B.) R4 Resistor, 15K $\Omega$ $\pm$ 10%, 1/2W (A.B.) R5 Resistor, 115 $\Omega$ $\pm$ 2%, 1/2W (A.B.) R6 Resistor, 22 $\Omega$ $\pm$ 5%, 1/2W (A.B.) R7 Resistor, 1.6K $\Omega$ $\pm$ 5%, 1/2W (A.B.) R8 Resistor, 1.6K $\Omega$ $\pm$ 5%, 1/2W (A.B.) R9 Resistor, 390 $\Omega$ $\pm$ 10%, 1/2W (A.B.) R10 Resistor, 27 $\Omega$ $\pm$ 10%, 1/2W (A.B.) R11 Resistor, 1.5K $\Omega$ $\pm$ 5%, 2W (Sprague 240E1525 or 3W Ohmite W.W. Axial L) R12, 13 Resistor, 10 $\Omega$ $\pm$ 5%, 1/2W (A.B.) T1 Transformer (ALTEC 4800) T2 Transformer (ALTEC 16653)  |
|---|---|---|
|   | TI CW CW RI4 IBK RI IG60.n. C4  | R4 15K 7.6V  OI AL2712  R7 1.6K  O6  O6  ONITOR O7  OBTAIN DESIRED VOLTAGE  R5 100.  R1 100.  R5 100. |
| NOTE C'   |   | 011   |

I.SELECTED IN TEST. VALUE BETWEEN 10K AND 50K AS REQUIRED TO ADJUST AMPLIFIER FOR MAX OUTPUT.

<sup>2.</sup> R6 NOMINAL VALUE IS 18 OHMS, THIS VALUE MAY BE SELECTED IF Q2 AND Q3 ARE HIGH GAIN TRANSISTORS. WHEN VALUE SHOULD BE BETWEEN 20 AND 27 OHMS.

# 460A TRANSISTOR AMPLIFIER TELEPHONE REPEATER TYPE

SECTION I



Figure 1. ALTEC 460A Amplifier

#### **SPECIFICATIONS**

Type: Compressor Amplifier Gain: 35 dB (no compression)

25 dB (35 dB change in input results in Compression:

10 dB change in output)

Power Output: +15 dBm with +5 dBm input

> +9 dBm with -10 dBm input +6 dBm with -20 dBm input +2 dBm with -30 dBm input Less than 6% at +5 dBm output

Distortion: Frequency Response: ±3 dB from 200 to 6000 Hz

Input Impedance: 600 ohms Load Impedance: 600 ohms Output Noise Level: -65 dBm

25 mA at 24V dc Power Required:

24 to 26V dc battery or rectified ac with Power Supply:

total ripple contents below 2 mV 1-5/8" H x 1-5/8" W x 5" D

Finish: Cadmium plate with dichromate finish Mounting Socket: 11-pin socket (Amphenol 78-S11)

Monitor Taps: 11 ±1.5 dB below amplifier output

available at test jacks on front panel

when bridged by 600 ohms

Simplex Taps: Primary of input transformer and second-

ary of output transformer center tapped

for dc simplex operation

Simplex Current: 100 mA maximum; 5 mA maximum out-

of-balance current

Weight: 16 ounces

#### DESCRIPTION

Dimensions:

The 460A Amplifier is a two-stage, transistorized plug-in compressor-type amplifier designed for use with telephone repeater and communication equipment. The amplifier operates from a 24 to 26 volt central office supply, a local battery or ALTEC power supply units. The output power is dependent upon the input signal and approximates +2 dBm with an input of -30 dBm, increases to +9 dBm with -10 dBm input and +15 dBm with +5 dBm input. Negative feedback is used to reduce distortion and to stabilize gain. The unit is designed to operate at temperatures of up to  $60^{\circ}$  C and is rated most conservatively at room temperatures.

A dc simplex current may be used to bypass the amplifier. A maximum current of 100 mA is permitted, provided out-of-balance current does not exceed 5 mA.




Figure 2. Dimensional Drawing

## APPLICATION

The 460A Amplifier may be used in voice frequency systems to enable a sensibly constant speech level output to be obtained when input signal levels vary widely. The amplifier may be used advantageously in many telephone system applications, some of which are:

> Toll Conference Grouping Systems Loudspeaking Telephone Systems Supervisory Monitoring

## SUPPORT EQUIPMENT

A number of mounting panels are available for the 460A Compressor Amplifier:

| PANEL  | CAPACITY      | LOCATION                        |
|--------|---------------|---------------------------------|
| 7305A  | 12 Amplifiers | 19-inch relay rack              |
| 7316A  | 10 Amplifiers | 19-inch relay rack              |
| 12910  | 10 Amplifiers | 19-inch relay rack              |
| 13227  | 1 Amplifier   | Type 105 apparatus box or equal |
| 14115A | 2 Amplifiers  | KTU-15A type frame or equal     |

#### INSTALLATION AND OPERATION

The 460A Compressor Amplifier should be inserted into its socket carefully to prevent possible damage to the pins of the connector plug. The 460A is a transistorized unit and is dependent upon the polarity of the power supply for its operation. Prior to connecting the amplifier, a careful check should be made to determine that the positive side is at pin 9, and the negative side is at pin 8 of the 11-pin socket of the mounting panel.

## MAINTENANCE

The 460A Compressor Amplifier is of the plug-in type. In the event of a malfunction, the 13204 or 13903 extractor tool is used to remove the amplifier from the mounting panel. A replacement amplifier will enable speedy restoration of service. The defective amplifier may be serviced locally or returned to the manufacturer for repair.






Figure 3. Schematic 460A Transistor Amplifier



## 460B TELEPHONE TYPE COMPRESSOR AMPLIFIER








Figure 2. Dimensional Drawing

#### **SPECIFICATIONS**

Type:

Telephone Type Compressor Ampli-

Gain:

 $35 \pm 1.5$  dB (without compression)

Compression

Threshold (LEVEL):

Adjustable, -9 to +10 dBm

Compression

Ratio (SLOPE):

Adjustable, 3:1 to 40:1

Maximum Power Output: +13 dBm

Distortion:

Below 5.0% THD, 300 to 6000 Hz

adjusted for +5.0 dBm output

Frequency Response:

 $\pm 1.0 \, dB$ , 300 to 6000 Hz at  $\pm 5.0$ 

dBM output

Input Impedance:

600 ohm

Load Impedance:

600 ohm

Noise Level:

-65 dBm

Operating Voltage

(By "U" link transfer):

48 to 52V (as shipped) or 24 to 26V

Current Drain:

20 to 30 milliamperes

Controls:

LEVEL and SLOPE, front mounted

potentiometers

Dimensions:

1-5/8" H x 1-5/8" W x 5-1/2" D

Finish:

Cadmium plate with dichromate

finish

Mounting:

Simplex Operation:

11-pin Amphenol 86-CP-11 plug to engage with 78-S11 equipment socket

Center tapped input and output

transformers

Simplex Current: 100 milliamperes maximum with 5

milliamperes out-of-balance current

Weight:

11 ounces

Accessories:

ALTEC 12910 Mounting Panel, 19"  $\times$  1-3/4" for standard rack mounting, containing ten 11-pin sockets for mounting ten 460B Amplifiers

ALTEC 13227 Assembly for mounting a single 460B Amplifier within a type 105B Apparatus Box or a custom

built panel

ALTEC 529A Power Supply (24V) capable of energizing up to 100 460B **Amplifiers** 


ALTEC 538A Power Supply Unit capable of energizing two 460B Ampli-

ALTEC 533A Power Supply Unit capable of energizing one 460B Ampli-

fier



## ALTEC 460B COMPRESSOR AMPLIFIER



SHOWING COMPRESSION RATIO (SLOPE) WITH THRESHOLD (LEVEL) CONTROL CW AND CCW

Figure 3

## DESCRIPTION

The 460B Compressor Amplifier is a two-stage, transistorized plug-in compressor-type amplifier designed for use with telephone repeater and communication equipment. The amplifier operates from 24 to 26 or 48 to 52V dc power. The output power is dependent upon the input signal and approximates -3 dBm with an input of -40 dBm, increases to +7 dBm with -30 dBm input and +14 dBm with -23 dBm input. Negative feedback is used to reduce distortion and to stabilize gain. The unit is designed to operate at up to 150°F (65°C).

The circuitry of the 460B Amplifier has been designed to reduce to a minimum, pickup of radiated interference from nearby stepping switches, relays and spikes arising from power supplies and other equipment. A reverse polarity diode is also included in the circuitry in order to protect the transistors if the power supply voltage is inadvertently reversed.

A dc simplex current may be used to bypass the amplifier. A maximum current of 100 milliamperes is permitted, provided out-of-balance current does not exceed 5 milliamperes.

## APPLICATION

The 460B Compressor Amplifier may be used in voice frequency systems to enable a relatively constant output speech level to be maintained with wide variations of input signal level. The amplifier may be used with advantage in many telephone system applications, some of which are:

Toll Conference Systems Loudspeaking Telephone Systems Systems as Used at Military Complexes Supervisory Monitoring

## INSTALLATION AND OPERATION

The ALTEC 460B Amplifier operation depends upon the polarity of the telephone repeater station supply voltage. Prior to inserting the amplifier into the mounting, it should be determined that the voltage "U" link position agrees with the operating voltage. Also, make certain that the positive of the supply is




Figure 4

on pin 9 of the socket, with the negative on pin 8. The amplifier should be inserted carefully to prevent damage to the plug pins or the locating keyway.

A functional check may be carried out by applying a 1000 Hz, -20 dBm signal at the input of the amplifier and noting that the output signal does not increase more than 3.0 dBm when the input signal is increased to "0" dBm.

## CAUTION

Damage to the equipment will result if 50 volts are applied to the equipment with the "U" link in the 24 volt position.

## Compression Resetting Procedure

## SLOPE Control (Initial Setting)

The SLOPE control, located on the front of the 460B Amplifier, should be turned fully clockwise (CW), then returned counterclockwise (CCW) by approximately 5.0 degrees. This is the minimum slope adjustment.

## LEVEL Control

When a 1000 Hz, 0 dB signal into 600-ohms, is applied to the input of the 460B Amplifier, the output signal leve! will remain constant regardless of any further increase in input signal level. However, a clockwise rotation of the LEVEL control, located on the front panel, will raise the level of the output threshold and decrease compression. A counterclockwise rotation of the LEVEL control will increase compression and again change the threshold.

## SLOPE Control (Resetting)

When a close value of compression relief is desired, a resetting of the SLOPE control will be necessary. A counterclockwise rotation of the SLOPE control will produce characteristics as shown by the graphs. (See Figures 3 and 4).

## MAINTENANCE

The 460B Amplifier is of the plug-in type. In the event of a malfunction, the unit should be withdrawn from the rack or panel with the aid of an ALTEC 13204 or 13903 Extractor Tool. The insertion of a serviceable unit will rapidly restore normal service. The defective amplifier may be serviced locally or

returned to the manufacturer for repair. To withdraw the amplifier assembly from its protective cover, remove the two screws from the rear (plug end) of the unit and withdraw the assembly from the front.

## PARTS LIST

| Reference  | Name and  | Reference  | Name and   |
|------------|---|------------|--|
| Designator | Description                                     | Designator | Description  |
| C1 12      | C   | 5.4        | 2-1  |
| C1,12      | Capacitor, 4 µF, 30V, PSD (Callins)             | R6         | Resistor, 15K $\Omega$ , 5%, 1/4W                  |
| C2         | Capacitor, 0.002 µF, Ceramic Disc (Erie)        | R <i>7</i> | Resistor, 115 $\Omega$ , 5%, 1/4W                  |
| C3,7       | Capacitor, 0.001 µF, Ceramic Disc (Erie)        | R8         | Resistor, $100 \Omega$ , $5\%$ , $1/4W$            |
| C4         | Capacitor, 150 µF, 3V, 285 PSS (Callins)        | R9.        | Potentiometer, 200K Ω, PC leads, 3/8" split        |
| C6         | Capacitor, 5 µF, 25V, PSS (Callins)             |            | locking bushing, 1/16" slotted shaft (Clarostat    |
| C5,8       | Capacitor, 10 µF, 10V, CM106 (Comps Inc.)       |            | 63M series)  |
| C9         | Capacitor, 3.3 µF, 12V, CM335 (Comps Inc.)      | R10,19     | Resistor, 1K $\Omega$ , 5%, 1/4W                   |
| C10        | Capacitor, 10 pF, 20V, CL106 (Comps Inc.)       | R11        | Resistor, $27 \Omega$ , $5\%$ , $1/4W$             |
| CII        | Capacitor, 50 µF, 25V, 4-85 PSD 50-25 (Callins) | R12        | Resistor, 1.6K Ω, 5%, 1/4W                         |
| C13,14     | Capacitor, 0.005 µF, Ceramic Disc (Erie)        | R13,17,18  | Resistor, 10K Ω, 5%, 1/4W                          |
| C15        | Capacitor, 0.1 µF, 200V, 10% (Electrocube       | R14,15     | Resistor, $10 \Omega$ , $5\%$ , $1/4W$             |
| 34         | 710)  | R16,25     | Resistor, 390 Ω, 5%, 1/4W                          |
| CR1,2,3,5  | Diode, 1N456                                    | R20        | Resistor, 68K Ω, 5%, 1/4W                          |
| CR4        | Diode, Zener, LPM 9.1A (Semcor)                 | R21        | Potentiometer, 15K $\Omega$ , PC leads, 3/8" split |
| CR6        | Diode (S52)                                     |            | locking bushing, 1/16" slotted shaft (Clarostat    |
| ЛÌ         | Plug (Amphenol 86-CP-11)                        |            | 63M series)  |
| Q1,2,3,4   | Transistor, (G.E 2N2712)                        | R22        | Resistor, 330 Ω, 5%, 1/4W                          |
| Q5,6       | Transistor, (G.E 2N3900A)                       | R23        | Resistor, 220 Ω, 5% 1/2W                           |
| R1         | Resistor, 2.7K Ω, 5%, 1/4W                      | R24        | Resistor, 1K Ω, 10%, 3W WW (Sprague)               |
| R2,3       | Resistor, 470 $\Omega$ , 5%, 1/4W               | Tl         | Transformer (ALTEC 4823)                           |
| R4         | Resistor, 470K $\Omega$ , 5%, 1/4W              | T2         | Transformer (ALTEC 16698)                          |
| R5         | Resistor, 3.9K Ω, 5%, 1/4W                      |            | •            |




Figure 5. Schematic 460B Compressor Amplifier

# 461A Transistor amplifier telephone repeater type




Figure 1. ALTEC 461A Amplifier

## **SPECIFICATIONS**

Type: Power Amplifier, Transistor Type, Class

B push-pull

Power Output: 2 watts maximum

Distortion: Less than 6% THD at 2 watts, 1000 Hz Gain: 22 dB (+11 dBm input for 2 watts output)

Input Impedance: 600 ohms
Load Impedance: 8 ohms

Frequency Response: ±1 dB, 100 to 6000 Hz relative to 1000

Hz

24V dc battery or rectified ac with total ripple contents below 2 mV and regulation better than 5% for a current

change of 250 mA

Power Required: 250 mA for 2 watts output Dimensions: 1-5/8" H x 1-5/8" W x 5" D

Finish: Cadmium plate with dichromate finish

Weight: 16 ounces

Mounting Socket: 11-pin socket (Amphenol 78-S11)

## DESCRIPTION

Power Supply:

The ALTEC 461A Amplifier is a single stage, push-pull Class B operated transistor power amplifier designed for use with telephone and other communciations equipment. The unit operates from a single supply source (24 volt) which may be obtained from a central office talking battery supply, a local battery, or from a power supply unit which has good regulation characteristics and low ripple content in its output. No other supply voltage is required.

The current drawn from the supply depends on the degree to which the unit is driven by the input signal. For example, with +11 dBm applied at the input, the output power approximates two watts and the current consumption is 250 mA. With no input signal, the current drawn is less than 20 mA.

The output power into the nominal output load of eight ohms is dependent on the input signal as indicated below:

| Input (600 ohms) | Output watts (8 ohms) |
|------------------|-----------------------|
| +11 dBm          | 2                     |
| + 8 dBm          | 1                     |
| + 5 dBm          | 1/2                   |

## APPLICATION

The output power of the 461A Amplifier is intended to drive a



Figure 2. Dimensional Drawing

loudspeaker for monitoring purposes or a distribution network to route information to several locations.

The 461A Amplifier can be used advantageously in many telephone system applications, some of which are:

Loudspeaking Telephone Systems Supervisory Monitoring Systems Audio Distribution Systems

## INSTALLATION AND OPERATION

The 461A Amplifier can be mounted in the ALTEC 12910 Mounting Panel in quantities up to a maximum of ten amplifiers, or in a 12962 Assembly if only one unit is to be mounted. The 12910 Mounting Panel occupies 1-3/4 inches of rack space on a 19-inch rack. Four 12962 Assemblies may be mounted within a type 105 Apparatus Box. A terminal strip on the 12962 Assembly indicates where the cable connections are to be made.

The 461A Amplifier should be inserted into its socket carefully to prevent possible damage to the pins of the connector plug. Withdrawal of the amplifier from the 12910 Mounting Panel should be made using the Altec 13204 Extractor Tool.

The 461A is a transistorized unit and is dependent upon the polarity of the power supply for its operation. It is strongly recommended that a functional check be made immediately after the supply is connected. This check could consist of applying +10 dBm, 1000 Hz, at the input of the unit and measuring the output. It should be approximately two watts in eight ohms.

#### MAINTENANCE

The 461A Amplifier is of the plug-in type. In the event of a malfunction, use a 13204 or 13903 Extractor Tool to remove the amplifier from the mounting panel. Use of a replacement amplifier will enable speedy restoration of service. The defective amplifier may be serviced locally or returned to the manufacturer for repair.

#### SUPPORT EQUIPMENT

| PANEL   | CAPACITY   | LOCATION  |
|---|--|---|
| 7305A<br>7316A<br>12910<br>12962<br>13227<br>14115A | 12 Amplifiers 10 Amplifiers 10 Amplifiers 1 Amplifier 1 Amplifier 2 Amplifiers | 19-inch rack 19-inch rack 19-inch rack Type 105 Apparatus Box Type 105 Apparatus Box Type 105 Apparatus Box |
| 14113/  | 2 Ampiniers  | Type 105 Apparatos box  |






Figure 3. Schematic 461A Amplifier

.

T2

Transformer (ALTEC 16613)



Figure 1. ALTEC 469A Transistor Amplifier

## SPECIFICATIONS

Frequency Response:

Distortion:

±1 dB, 200 - 6,000 Hz Below 1% THD (at +10 dBm, 200 -

6,000 Hz

Maximum Level Input:

-5.5 dB bridging 600 ohm line (at

maximum gain)

Maximum Power Output: Output Noise Level:

+17 dBm -70 dBm

Input Gain Control: Maximum Gain:

Varies from -2 dB to maximum gain

22.5 dB bridging 600 ohm line 24 - 26V dc

Operating Voltage: Input Impedance: Output Impedance:

24,000 ohms 600 ohms

Current Drain:

20 mA at 25V dc

Monitor Facilities:

11  $\pm$ 1.5 dB below amplifier output is available at test jacks on front panel when bridged by 600 ohms

Dimensions: Finish: Weight:

1-5/8" W x 1-5/8" H x 5" D Cadmium plated/dichromate finish

13 ounces

## DESCRIPTION

The 469A ALTEC Transistor Amplifier, two-stage, plug-in unit, is designed as a high input impedance bridging amplifier for use in voice frequency circuits and can be operated from 24-26 volt central office or battery supply. The input circuit of the amplifier can be connected across a voice frequency telephone circuit and introduces negligible loss.

The circuitry of the 469A Amplifier has been designed to be relatively insensitive to RF radiation from nearby relays, stepping switches, battery supply spikes, etc., in order that relatively high speed data may be passed through the amplifier without excessive signal mutilation. With the gain control set at the maximum position, the ALTEC 469A is capable of receiving an input level of 1 milliwatt without damage to the transistors.

Negative feedback is utilized to reduce distortion and to stabilize gain within 0.3 dB for a 25% reduction of supply voltage.

The output carrying capacity is adequate for a maximum +10 VU level of the transmitting toll switchboard and equipment having similar signal level. The input and output longitudinal balance is sufficiently high so that normal noise requirements are met without the use of a mid-point ground. The input winding of the transformer may be do isolated if required.



Figure 2. Dimensional Drawing

#### **APPLICATIONS**

The 469A Amplifier is used in voice communication circuits where it is necessary to bridge a transmission path for circuit distribution, interception, etc.

## INSTALLATION AND OPERATION

The 469A depends upon the polarity of the repeater station supply voltage for proper operation. Prior to inserting the amplifier, it should be determined that the positive side of the supply is at pin 9, the negative side at pin 8 (of the 11-pin socket mounted on the repeater rack). The amplifier should be inserted carefully to prevent possible damage to the pins of the 11-pin plug connector.

The gain control affords a range of approximately 40 dB. In order to adjust the gain, the lock nut on the control must be loosened. After adjustment is completed, carefully tighten the locking nut and recheck the gain setting to ascertain that the control shaft is not disturbed in the tightening operation. DC isolation of the input transformer winding is provided by capacitor C7. If a center tap ground is required, J1 pins 5 and 7 should be strapped and grounded.


## MAINTENANCE

In the event of a malfunction, the ALTEC 13204 or 13903 Extractor Tool is used to remove the amplifier from the mounting panel. A replacement amplifier may then be installed to enable rapid restoration of normal service. The defective amplifier may be serviced locally or returned to the manufacturer for repair. Should it become necessary to remove the amplifier from its protective cover, remove the two screws and plate from the rear (plug end), then withdraw the unit from the front.

## SUPPORT EQUIPMENT

The following panels are available for the amplifier, as listed:

| PANEL   | CAPACITY  | LOCATION   |
|---|---|--|
| 7305A<br>7316A<br>12910<br>12962<br>13227<br>14115A | 12 Amplifiers 10 Amplifiers 10 Amplifiers 1 Amplifier 1 Amplifier 2 Amplifier | 19" relay rack<br>19" relay rack<br>19" relay rack<br>Type 105 apparatus box or equal<br>Type 105 apparatus box or equal<br>KTU-15A type frame |
| 107 (   | - / imprimer  | it to 13/4 type frame  |



| C1<br>C2<br>C3<br>C4<br>C5<br>C6<br>C7<br>J1<br>Q1 | Capacitor, 8 mfd, 6V (Sprague 40D126A1) Capacitor, 10 mfd, 12V (Sprague 40D146A1) Capacitor, 50 mfd, 3V (Sprague 40D112A1) Capacitor, 0.2 mfd, 200V (Hopkins P22D) Capacitor, 200 mfd, 3V (Sprague 40D116A1) Capacitor, 20 mfd, 50V (Sprague 40D195A1) Capacitor, 0.1 mfd ± 5%, 300V (Hopkins P-13 MF Oreg.) Plug, 11-pin (Amphenol 86-CP-11) Transistor (G.E. 2N191) Transistor (G.E. A2N188A) | R3<br>R4<br>R5<br>R6<br>R7<br>R8<br>R9 | Resistor, $12\Omega \pm 10\%$ , $1/2W$<br>Resistor, $100K\Omega \pm 5\%$ , $1/2W$<br>Resistor, $10K\Omega \pm 5\%$ , $1/2W$<br>Resistor, $4.7K\Omega \pm 5\%$ , $1/2W$<br>Resistor, $1K\Omega \pm 5\%$ , $1/2W$<br>Resistor, $120\Omega \pm 5\%$ , $1/2W$<br>Resistor, $120\Omega \pm 5\%$ , $1/2W$<br>Resistor, $820\Omega \pm 5\%$ , $1/2W$<br>Resistor, $5.6K\Omega \pm 5\%$ , $1/2W$<br>Resistor, $12K\Omega \pm 1\%$ , $1/2W$ (Dalohm DC $1/2$ or equivalent)<br>Resistor, $82\Omega \pm 5\%$ , $1/2W$ | R12<br>R13<br>R14<br>T1<br>T2 | Resistor, $680\Omega\pm5\%$ , $1/2W$<br>Potentiometer, $2K\Omega$ , Z taper (Clarostat CM22782)<br>Resistor, $5.1K\Omega\pm5\%$ , $1/2W$<br>Resistor, $27\Omega\pm5\%$ , $1/4W$<br>Transformer (ALTEC 15325)<br>Transformer (ALTEC 16495) |
|--|---|--|---|-------------------------------|---|
|--|---|--|---|-------------------------------|---|

Figure 3. Schematic 469A Transistor Amplifier



Figure 1. 479A Repeater Amplifier

#### SPECIFICATIONS

Type: Telephone Repeater Amplifier, 600/

Frequency Response: ±1.0 dB, 200 to 6000 Hz

Below 1.0% THD at +10 dBm, 200 to Distortion: 6000 Hz

-22 dBm at maximum gain Power Input (Maximum)

Power Output: +17 dBm

Noise Level: -70 dBm

Gain: Front panel potentiometer, -2.0 dB

to 39.0 ±1.0 dB

Impedance, Input: 600 or 1200 ohms  $\pm10\%$  by "U" link

transfer

Impedance, Output 600 or 1200 ohms ±10% by "U" link

transfer

Operating Voltage: 24 or 48V dc by "U" link transfer

Current Drain: 22.0 milliamperes

Monitor Facilities: A + 600 ohms - 11.0 ±1.5 dB below

> amplifier output level at pin numbers 7 and 10 on Amphenol 11-pin connector (J1) and at front panel test jacks. At 1200 ohms - 13.0 ±1.5 dB. 100 mA

Max. Simplex Current: Max. out-of-balance Simplex Current:

5.0 mA Dimensions: 1-5/8" H x 1-5/8" W x 5" D (less

plug)

Finish: Cadmium plated with dichromate

finish

Weight: 13 ounces

Mounting: 11-pin plug connector, Amphenol

86-CP-11

## DESCRIPTION

The ALTEC 479A Telephone Repeater Amplifier is an alltransistor unit, utilizing three silicon transistors and a printed circuit for maximum uniformity of production. A minimum variation in operational characteristics is noted when the amplifier is subjected to ambient temperatures as great as  $140\,^{\circ}F$  .

The design of the ALTEC 479A Amplifier provides the following features:




Figure 2. Dimensional Drawing

- (a) Dual voltage.
- (b) Selectable input and output impedances.
- (c) Effects of pulsing transients from adjacent circuits are
- (d) Minimum gain variations at elevated temperatures of up to 140°F.

Operating voltages of the 479A Amplifier are selectable (24 to 26V or 48 to 52V dc) and is obtained by "U" link transfer through the appropriate cover cutout. (See Figures 1 and 3). The "U" link acts as a strap, connecting the B-, (pin 8), to either R10, 270 ohms, for 48 to 52 volt operation or to R11, 1500 ohms for 24 to 26 volt operation.

Input and output impedances (600 or 1200 ohms) are similarly selected by transfer of the "U" links in the appropriate cover cutout, located on the left side of the amplifier cover.

The circuitry of the 479A Amplifier has been designed to minimize RF radiation pick up from nearby relays, stepping switches, battery supply spikes, etc., in order that relatively high speed data may be passed through the amplifier without excessive signal mutilation. With the gain control set at the maximum position, the ALTEC 479A Amplifier is capable of receiving an input level of 1.0 milliwatt without damage to the transistors. Negative feedback is utilized to reduce distortion and to stabilize gain within 0.3 dB for a 25% reduction of supply voltage. When the ambient temperature increases from 70°F to 140°F, the output impedance undergoes an insignificant variation of only -1.5%.

The output carrying capacity is adequate for a maximum +10 VU level to the transmitting toll switchboard and equipment requiring a similar level. The input and output longitudinal balance is sufficiently high, enabling normal noise requirements to be met without the use of a mid-point ground.

In-and-out center taps are provided for simplex operation. The maximum simplex current is 100 mA and the maximum out-ofbalance simplex current is 5 mA.

#### **APPLICATIONS**

The ALTEC 479A Amplifier is used in voice frequency communications circuits. A telephone repeater system can be assembled



on the ALTEC 7300 through 7305 Telephone Repeater Terminating equipment using these amplifiers and additional ALTEC plug-in items of equipment.

## INSTALLATION AND OPERATION

The operation of the 479A Amplifier depends upon the polarity of the supply voltage for proper operation. Prior to inserting the amplifier, it should be determined that the positive side of the supply is at pin 9; the negative at pin 8 (of the 11-pin socket mounted on the repeater rack). The amplifier should be inserted carefully to prevent possible damage to the locating pins of the 11-pin plug connector. Removal of the 479A Amplifier is accomplished by means of the ALTEC 13204 or 13903 Extractor Tool.

The gain control affords a range of approximately 40 dB. In order to adjust the gain, the lock nut on the control must be loosened. The level at the monitor pins on the front panel, bridged by 600 ohms, is approximately 11 dB below the output level of the amplifier. After adjustment is completed, carefully tighten the locking nut and recheck the gain setting to ascertain that the control shaft is not disturbed in the tightening operation.

#### MAINTENANCE

All 479A Amplifiers are of the plug-in type. In the event of a malfunction, the ALTEC 13204 or 13903 Extractor Tool is used to remove the amplifier from the mounting panel. A replacement amplifier may then be installed, enabling rapid restoration of service. The defective amplifier may be serviced locally or returned to the manufacturer for repair. Should it become necessary to remove the amplifier from its protective cover, remove the two screws and plate from the rear (plug-end), then withdraw the unit from the front.

## MOUNTING PANELS

| PANELS CAPACITY         |   | LOCATION  |
|-------------------------|---|---|
| 7305A<br>12910<br>12962 | 12 amplifiers<br>10 amplifiers<br>1 amplifier | 19-inch relay rack<br>19-inch relay rack<br>Type 105 apparatus box or<br>equivalent |
| 13227                   | 1 amplifier                                   | Type 105 apparatus box or equivalent  |
| 14115A                  | 2 amplifiers                                  | KTU-15A type frame or equivalent  |




Figure 3. 479A Schematic Diagram

# 480A TRANSISTOR AMPLIFIER TELEPHONE REPEATER TYPE



Figure 1. 480A Repeater Amplifier

## **SPECIFICATIONS**

Type: Bridging Amplifier Frequency Response:  $\pm 1.0 \text{ dB}$ , 200 to 6000 Hz

Distortion: Below 1% THD (At +10 dBm, 200 to

6000 Hz)

Maximum Power Input: -5.5 dBm (at maximum gain) bridging

600 Ω line

Maximum Power Output: +17 dBm Output Noise Level: -70 dBm

 $\begin{array}{lll} \text{Input Gain Control:} & \text{From -2 dB to maximum gain} \\ \text{Maximum Gain:} & 22.5 \text{ dB bridging a 600 } \Omega \text{ line} \\ \text{Operating Voltage:} & 24 \text{ or } 48 \text{ V} \text{ dc (selected by moving} \end{array}$ 

screw, accessible on base of ampli-

fier case)

Input Impedance: 24,000 ohms
Output Impedance: 600 ohms

Current Drain: 20 mA (at 25 and 50V dc, when

selector screw is in proper position)
11 ±1.5 dB below amplifier out-

put is available at test jacks on

front panel when bridged by 600  $\Omega$  1-5/8" H  $\times$  1-5/8" W  $\times$  5" D (less

1-3/0 11 x 1-3/0 W X 3 D (1633

prog)

Finish: Cadmium plated with dichromate

finish

Weight: 13 ounces

#### DESCRIPTION

Dimensions:

Monitor Facilities:

The ALTEC 480A Repeater Amplifier is a solid-state bridging amplifier which utilizes three silicon transistors and a printed circuit board. Because of the amplifiers' design, ambient temperatures as great as  $140^{\circ}F$  (60°C) produce only a minimum variation in operational characteristics. Operating voltage of the 480A Amplifier is selectable (24 - 26 or 48 - 52V dc) by moving the screw, located on the base of the amplifier case, to one of the two positions indicated. The screw performs the same function as a strap by connecting the B+, (pin 9), to either the 270-ohm resistor, R10, for 24 - 26 volt operation or to the 1500-ohm resistor, R11, for 48 - 52 volt operation. Refer to the schematic drawing.

The circuitry of the 480A Amplifier has been designed to minimize RF radiation from nearby relays, stepping switches, battery supply spikes, etc. This enables relatively high speed



Figure 2. Dimensional Drawing

data to be passed through the amplifier without excessive mutilation. With the gain control set at the maximum position, the ALTEC 480A Amplifier is capable of receiving an input level of one milliwatt without damage to the transistors. Negative feedback is utilized to reduce distortion and to stabilize gain within 0.3 dB for a 25% reduction of supply voltage.

The output carrying capacity is adequate for a maximum +10 VU level of the transmitting toll switchboard or equipment having a similar signal level. The input and output longitudinal balance is sufficiently high so that normal noise requirements are met without the use of a mid-point ground.

The primary of the input transformer may be dc isolated, or alternatively, simplex signaling may be used by strapping terminals 5 and 7. Refer to the schematic drawing.

#### APPLICATIONS

The 480A Amplifier is used in voice frequency communication circuits where it is necessary to bridge a transmission path for circuit distribution monitoring, interception, etc.

## INSTALLATION AND OPERATION

The ALTEC 480A Amplifier depends upon the polarity of the repeater station supply voltage for proper operation. Prior to inserting the amplifier into the panel, it should be determined that the positive side of the supply is at pin 9 and the negative side at pin 8 (of the 11-pin socket mounted on the repeater rack). The amplifier should be inserted into the panel carefully, to prevent possible damage to the locating pin of the 11-pin connector. Removal of the 480A Amplifier from the panel is accomplished by means of the ALTEC 13204 or 13903 extractor tool.

The gain control affords a range of approximately 22.5 dB. In order to adjust the gain, the lock nut on the control must be loosened. The level at the monitor pins on the front panel, bridged by 600-ohms, is 11 dB below the output level of the amplifier. After adjustment is completed, carefully tighten the locking nut and recheck the gain setting to ascertain that the control shaft is not disturbed in the tightening operation. DC isolation of the input transformer is provided by capacitor C9. If a center tap is required, J1 pins 5 and 7, can be strapped.



## MAINTENANCE

Ω=OHMS K = 1,000 OHMS M = 1,000,000 OHMS

ALL RESISTORS 10% 1/4W UNLESS OTHERWISE SPECIFIED.

The 480A Amplifier is of the plug-in type. In the event of a malfunction, the ALTEC 13204 or 13903 Extractor Tool is used to remove the amplifier from the mounting panel. A replacement amplifier may then be installed, enabling normal service to be restored. The defective amplifier may be serviced locally or returned to the manufacturer for repair. Should it become necessary to remove the amplifier from its protective cover, remove the two screws and the plate from the rear (plug end), then withdraw the unit from the front of the panel.

## SUPPORT EQUIPMENT

The following panels are available for the amplifier:

| PANEL                             | CAPACITY   | LOCATION   |
|-----------------------------------|--|--|
| 12910<br>12962<br>13227<br>14115A | 10 Amplifiers 1 Amplifier 1 Amplifier 2 Amplifiers | 19" relay rack<br>Type 105 apparatus box or equal<br>Type 105 apparatus box or equal<br>KTU-15A frame or equal |

#### Capacitor, 5.0 mfd, 25V (Callins ASDP 5-25 Plug, 11-pin (Amphenol 86-CP-11) insulated or Sprague 404D176A1) Capacitor, 10 mfd, 12V (Callins ASDP 10-12 Q1,2,3 Transistor (2N2712) NOTES C2 Potentiameter, 1.68K $\Omega$ (ALTEC 14395-1) Resistor, 82 $\Omega$ ± 5%, 1/4W (A.B.) Resistor, Selected ± 10%, 1/4W (See schematic) I. STRAP SOCKET PINS 587 IF SIMPLEX INPUT REQUIRED insulated or Sprague 40D146AL) R2 Capacitor, 200 mfd, 25V (Callins PSS200.25 or equivalent 13-85) 2. SELECTED IN TEST. VALUE BETWEEN IOK AND 50K (R3) R4 Resistor, $15K\Omega \pm 10\%$ , 1/4W (A.B.) Resistor, $115\Omega \pm 2\%$ , Dep. Carbon AS REQUIRED TO ADJUST AMPLIFIER FOR MAX OUTPUT. Capacitor, .002 mfd $\pm$ 20%, Ceramic Disc, Z5U or Z5F 3. R6 NOMINAL VALUE IS 18 OHMS, THIS VALUE MAY BE R6 Resistor, $180 \pm 1.0\%$ , 1/4W (A.B.) Capacitor, .001 mfd $\pm$ 20%, Ceramic Disc, Z5U or Z5F SELECTED IF Q2 AND Q3 ARE HIGH GAIN TRANSISTORS Resistor, $1.6K\Omega \pm 5\%$ , 1/4W (A.B.) Resistor, $10K\Omega \pm 5\%$ , 1/4W (A.B.) Resistor, $390\Omega \pm 10\%$ , 1/4W (A.B.) Resistor, $270\Omega \pm 10\%$ , 1/4W (A.B.) WHEN VALUE SHOULD BE BETWEEN 20 AND 27 OHMS. 88 C7.8 Capacitor, .005 mfd ± 20%, Ceramic Disc, Z5U or Z5F RIO Capacitor, 0.1 mfd ± 5%, 300V (SE110W3104J or Electro-Cube Rep P1 3 MFC-703 or equiv.) Diode(1N456A per ALTEC Dwg. 8668) C9 Resistor, $1.5K\Omega \pm 5\%$ , 2W, W.W. Axial L (Sprague 240E1525 or 3W Ohmite) CR1 R12.13 Resistor, $10\Omega \pm 5\%$ , 1/4W (A.B.) 20V NOTE 3 R6 Resistor, $18K\Omega \pm 10\%$ , 1/4WTransformer (ALTEC 15357) NOTE 2 Transformer (ALTEC 16653) OUTPUT 6000 7,6V R14 ₹R8 IOK 5% IMPEDANCE 5MF 25V 02 MONITOR QI ISV 2N2712 BRIDGING INSTALL SPECIAL SCREW TO OBTAIN DESIRED VOLTAGE INPUT 24.000 a 03 5% 3W 2N2712 IMPEDANCE NOTE ! .002MF RI2 5% RI3 5% 48-52V A (AS SHIPPED) CRI IN456A C8 R9 24-26V. 390a -08 LEGEND:

Figure 3. Schematic of 480A Amplifier



# 481A EQUALIZING AMPLIFIER



Figure 1. 481A Equalizing Amplifier



Figure 2. Dimensional Drawing

## **SPECIFICATIONS**

Type: Telephone Repeater with Equali-

zation.

Gain: (No equalization)  $24.5 \text{ dB} \pm 0.5 \text{ dB}$ 

(Equalized) 28.5 dB ±0.5 dB @

3750 Hz.

Equalization: 200 Hz to 3750 Hz, 20 dB max.

l gain control variable 0-29 dB

1 equalization control variable 0-20

dB.

Frequency Response: ±1 db 200 Hz - 3000 Hz without

equalization.

Distortion: Below 1% THD 200 Hz - 4000 Hz at

+10 dBm

Maximum Power

Controls:

(Input): -7.0 dBm at maximum gain

(Output):  $+17.0 \text{ dBm } \pm 1 \text{ dBm}$ 

Noise Level: -70 dBm with input terminated into

600-ohm with maximum gain.

Operating Voltage:

24 or 48 volts by selection of screw

position.

Impedances

Current Drain:

Input & Output: 600-ohm nominal  $\pm 10\%$ , 200 Hz to

4000 Hz at maximum gain.

22.5 milliamperes ±2 milliamperes

100 mA

Max. Out-of-Balance Current: 5 mA

Monitor Facilities:

Max. Simplex Current:

11 dB (±1.5 dB) below amplifier out-

put at test jacks on front panel,

into 600-ohms

Dimensions: Finish:

Weight:

 $1-5/8" \times 1-5/8" \times 5"$  less plug Cadmium plated/dicromate finish

13 ounces

## DESCRIPTION

The ALTEC 481A Amplifier is an all-transistor item utilizing three silicon transistors on a printed circuit board giving minimum variation in operational characteristics with ambient temperatures up to 140°F. Operating voltage is selectable (24-26 or 48-52V dc) by moving a small screw to the alternate position on the amplifier base as indicated on the case, as may be seen in the above illustration and on the schematic. The screw acts as a strap connecting B+ (pin 9) to either R10 (270 ohms) for 24-26 volt operation, or to R11 (1500 ohms) for 48-52 volt operation. Equalization is achieved by a fixed LC and adjustable R network across the amplifier input stage, having the EQUALIZATION control (R14) on the front panel adjacent to the GAIN control, R1.

The circuitry of the ALTEC 481A Amplifier has been designed to minimize pick up of RF radiation from nearby relays, stepping switches and battery supply transients spikes, etc., in order that relatively high speed data may be passed through the amplifier without excessive signal mutilation. With the gain control set at maximum, the ALTEC 481A Amplifier is capable of receiving an input level of 1 milliwatt without transistor damage. Negative feedback is utilized to reduce distortion and to give gain stability at elevated temperatures.

The output power capability is adequate for a maximum of  $\pm 10$  VU level to the toll switching and other transmission equipment. Input and output center taps are furnished on the transformers for simplex operation requiring up to  $\pm 100$  milliamperes of current and with an out-of-balance current not exceeding 5 milliamperes.

## APPLICATION

The ALTEC 481A Amplifier can be used on non-loaded facilities requiring equalization, such as data or voice circuits having deviation of  $\pm 1.0$  dB, 200 to 3000 Hz. The various charts, Figure 3, give some typical facilities of 19-22-24 and 26 GA and the equalization limits obtainable in Kilo feet and  $\pm 1$  dB of deviation. The non-loaded curves indicate the facility loss NRCL in all cases and the gain with equalization as shown, as RCL.

## INSTALLATION AND OPERATION

The ALTEC 481A Amplifier is shipped with the voltage selection screw set for 48 volt operation. Before installation it may be necessary to change the voltage selection screw. Also, prior to installation of the amplifier, it should be determined that the positive of the power supply is connected to pin 9 and the negative to pin 8 of the 11 pin receptacle of the associated



Specifications and components subject to change without notice. Overall performance will be maintained or improved.




Figure 3. Typical Equalization Curves

mounting. The unit should be carefully inserted to prevent possible damage to the locating keyway on the 11 pin connector plug.

The GAIN control affords a range of approximately 25 dB and the EQL control gives equalization of approximately 20 dB. In order to make control adjustments, the lock-nuts on the potentiometers must first be loosened. Attention should be given to their re-locking when adjustments are optimized and a final check made that tightening has not disturbed the optimized settings.

## Line-Up Procedure

The length of cable or line facility that can be equalized is determined first, by the capability of the amplifier and then by the degree of deviation required. The capability of the ALTEC 481A Equalizing Amplifier is approximately 20 dB. (See Figures 3 and 4 for non-loaded facilities).

The following equipment is needed at the sending end of a circuit facility requiring equalization:

- Oscillator 19C, 21A TMS or equivalent sweep generator.
- A coordinating telephone talk circuit between the sending and the receive locations.

The following equipment is needed at the receiving end of a circuit facility requiring equalization:

- 1. A TMS or VTVM or equivalent sweep receiver as measuring equipment.
- The coordinating telephone talk circuit between the send and the receive locations.

The receive location should request over the talk coordinating telephone circuit, a level of 1 milliwatt at 3000 Hz ("0" dBm into 600-ohms), as a transmit signal into the line under test from the send location.

All tests at the receive location are to be made at the ALTEC 481A output with a VTVM terminated into 600-ohms or a sweep receiver.

## NOTE

It is assumed that a "0" loss circuit is being established between the send and receive locations. It is recognized that a -1.0 dB or some other value may be required, dependent upon the equalization and the overall gain available and also the line facility. Set the equalization control fully CW and adjust the gain control until a "0" dB signal level is read on the VTVM across the 600-ohm termination. The receive location should then request a "0" dB signal level at 1000 Hz into the line from the send location.

Since the equalizing curve has a characteristic slope, adjustments to the following curve, Figure 6, must be made for optimum response.

Due to the slope of the equalizing characteristic, the reading at 1000 Hz will always be less than the reading obtained at 3000 Hz, hence the minus (-) values given. The readjustment at 1000 Hz is the slope differential changing the equalization to the required amount. (See Figure 6).

Having arrived at the amount of equalization, it is now necessary to set the gain to the reference level required and this is accomplished by the final adjustment to the "0" dB reference level.

If sweep receiving and transmitting equipment is available, the indicated curve can visually be adjusted for optimum deviation by experiment on either the gain or the equalization control at the receive location, having first requested a sweep send from the send location into the line under test.

Having optimized the settings, the control potentiometers should be locked.




Figure 4. Equalizing Capability Control

#### **EXPLANATION OF CURVES**

Figure No. 3 indicates typical gage and lengths for  $\pm 0.25\,\text{dB}$  deviation and other curves showing the same gage and varying lengths to obtain  $\pm 1.0\,\text{dB}$  deviation.

The Non-Repeater Circuit Loss (NRCL) is shown in all cases and the Repeater Circuit Loss (RCL) is shown with equalization in all cases.

Figure No.  $4\,\mathrm{s}\,\mathrm{h}\,\mathrm{o}\,\mathrm{w}\,\mathrm{s}$  the degree of control by equalization at 0% – 50% and 100% rotation.

Figure No. 5 indicates the impedance change of the input, relative to gain and equalization minimum and maximum. Note the actual ohms reading for input is times two on the scale. The output impedance is also shown as within 10% of 600 ohms.

Figure 6 is a simplified method of obtaining the best equalizing response with a minimum of adjustment, giving the readjustment value for a certain 1000 Hz received reading. For example, a -4 dB reading at 1000 Hz would require only a 1.4 dB increase adjustment and that would give a good flat response at that




Figure 5. Impedance Curve with Maximum and Minimum Equalization

level, which now only requires gain increase to give a "0"  ${\sf dB}$  level.


#### MAINTENANCE

The ALTEC 481A Equalizing Amplifier is of the plug-in type; in the event of a malfunction, the 13204 or 13903 extractor tool is used to remove the amplifier from its socket in the mounting panel. A replacement amplifier may then be installed, enabling rapid service restoration to be made.

## SUPPORT EQUIPMENT

The following panels are available for the amplifier as listed:

| PANEL  | CAPACITY      | LOCATION                        |
|--------|---------------|---------------------------------|
| 12910  | 10 Amplifiers | 19" relay rack                  |
| 12962  | 1 Amplifier   | Type 105 Apparatus box or equal |
| 13227  | 1 Amplifier   | Type 105 Apparatus box or equal |
| 14115A | 2 Amplifiers  | Type KTU 15A type frame or      |
|        |               | equal                           |



FOR "X" RECEIVED READING @ 1000 Hz ADJUST TO "Y" VALVE OF "0" REFERENCE LEVEL

FINALLY: ADJUST GAIN TO EQUIVALENT TRANSMISSION LEVEL

Figure 6. Adjustment Curve




Figure 7. Schematic 481A Equalizing Amplifier

## 489A COMBINATION PREAMPLIFIER / POWER AMPLIFIER




Figure 1. 489A Combination Preamplifier/ Power Amplifier

#### **FUNCTION**

The function of the ALTEC 489A Combination Preamplifier/ Power Amplifier is to provide gain on voice-frequency circuits for speech or program transmission.

## **SPECIFICATIONS**

Solid-state, plug-in, voice-frequency Type:

telephone preamplifier/power amplifier combination. Class A-B operation.

600 ohms  $\pm 10\%$  or 24,000 ohms nominal Input Impedance:

Load Impedance: Not less than 4 ohms

 $\pm 1$  dB from 200 to 6000 Hz (relative to Frequency Response:

1000 Hz)

63 dB ±1 dB (600-ohm input impedance Gain:

from 600-ohm source)

47 dB  $\pm 1$  dB (24,000 ohms bridging 600-

ohm line)

Distortion: Less than 2% THD at 2W

Power Output: 2W into 4-ohm load (speech or program)

Power Input

(Maximum):

Noise Level: More than 60 dB below full 2W output

Input Return Loss (at 600 ohms):

23 dB from 200 to 6000 Hz 27 dB from 300 to 3000 Hz

30 dB from 800 to 2500 Hz

To produce 2W into 4-ohm load -Sensitivity:

-30 dBm at 600-ohm input

-14 dBm at 24,000-ohm input bridging

600-ohm line

Gain Control: Potentiometer - continuously variable

from 0 dB to 63 or 47 dB

-24 to -26V dc or -48 to -52V dc

Operating Voltage: Operating Current -Maximum (2W)

Condition: Idle Condition:

180 mA at -24V dc or 190 mA at -48V dc 5 mA at -24V dc or 16 mA at -48V dc




Figure 2. Dimensional Drawing

Up to 55° C (131° F) Temperature Range:

Amphenol 86-CP-11 plug (mates with Type of Termination:

Amphenol 78-S11 socket)

Dimensions: 1-5/8" H × 1-5/8" W × 5-1/2" D (see

Figure 2)

Finish: Cadmium plate with dichromate finish Weight:

16 ounces

Mounting Facilities: ALTEC S-19 Loudspeaking Telephone

System

ALTEC 7305 Mounting Panel ALTEC 7316A Mounting Panel ALTEC 12910 Mounting Panel ALTEC 13227 Mounting Assembly ALTEC 14115A Mounting Assembly ALTEC 42399A KTU Mounting

#### DESCRIPTION

The ALTEC 489A Combination Preamplifier/Power Amplifier is a solid-state plug-in unit. It is designed for use with voicefrequency circuits in telephone and other communications equipment where speech or program transmission is required. The amplifier can be operated from a -24 to -26V dc or -48 to -52V dc central office battery supply. It will provide two watts of output power to a four-ohm load. The current drain at full output (2W) is 180 mA with -24V dc input or 190 mA with -48V dc input. The current drain with no signal applied (idle condition) is 5 mA at -24V dc or 16 mA at -48V dc.

The circuitry of the 489A amplifier (see Figure 3) has been designed to minimize the effect of RF radiation from nearby relays, stepping switches, battery supply spikes, etc. Negative feedback is used to reduce distortion and stabilize gain. The amplifier provides a signal with low distortion — less than 2% THD across the band from 200 to 6000 Hz and can thus be used for audio distribution via splitting networks or for loudspeaking telephone systems or for other circuits where audible output is






Figure 3. Schematic, 489A ( ination Preamplifier/Power Amplifier

## APPLICATION

The 489A amplifier is used in circuits requiring up to two watts of continuous speech or program transmission power. It is capable of delivering continuous-duty tone; but because of heat dissipation problems, the unit must be derated when it is operated in ambient temperatures greater than 25° C (77° F) or when it is operated in the 48V dc mode. Maximum allowable power for continuous-duty operation can be obtained from Figure 4 or by calculation from the following equations.

(1) 24V dc operation: 
$$P = 2 - \frac{(T - 77)}{54}$$

(2) 48V dc operation: 
$$P = 1.25 - \frac{(T - 77)}{72}$$

Where: P is in watts

T is ambient temperature of intended installation area in °F.




Figure 4. Power Derating for Continuous-Duty Operation

## OPERATION AND INSTALLATION

The 489A amplifier may be installed in any ALTEC mounting facility containing an Amphenol 78-S11 socket; typical mounting facilities are specified above. The 489A amplifier depends on the polarity of the supply voltage for proper operation. Prior to installing the amplifier in its intended mounting socket, the socket should be wired in accordance with Table 1. The amplifier should then be carefully inserted to prevent possible damage to the locating key or pins of the plug and/or socket.

Table 1. Socket Wiring Connections

| Function                | Pin Connections        |  |
|-------------------------|------------------------|--|
| 600-ohm input           | 1 and 2                |  |
| 24,000-ohm input        | 2 and 5                |  |
| Output                  | 3 and 4                |  |
| Battery Positive        | 9                      |  |
| Battery Negative (-24V) | 10 (also strap 6 to 7) |  |
| Battery Negative (-48V) | 8 (also strap 7 to 10) |  |


The gain control is on the front panel and provides a range of 63 dB or 47 dB, depending on the type of application. To adjust the gain, the locknut on the control must be loosened. The output level can be monitored with a suitable meter at connector pins 3 and 4. After adjustment is completed, carefully tighten the locknut and recheck the gain setting to make certain the control shaft has not been disturbed in the tightening process.


## MAINTENANCE

To achieve restoration of service if a malfunction occurs, remove the unit from the mounting panel with an ALTEC extractor tool and install a replacement unit. A defective unit may be serviced locally but it should be returned to ALTEC for repair. To remove the unit from its protective cover, remove the two screws and plate from the rear (plug end), then withdraw the unit from the front. For factory service, contact the Order Manager — Telecommunications Products, ALTEC, 1515 South Manchester Avenue, Anaheim, California 92803 to obtain necessary ALTEC authorization documents to expedite repair and return of the unit. The unit should then be returned with the documents to ALTEC. For additional information or technical assistance, call (714) 774-2900, or TWX 910-591-1142.

#### PARTS LIST

| Reference    | Ordering        | Name and                             |
|--------------|-----------------|--------------------------------------|
| Designator   | Number          | Description                          |
|              |                 |                                      |
| C1           |                 | Cap., 0.25 µF ±5%, 100V              |
| C2,4         | 15-01-112803-01 | Cap., 160 µF, 40V                    |
| C3           | 15-01-107221-01 | Cap., 5 µF, 25V                      |
| C5           | 15-02-107046-01 | Cap., 0.002 µF ±20%, 100V            |
| C6           | 15-01-112804-01 | Cap., 470 µF, 25∨                    |
| C7           | 15-06-051234-02 | - part of the second                 |
| CR1          | 48-01-109849-01 | Diode, Zener, 25V ±5%,               |
|              |                 | 400 mW                               |
| J1           | 21-01-100748-01 | Plug, 11-pin                         |
| Q1           | 48-03-101098-01 | Transistor                           |
| Q2           | 48-03-041342-01 | Transistor                           |
| R1,2         | 47-01-102179-01 | Res., 22K $\Omega$ ±10%, 1/4W        |
| R3           | 47-01-100480-01 | Res., 820K $\Omega \pm 10\%$ , 1/4W  |
| R4,6,8,10,13 | 47-01-102181-01 | Res., 33K $\Omega \pm 10\%$ , 1/4W   |
| R5           | 47-01-102175-01 | Res., $10K \Omega \pm 10\%$ , $1/4W$ |
| R7           | 47-01-102157-01 | Res., 330 $\Omega$ ±10%, 1/4W        |
| R9           | 47-01-100479-01 | Res., 680K $\Omega \pm 10\%$ , 1/4W  |
| R11          | 47-01-100474-01 | Res., 330K $\Omega \pm 10\%$ , 1/4W  |
| R12          | 47-01-102159-01 | Res., $470 \Omega \pm 10\%$ , $1/4W$ |
| R14          | 47-01-105306-01 | Res., $22 \Omega \pm 10\%$ , $1/4W$  |
| R15          | 47-01-102330-01 | Res., $10 \Omega \pm 10\%$ , $1/2W$  |
| R16          | 47-01-102359-01 | Res., 2.2K $\Omega \pm 10\%$ , 1/2W  |
| R17          | 47-06-014395-01 | Pot., 1.68K Ω ±10%                   |
| T1           | 56-05-015417-01 | Transformer, input                   |
| T2           | 56-07-016756-01 | Transformer, output                  |
| U1           | 17-01-041633-01 | Integrated circuit                   |





2227A Transistor Amplifier

## **SPECIFICATIONS**

Normal Frequency

Response:

+0.25 dB to -0.5 dB, 300 to 10,000 Hz

+0.25 dB to -1.25 dB, 200 Hz relative

to 1000 Hz

-11.5 dB at 50 Hz relative to 1000 Hz

Extended Frequency Response (By "U"

Link Transfer):

 $\pm 1.0$  dB at 70 to 10,000 Hz

-3.0 dB at 50 Hz relative to 1000 Hz

Distortion:

Less than 2.0% THD, 70 to 6000 Hz at

+10 dBm and below

Less than 1.0% THD, 200 to 6000 Hz

at +15 dBm

Power

Maximum Output:

+19 dBm at 1000 Hz

Input:

-17 dBm at maximum gain at 1000 Hz

Maximum Gain

at 1000 Hz:

 $35 dB \pm 1 dB$  (Normal Frequency Response)

36 dB ±1 dB (Extended Frequency Re-

sponse)

Minimum Gain:

0 dB to -2.0 dB

Operating Voltage (By "U" Link

Transfer):

24 or 48V do

Operating Current:

18 milliamperes dc ±2 millampere

Impedance, Input:

600 or 1200 ohms

Impedance, Output:

600 or 1200 ohms

(Wiring options on mounting receptacle)

Noise Level:

-65 dB at maximum gain (600 ohm input

termination)

Monitor:

Output bridging test jacks on front panel

Simplex:

100 milliamperes maximum with 5 milliamperes maximum out-of-balance

Mounting:

15-pin (male

connector)

To mate with customer furnished 15-pin

receptacle (Amphenol 126-150 or

Continental 14525L5)

Dimensions:

 $1-21/32" \times 1-23/32" \times 6-15/16"$  overall


Finish:

Cadmium plate with iridite overcoat

Weight:

16 ounces





**Dimensional Drawing** 

#### DESCRIPTION

The ALTEC 2227A Amplifier, designed as a substitute or equivalent item having mechanical and electrical compatibility with the 227 type Amplifier, utilizes a similar 15-pin connector for the circuit functions.

The design of the ALTEC 2227A Amplifier provides the following features:

- (a) Dual voltage.
- (b) Normal or extended low frequency response.
- (c) Protective devices to guard against high voltages.
- (d) The effects of pulsing transients are minimized.
- (e) Minimizes gain variations at elevated temperatures of up to 150°F.
- (f) Has a single gain control.

The option for the Normal/Extended LF response is obtained by "U" link transfer through the appropriate cut-out in the cover. The option for operating voltage selection of either 24 or 48 Volt operation, is similarily obtained by "U" link transfer through the appropriate cover cut-out.

The amplifier circuit incorporates three silicon type transistors and employs negative feedback to reduce distortion and to stabilize gain within 0.15 dB of change for a 25% reduction in supply voltage. With the gain control set at maximum, the ALTEC 2227A Amplifier is capable of receiving an input level of one (1) milliwatt without transistor damage.

The power output is adequate for a maximum of a  $\pm 10$  VU level to the toll or other switching equipment for transmission purposes. An ambient temperature increase from normal up to  $150^{\circ}$ F changes the output impedance less than 1.5%.

Center taps are furnished on input and output transformers for a maximum simplex current of 100 milliamperes, with a permis-

sible five milliampere out-of-balance current. The input and output transformer longitudinal balance is sufficiently high that normal noise requirements can be met without the use of a midpoint ground.

The frequency response feature which permits normal or extended operation, gives optional use for ordinary VF transmission or, with a minimum of circuit changing, for digitized speech voice coding use requiring the improved VF response.

## AMPLIFIER CONSTRUCTION

The ALTEC 2227A Amplifier consists of eight printed circuit boards or wafers, four support rods, a front panel, interconnecting bus leads, rear connectors, and a cover. Seven of the eight wafers are positioned by the four cover support rods and the eighth is part of the rear connector plate assembly, which, with the front panel, locates the rods.

The separate printed circuit wafer assemblies are interconnected with bare tinned copper wire of #20 gage which is soldered at each wafer, to circuit requirements. The soldering of the bus leads imparts rigidity to the assembly, making a unit of rugged construction, not easily damaged.

The inner assembly of wafers, rods and bus leads slides into the cover and is secured by two screws at the connector end of the unit.

Slots are furnished in the cover to give access for the changing of the operating voltage, or the changing of the low frequency response. This is accomplished by moving a "U" link to an alternate position. The cover is suitably engraved to indicate which slot gives access for voltage and/or frequency response change.

The cover has front extension tabs which permit removal of the amplifier from its mounting socket with the aid of an extractor tool.

## **APPLICATION**

The ALTEC 2227A Amplifier can be used with any 227 type Amplifier mounting, having a 15-pin receptacle. It is completely compatible as regards equalization, gain, operating voltages, input and output impedances with existing 227 type Amplifiers and has only a single potentiometer for gain adjustment.

The amplifier may be used where a relatively flat frequency response is required, as in data transmission, or alternatively, in VF speech transmission where low frequency attenuation may be desirable.

Because of the good battery isolation and noise rejection factor, the amplifier may be applied with advantage in locations where dialing transients from adjacent circuits may give rise to cross-talk effects via the rack common power source.

## INSTALLATION

The ALTEC 2227A Amplifier is a transistorized unit and is dependent upon the polarity of the power supply for its operation. Prior to installation, a check should be made to determine that the positive polarity is present on pins 7 and 15 and that negative polarity is present on pin 14 of the mounting shelf.

The 2227A Amplifier should be inserted into its socket carefully to prevent damage to the pins of the plug connector.

## MAINTENANCE

The 2227A Amplifier is of the plug-in type. In the event of a malfunction, an extractor tool should be used to remove the unit from the mounting and a replacement amplifier inserted. The defective amplifier may be serviced locally or returned to the manufacturer for repair.

#### **PARTS LIST**

| Reference      | Name and   |
|----------------|--|
| Designator     | Description  |
|                |  |
| Cl             | Capacitor, 0.6 µF, 100V, 5% (SEI 1294)                             |
| C2             | Capacitor, 3 µF, 25V (Callins 1.85 ASD 325 with                    |
| <u> </u>       | sleeving or equivalent)  |
| C3             | Capacitor, 0.008 µF, 300V (Hopkins PO 0083                         |
| CO             | pF or equivalent)  |
| C4,5,6         | Capacitor, 5 pF 25V (Callins 1.85 ASD 5.25 with                    |
| C4,5,0         | sleeving or equivalent)  |
| C7             | Capacitor, .002 Ceramic Disc ±20%, Z5U or 25F                      |
| C8,9           | Capacitor, .001 Ceramic Disc ±20%, Z5U or 25F                      |
| Acceptance for | Capacitor, .005 Ceramic Disc ±20%, Z5U or 25F                      |
| C10<br>C11     | Connector, 200 Cerumic Disc ±20%, 250 or 25r                       |
| CII            | Capacitor, 200 µF, 25V (Callins 13.85 PSS 200.25                   |
| C12            | or equivalent)   |
| C12            | Capacitor, 100 µF, 3V (Callins 4.85 ASD 100.3                      |
| CD1            | with sleeving or equivalent)                                       |
| CR1            | Diode (1N456)  |
| CR2            | Diode (Diodes Inc., 52S)   |
| CR3,4          | Diode, Zener 13V, 10% (LPM13 or D12488)                            |
| Jl<br>J        | Plug, (Continental KS 14524-L9)                                    |
| J2,3           | Socket, 3-pin (Cinch 203/91/03/029)                                |
| Q1             | Transistor (2N4062 TI)   |
| Q2,3           | Transistor (Motorola MPS 6519)                                     |
| R2             | Resistor, 562 $\Omega$ , 1%, 1/8W Ohmite .312 x .093)              |
| R3             | Potentiometer, 1.68K $\Omega$ , $\pm 2\%$ "Z" Taper, PC            |
|                | leads, 3/8" Split Locking Bushing, 1/16" Slotted                   |
|                | Shaft (Clarostat Series 63M)                                       |
| R4             | Resistor, $732 \Omega$ , 1% 1/8W (RN60D)                           |
| R5             | Resistor, 8.2K Ω, 5%, 1/4W   |
| R6             | Resistor, 12K $\Omega$ , 5%, $1/4W$                                |
| R7             | Resistor, 33K Ω, 5%, 1/4W  |
| R8             | Resistor, 31.6 Ω, 1%, 1/4W (RN60D)                                 |
| R9             | Resistor, 270 $\Omega$ , 5%, $1/2W$                                |
| R10            | Resistor, 1.2K Ω, 5%, 3W   |
| RII            | Resistor, 1210 Ω, 1%, 1/8W (RN60D)                                 |
| R12            | Resistor, 15K $\Omega$ , 1%, 1/8W (RN60D)                          |
| R13            | Resistor, 120 Ω, 5%, 1/4W  |
| R14            | Resistor, 61.9 Ω, 1%, 1/4W (RN60D)                                 |
| R15            | Resistor, 2.4K Ω, 5%, 1/4W   |
| R16,18         | Resistor, 22.1 $\Omega$ , 1%, 1/4W (RN60D)                         |
| R17            | Resistor, $30 \Omega$ , $5\%$ , $1/4W$ (Ohmite $.25 \times .090$ ) |
| R19,20         | Resistor, $180 \Omega$ , 5%, $1/4W$ (Ohmite .25 x .90)             |
| R21            | Resistor, 15K Ω, 5%, 1/4W  |
| 11             | Transformer (ALTEC 4821)   |
| T2             | Transformer (ALTEC 16697)  |
|                |  |

