



Railway Train Dispatching Telephone Systems

Western Electric
Products

Copyright, 1934
Western Electric Company, Incorporated



Western Electric Railway Train Dispatching Telephone Systems

A development of Bell Telephone Laboratories, Incorporated, The Rescarch Laboratories of the American Telephone & Telegraph Company and the Western Electric Company



No. 60AP Selector

INTRODUCTION

RAILWAY Train Dispatching Telephone Equipment has proved indispensable as a quick and reliable means of communication between the dispatcher and the various way station operators of a Train Dispatching System. The dispatcher can call selectively any one of a number of way stations on the same telephone line without producing a signal at any of the other stations.

The apparatus used in this equipment is the result of years of research and has back of it over half a century of telephone manufacturing experience. This equipment represents the highest standards of design, engineering and workmanship. Its efficiency and reliability has been proved under the most severe operating conditions.

General Description

ODERN railroads are separated into divisions for the purpose of efficient dispatching. A division may be from 30 to 150 miles in length for busy multiple track roads or from 100 to 300 miles for single track roads where the daily traffic is light. On each division there is a dispatcher who has control of all train movements on his division. There may be from 15 to 75 stations or signal towers with which the dispatcher will want to communicate. The dispatcher has a train sheet in front of him on which he keeps a record of the time of arrival and departure or passing at each station of all trains whether passenger, freight or extra. Also the train sheet shows the engine number, the make up of the train, and the names of the crew. Whenever there is any change from the regular schedule, it is necessary for him to issue a train order to the nearest station agents or signal men which in turn is given to the trainmen. The usual method of giving a train order by telephone is as follows: The dispatcher, as he gives the order over the telephone to the operator at the distant station, writes the order in a log book and at the same time the way station operator writes the order on duplicate forms for handing to the conductor and the engineer. As a check, the operator always reads the order back over the telephone to the dispatcher who underlines each word in the log book to indicate he has received the order back as originally given. Often the order is taken by three or more operators at the same time; if so, each reads it back in turn and the dispatcher underlines his original order each time. In giving an order, all important words and numbers are both pronounced and spelled out.

Although a train dispatching system is nothing more than a long and heavily loaded selective party line, there were many new problems that had to be considered that are not met with in the commercial telephone systems. It is necessary to operate a selective device at each of the twenty-five, fifty or seventy-five way stations over a pair of wires up to 300 miles in length without interfering in any way with the telephone transmission. Of course, each installation differs from every other one as to number of way stations and length of line. To function under these varying conditions the selector must operate on very little energy but on the other hand to warrant its use for this class of service the selector must be very positive and reliable in its operation. If the line wires become open at any point, the dispatcher must be able to call stations up to the open point even under the most severe weather conditions.

The most modern selector, the Western Electric No. 60 type, is the standard on all rail-roads in the United States and is used in nearly all countries of Europe and in Japan, China, India, Africa, Australia, Canada and South American countries. This selector is a polarized device somewhat similar in magnetic structure to a ringer and so arranged that the armature on each plus and minus impulse advances a ratchet wheel one step. Although very sensitive, the selector is rugged and will withstand rough handling.

CHAPTER I LAYOUT OF SYSTEM

A Railway Train Dispatching Telephone System consists of a Dispatcher's (sending) station and a number of Way or (receiving) stations.

The dispatcher's station is equipped with telephone apparatus for receiving and transmitting messages. This consists essentially of an apparatus case containing the various parts required for protection and operation and a key equipment for signalling each way station on the circuit.

Each way station is equipped with telephone apparatus for receiving and transmitting messages, and also a selector set for signalling and for receiving time signals.

For circuit arrangement of a Railway Train Dispatching Telephone System see pages 58 and 59.

Dispatcher's Station Equipment

The following selector and telephone apparatus is recommended for the dispatcher's station. The selection of the proper equipment depends upon the total number of way stations to be installed and also the type of station selector sets and whether telephone apparatus with or without loud speaking telephone is required.

DISPATCHER'S SELECTOR APPARATUS

Qu

Quantity

uantity	Apparatus
One-	No. 60B Selector Apparatus Case.
	No. 61A Selector Key (17 Unit Code) or
	No. 61B Selector Key (27 Unit Code) or
One-	No. 62A or No. 63A Selector Key (17 Unit Code) or
	No. 62B or No. 63B Selector Key (27 Unit Code) or
One—	The state of the s
	No. 60B Selector Key Case (capacity 36 stations) or
	No. 60C Selector Key Case (capacity 48 stations) or
	No. 60D Selector Key Case (capacity 60 stations) or
	No. 60E Selector Key Case (capacity 12 stations).
One—	of the way stations.
One-	No. 60B Selector Key installed in above key case for each No. 60BP Selector installed at the way stations.
MOURITA	WI - COT - C. I

NOTE: Where 60 Type Selector Keys are used, a 60B Selector Key is also required for each way station extension bell installed.

DISPATCHER'S TELEPHONE APPARATUS—HEADSET OUTFIT

Quantity	Apparatus
	No. 502A Subscriber Set.
One-	No. 345A Jack Box.
Three-	-Each of the following:
	No. 386 Transmitters equipped with No. 3A Transmitter Attachments.
	No. 189 Receivers.
	No. 565, 5' 6" Cords equipped with No. 137 Plugs.
One-	No. 1B Foot Switch with
One-	No. 1A or No. 1B Foot Switch Attachment and
One-	No. 2A Foot Switch Attachment (Conduit).

Apparatus

DISPATCHER'S TELEPHONE APPARATUS—LOUD SPEAKING

In addition to the telephone apparatus outlined in preceding paragraphs with the exception of the No. 1B Foot Switch, the following loud speaking telephone apparatus is recommended.

	No. 12A Loud Speaking Telephone Outfit. No. 3B Foot Switch.			
	AC CURRENT SUPPLY			
One—	No. 6052A Amplifier (for 60 cycle, 110 volt) or, No. 6040A Amplifier (for 25 cycle, 110 volt).	One-	No. 34G Resistance.	
One-	No. 579A Loud Speaking Telephone.		No. 3B Foot Switch.	

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS Layout of System

Dispatcher's Station Equipment

(Continued)

DISPATCHER'S TIME SENDING APPARATUS

One- No. 60A Time Sending Set.

DISPATCHER'S BATTERY REQUIREMENTS

One— No. 60B Vacuum Tube Rectifier, or Dry Cells, or Storage Cells, or Motor-Generator Set, as required for main battery source.

Dry Cells for Local Relay Battery, 12 or 24 volts.

No. 2B Battery Box for above dry cells.

Transmitter Battery Requirements—4 to 5 volts.

DISPATCHER'S HAND GENERATOR BOX

One— No. 299F Hand Generator Box (for use in calling magneto portable or siding sets).

Way Station Equipment

The following Selector and Telephone Apparatus is recommended for each way station. The selection of the proper equipment depends upon whether the selectors are to be used for regular line circuits or to be operated through a repeating coil or transformer with or without extension sets; also, whether Loud Speaking Telephones are required.

WAY STATION SELECTOR APPARATUS

Quantity Apparatus

No. 160C Selector Set for use without repeating coil or transformer, or, No. 160R Selector Set for use with repeating coil or transformer. No. 60AP Selector for use where extension bells are not required. One-

One—No. 60BP Selector for use where two- to four-party way station extension bells are required.
One—No. 127J Extension Bell for each way station extension, and when using the No. 60BP Selector.

WAY STATION TELEPHONE APPARATUS (Without Loud Speaking Telephones)

No. 501A Desk Set Box (sub-set—equipped with key) or, No. 501B Desk Set Box (sub-set—arranged for foot switch). One-

One— No. 1142AB Desk Set Box (sub-set—arranged for foot switch).

No. 1120C Transmitter Arm, or,
No. 1148DA, DB, DC or DD Transmitter Arm, as required.

One— No. 3C Foot Switch with (for No. 501B Desk Set Box).

One— No. 1A or B Foot Switch Attachment, and
One— No. 2A Foot Switch Attachment (Conduit).

WAY STATION TELEPHONE APPARATUS (With Loud Speaking Telephones)

One-

No. 501B Desk Set Box (sub-set).

No. 1142AB Desk Stand or 1148 Type Transmitter Arm.

No. 6052A Amplifier (60 cycles, 110 volt) or,

No. 6040A Amplifier (25 cycles, 110 volt)!

No. 579A Loud Speaking Telephone.

No. 147AC Transmitter Arm.

One-

One— No. 3D Foot Switch with
One— No. 1A or B Foot Switch Attachment, and
One— No. 2A Foot Switch Attachment.

WAY STATION EXTENSION BELL

One— No. 127J Extension Bell, for each way station extension.

WAY STATION BATTERY REQUIREMENTS

Three—Dry Cells.
One— No. 1A Battery Box (for three dry cells).

WAY STATION PROTECTORS

As required—No. 58BP Protectors.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS Layout of System

Miscellaneous Equipment

Apparatus for miscellaneous purposes on Railway Train Dispatching Systems is described more fully in the following pages. The most important of this type of equipment is as follows:

REPEATING COIL AND TRANSFORMER

Circuits equipped with 60 Type Selectors may be operated through 341A Transformers or 70A Repeating Coils. The advantages are as follows:

 To obtain a low resistance in the simplex telegraph leg.
 To operate two or more simplex selector circuits with a common battery supply.
 To operate one or more branch selector circuits from the main selector circuit without any metallic connection to it.

4. To allow two selector circuits to be used as side circuits for obtaining a composited or simplexed phantom with the physical and phantom telephone and the telegraph circuits terminated at the same or different points. The circuit on page 26 shows a general way of obtaining these conditions.

SIDING TELEPHONE SETS

Quantity Apparatus

No. 1293BC Telephone set or, No. 1317BU or DU Telephone Set or, No. 1336F or H Telephone Set.


PORTABLE TELEPHONE SETS

One— No. 1330E or F Telephone Set or, No. 1331E or F Telephone Set or, No. 1332A or E Telephone Set. One— No. 3 or 5 Line Pole.

TESTING APPARATUS

One- No. 60B Test Set.

Schematic Wiring of No. 60B Selector Apparatus Case



RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS CHAPTER II


DESCRIPTION, ADJUSTMENTS AND OPERATION OF SETS

GENERAL SEQUENCE OF OPERATIONS

The sending circuit arrangement is shown on page 6.

The sequence of operation of the various parts of the system when a call is made is as follows: A selector key operated by the dispatcher causes three groups of impulses to be sent over the line in such a manner that only the selector at the station called will be advanced to its ringing position. (Refer to page 6 for the sending circuit and page 16 for the receiving circuit.) On operating the selector key, contact K1 (B4)-K3 is closed continuously and the No. 221JB Relay is operated, connecting the main battery through the contacts of the No. 26A Relay and the two No. 152A Retardation Coils to the line wires L1 and L2; also, the key contact K1 (B4)-K2 is closed intermittently, operating the pole-changer relay (No. 26A) to send a sequence of reverse impulses to the line. This sequence of impulses, while operating all selectors on the line, will advance only the code wheel of the selector at the station called so as to close its local bell circuit. The bell at that station will ring for about two seconds, then another impulse from the calling key will release the selector and open the bell circuit. While the bell is ringing a tone or answer-back will be heard in the receiver notifying the dispatcher that the signal is operating.

Dispatcher's Selector Equipment



No. 60B Selector Apparatus Case - Open

1-No. 2B Circuit Breaker

1-No. 221JB Relay.

1-No. 141A Condenser.

1-No. 629A Mounting Plate.

4—No. 63C Resistances.

60B SELECTOR APPARATUS CASE

This case contains all the calling apparatus at the Dispatcher's Station except the selector keys in ordinary installations. It is a metal cabinet approximately 18" high by 16" wide by 6½" deep arranged for wall mounting. It is completely wired and provided with terminals for connecting the battery lines and selector keys as shown on page 6.

 Λ short description of the apparatus contained in it follows:

1-No. 26A Telegraph Relay.

2-No. 152A Retardation Coils.

4-No. 138B Condensers.

1-No. 138A Condenser.

1-No. 63F Resistance.

The No. 2B Circuit Breaker is to open the main current supply lead if an excessive amount of current flows from the main battery, such as is caused by a short on the line or in any part of the sending circuit. The resistance of the circuit breaker is 2 ohms and it is normally adjusted to operate on 0.6 ampere and to non-operate on 0.4 ampere. These values can be increased or decreased by adjusting the air gap between the armature and the magnet by means of a knurled nut at the extreme end of the magnet. The circuit breaker when operated closes a local contact C1-C2. Any local alarm circuit can be connected as desired to terminals C1-C2.

The No. 221JB Relay is to connect the sending circuit to the line at the beginning of the operation of the selector key, and to disconnect the sending circuit again at the end of the operation of the selector key. This relay remains operated during the whole operation of the selector key. This relay has a normally closed contact that may be used for connecting an extension bell across the line as indicated on page 6. The resistance of the relay is 335 ohms and it should receive from .024 to .036 ampere of current for operation.


The No. 26A Telegraph Relay (pole changer) is to reverse the polarity of the main battery so that each succeeding impulse sent over the line is in the opposite direction to the preceding one. The resistance of the relay is 25 ohms. It should receive from 0.32 to 0.48 ampere of current for operation.

The No. 152A Retardation Coils and the No. 138B (1¼ mf) Condensers are to smooth out the impulses of the current used for operating the selectors while calling, so as not to cause an objectionably sharp click in the receiver, but merely a dull thump that is not objectionable and does not interfere with the telephone transmission. The resistance of these coils is 20 ohms each, or a total of 40 ohms for the two coils. The No. 138A and No. 141A Condensers with resistances are for spark "take-up."

Dispatcher's Selector Equipment (Continued)

The No. 58BP Protectors which are furnished with this apparatus case should be used to protect the inside apparatus against damage from high voltages by providing a shunt path from each side of the line through an air gap between the blocks to a ground connection. The spacing between the blocks of the protector is such that a breakdown will occur on an average of 700 volts, thus a low impedance path is provided to lead the high voltages off to ground rather than through the calling or telephone apparatus.

Selector Kevs



No. 60A Selector Key



No. 61A Selector Key

GENERAL

The function of the selector key is to control the operation of the stick relay (No. 221JB) and the pole-changer relay (No. 26A), so that the necessary sequence of current impulses to operate the selector at the station desired will be transmitted to the main line wires, see page 6.

There are three types of keys that may be used, (1) the 60 type selector key requiring an individual key for each selector, (2) the 61 type selector key provided with lever arms for setting the code as required when making a call, and (3) the 62 and 63 type selector keys provided with small button keys for setting the code as required when making a call.

No. 60 TYPE SELECTOR KEYS

The 60 type are individual keys having a clock spring operating an impulse wheel through a train of

The 60 type are individual keys having a clock spring operating an impulse wheel through a train of gears, with the speed controlled by a governor.

The keys are mounted in oak cases (page 94) coded Nos. 60A, B, C, D and E Selector Key Cases for mounting 24, 36, 48, 60 or 12 No. 60A or 60B Selector Keys or No. 50A Selector Key Space, respectively.

The No. 60 Type Selector Keys mount in the No. 60 Type Selector Key Case and can easily be removed with a screw driver by turning the screw under the handle counter clockwise. The keys, when mounted, make contact with the springs in the back of the key case. When a key is operated by turning the handle one-quarter turn and then releasing, it should return automatically to its normal position. The speed at which it returns can be increased or decreased by bending in or out the springs which carry the weights of the regulating governor. the regulating governor.

No. 60A SELECTOR KEY

The No. 60A Selector Key is for use with the No. 60AP Selector when set for the code numbers given in Table No. 1 (page 10). It may be set for any of the code numbers given in Table No. 1 by adjusting its segments as described in detail hereafter. In this series of settings the total number of current impulses for any code is seventeen. The governor springs for the No. 60A Selector Key is so adjusted that the impulse wheel will make one revolution in not less than $7\frac{1}{2}$ seconds and not more than 8 seconds.

No. 60B SELECTOR KEY

The No. 60B Selector Key is for use with the No. 60AP Selector when set for the code numbers in Table No. 2 (page 10), and with the No. 60BP Selector when set for the code numbers given in Table No. 1 for the No. 60BP Selector. It may be set for any of the code numbers given in Table No. 2 or 1, by the adjustment of its segments in a manner similar to that explained in detail for the No. 60A Selector Key, with the exception that the total number of impulses is increased by 10 for the 27 step code settings of the No. 60AP Selector and that a flat segment is used to reduce the total number of impulses to 17, 19, 21 or 23 for the A, B, C and D contacts for the 17 step No. 60BP Selector. The governor springs for the No. 60B Selector Key are so adjusted that the impulse wheel will make one revolution in not less than 9 seconds and not more than 948 seconds. more than 91/2 seconds.

Selector Keys (Continued)

METHOD OF SETTING CODES FOR No. 60 TYPE KEYS

In setting the segments on the impulse wheel of the key, each closure and each opening of the contacts count one. Two styles of segments are provided, one a flat segment which closes the contacts while the inner spring passes over it; the other segment with a bent-up part which engages with the insulated piece on the outer spring, raising this spring sufficiently to keep the contacts open while the outer spring passes over.

Each key requires two segments to give the three sets of impulses. If the first number in the code is odd, a flat segment is required, while a segment with the bent-up part is required if the first number is even. If the last number in the code is even, a flat segment is required, while a segment with the bent-up part is required if the last number is odd. Thus two like segments or one of each kind may be required to give the code setting. The first segment is set so that the inner contact spring, in passing over the first set of teeth on the impulse wheel gives the number of closures and openings of the contacts represented by the first number in the code. The other segment is set so that the contact springs, in passing over the third set of teeth on the impulse wheel, give the number of closures and openings of the contacts as represented by the last number in the code. Since the total number of impulses for any three digit code combination is always the same in the same table, it follows that if the first and the last numbers are set the middle one will be automatically determined.

For example, to set the No. 60A Selector Key for selecting station 8-5-4, begin at the first tooth and count 8 (first number in code) in a clockwise direction, counting one for each tooth and one for each space, in this case 4 teeth and 4 spaces. As the last count was a space, take a segment with the bent-up part and place it so as to keep the contact in the same position while passing over the segment, as on the last count. This segment is set approximately flush with the edge of the next tooth, so that the outside contact spring will be off this segment before the inner contact spring strikes the next tooth.

To set the other segment, begin at the ringing position and count 4 (last number in code) in a counter-clockwise direction, counting one for each space and one for each tooth, in this case two spaces and two teeth. As the last count was on a tooth, set the edge of a flat segment on the center of this tooth. The number of closures and openings of the contact while the inner contact spring passes between the two segments, is the middle number in the code (5 in this case).

METHOD OF SETTING No. 60 TYPE KEYS FOR TIME SENDING

To set the No. 60A Selector Key so that all No. 60AP Selectors will be advanced to their time receiving position, place a flat segment bridging from the center of the first tooth to the center of the fourth tooth. This gives, after the first long impulse, 22 regular impulses in succession.

The No. 60B Selector Key is set in a similar manner except the total number of impulses is 27 for the station codes, Table No. 2, page 10, and 32 total impulses for time sending.

No. 61A SELECTOR KEY

The No. 61A Selector Key is for use as a master key at test boards and switchboards; also at way stations on intercalling circuits. It may be set for any of the code numbers given in Table No. 1 for all selectors set for the 17 step code by moving the levers, extending through the cover, to the code desired. As in the case of the No. 60 Type Keys, the middle number of the code is automatically determined by setting the first and the third numbers.

The first lever on the left side is used only with the No. 60BP Selector and normally is placed for station "A" and should be left in this position when used in connection with the No. 60AP Selectors. When used with the No. 60BP Selectors it should be moved to the B, C and D position, corresponding with the code of the station desired.

To make a call, the second lever is placed opposite the first number of the code of the selector desired. The third lever is placed opposite the last number of the code of the selector desired. The right lever is then moved down to the bottom of its slot and released. The key then operates to give the same sequence of impulses as the No. 60A Key.

The No. 61A Selector Key may be set to call all stations on the line equipped with No. 60AP Selectors (17 step) and all stations connected to the "A" contact of the No. 60BP Selectors (17 step by setting the second and third levers each on zero. The key then sends out 17 consecutive impulses to step all selectors to the first ringing contact.

The No. 61A Selector key makes one complete operation in 7½ to 8 seconds. The speed is changed by bending the governor springs, at the right end, in to increase and out to decrease the speed.

Three terminals on the bottom, designated K1, K2 and K3, connect to the corresponding terminals in the No. 60B Selector Apparatus Case shown on page 6.

No. 61B SELECTOR KEY

The No. 61B Selector Key is similar to the No. 61A Selector Key except it is arranged for the code numbers given in Table No. 2 (page 10) for selectors set for the 27 step code. The key makes one complete operation in 9 to $9\frac{1}{2}$ seconds.

CODE SETTINGS FOR SELECTORS

TABLE No. 1

Total Steps in Each Code-17.

Total code settings for the No. 60AP Selector-78.

Code settings for the No. 60BP Selector with No. 60AP Selectors on the same line are marked with a star—28.

Additional code settings for the No. 60BP Selector with no No. 60AP Selectors on the same line are marked with a dot—18.

2-2-13 2-3-12 2-4-11 2-5-10 2-6-9 2-7-8 2-8-7 2-9-6 2-10-5 2-11-4 2-12-3 2-13-2	3-2-12 3-3-11 3-4-10 3-5-9 3-6-8 3-7-7 3-8-6 3-9-5 3-10-4 3-11-3 3-12-2	4-2-11 4-3-10 4-4-9 4-5-8 4-6-7 4-7-6 4-8-5 4-9-4 4-10-3 4-11-2	.5-2-10 .5-3-9 .5-4-8 .5-5-7 .5-6-6 .5-7-5 .5-8-4 .5-9-3 .5-10-2	6-2-9 6-3-8 6-4-7 6-5-6 6-6-5 6-7-4 6-8-3 6-9-2	*7-2-8 *7-3-7 *7-4-6 *7-5-5 *7-6-4 *7-7-3 *7-8-2	*8-2-7 *8-3-6 *8-4-6 *8-5-4 *8-6-3 *8-7-2	*9-2-6 *9-3-5 *9-4-4 *9-5-3 *9-6-2
*10-2-5 *10-3-4 *10-4-3 *10-5-2		*11-2-4 *11-3-3 *11-4-2		*12-2-3 *12-3-2		*13-2-2	

TABLE No. 2

Total Steps in Each Code-27.

Total Code settings for the No. 60AP Selector-241.


Code settings for the No. 60BP Selector with No. 60AP Selectors on the same line are marked with a star—147. Additional settings for the No. 60BP Selector with no No. 60AP Selectors on the same line are marked with a dot—38.

2-5-20 2-6-19 2-7-18 2-8-17 2-9-16 2-10-15 2-11-14 2-12-13 2-13-12 2-14-11 2-15-10 2-16-9 2-17-8 2-18-7 2-19-6 2-20-5 2-21-4 2-22-3 2-23-2	.3-4-20 .3-5-19 .3-6-18 .3-7-17 .3-8-16 .3-9-15 .3-10-14 .3-11-13 .3-12-12 .3-13-11 .3-14-10 .3-15-9 .3-16-8 .3-17-7 .3-18-6 .3-19-5 .3-20-4 .3-21-2 .3-22-2	4-3-20 4-4-19 4-5-18 4-6-17 4-7-16 4-8-15 4-9-14 4-10-13 4-11-12 4-12-11 4-13-10 4-14-9 4-15-8 4-16-7 4-17-6 4-18-5 4-19-4 4-20-3 4-21-2	.5-2-20 .5-3-19 .5-4-18 .5-5-17 .5-6-16 .5-7-15 .5-8-14 .5-9-13 .5-10-12 .5-11-11 .5-12-10 .5-13-9 .5-14-8 .5-15-7 .5-16-6 .5-17-5 .5-18-4 .5-19-3 .5-20-2	6-2-19 6-3-18 6-4-17 6-5-16 6-6-15 6-7-14 6-8-13 6-9-12 6-10-11 6-11-10 6-12-9 6-13-9 6-14-7 6-15-6 6-16-5 6-17-4 6-18-3 6-19-2	*7-2-18 *7-3-17 *7-4-16 *7-5-15 *7-6-14 *7-7-13 *7-8-12 *7-9-11 *7-11-9 *7-11-9 *7-12-8 *7-13-7 *7-14-6 *7-15-5 *7-16-4 *7-17-3 *7-18-2	*8-2-17 *8-3-16 *8-4-15 *8-5-14 *8-6-13 *8-7-12 *8-8-11 *8-9-10 *8-10-9 *8-11-8 *8-12-7 *8-13-6 *8-14-5 *8-16-3 *8-17-2
*9-2-16 *9-3-15 *9-4-14 *9-5-13 *9-6-12 *9-7-11 *9-8-10 *9-10-8 *9-11-7 *9-12-6 *9-13-5 *9-15-3 *9-16-2	*10-2-15 *10-3-14 *10-4-13 *10-5-12 *10-6-11 *10-7-10 *10-8-9 *10-9-8 *10-10-7 *10-11-6 *10-12-5 *10-14-3 *10-14-3	*11-2-14 *11-3-13 *11-4-12 *11-5-11 *11-6-10 *11-7-9 *11-8-8 *11-10-6 *11-11-5 *11-12-4 *11-13-3 *11-14-2	*12-2-13 *12-3-12 *12-4-11 *12-5-10 *12-6-9 *12-7-8 *12-8-7 *12-9-6 *12-10-5 *12-11-4 *12-12-3	*(3-2-12 *13-3-11 *13-4-10 *13-5-9 *13-6-8 *13-7-7 *13-8-6 *13-9-5 *13-10-4 *18-11-3	*14-2-11 *14-3-10 *14-4-9 *14-5-8 *14-6-7 *14-7-6 *14-8-5 *14-10-3 *14-11-2	*15-2-10 *15-3-9 *15-4-8 *15-5-7 *15-6-6 *15-7-5 *15-8-4 *15-9-3
*16-2-9 *16-3-8 *16-4-7 *16-5-6 *16-6-5 *16-6-3 *16-8-3 *16-9-2	*17-2-8 *17-3-7 *17-4-6 *17-5-5 *17-6-4 *17-7-3 *17-8-2	*18-2-7 *18-3-6 *18-4-5 *18-5-4 *18-6-3 *18-7-2	*19-2-6 *19-3-5 *19-4-4 *19-5-3 *19-6-2	*20-2-5 *20-3-4 *20-4-3 *20-5-2		

Selector Keys (Continued)



No. 62A Selector Key



No. 63B Selector Key

Nos. 62 AND 63 TYPE SELECTOR KEYS

These selector keys are master calling keys arranged to operate any or all selectors on a line to their ringing position by pushing one small locking key in each of the two groups of keys.

Γhe Nos. 62A and 62B Selector Keys are arranged for desk or table mounting, and the main apparatus unit is arranged so that it can be removed from its base by means of a jack connection (see page 12). The overall dimensions are approximately 12½" high, 10½" wide, 6½" deep. The metal frame and cover are finished in black.

The Nos. 63A and 63B Selector Keys are arranged for mounting in the face equipment of a 604 PBX switchboard between the stiles $(10\frac{1}{4})''$ face mounting) and are arranged so that they may be removed from the face equipment of the switchboard either from the front or rear. The metal frame and cover are finished in aluminum. The overall dimensions of the keys are approximately $10\frac{5}{8}''$ high, $9\frac{3}{4}''$ wide, $6\frac{1}{4}''$ deep.

The Nos. 62A and 63A Selector Keys provide means for calling all selectors in the 17 step selector code as given in Table No. 1, page 10. These keys have two groups of 14 keys each and one group of 7 keys.

The Nos. 62B and 63B Selector Keys provide means for calling all selectors in the 27 step selector code as given in Table No. 2, page 10. These keys have two groups of 21 keys each and one group of 7 keys.

Operation


The operating principle is the same for each type and capacity. With the manually operated selector keys, a separate key is used to call each selector. With the new key unit, it is possible to call every selector within the capacity of the unit by depressing combinations of push keys in the face of the key cabinet. The process of calling any given selector consists of depressing a button in the top (red) group of push keys corresponding to the first number in the desired code, and a second push key in the middle (white) group corresponding to the last number in the selector code. Upon depressing the second push key, circuits are set up which cause a motor-driven brush to sweep around a series of segments arranged in a circle. Page 12 shows this mechanism clearly. The operation of the push keys further establishes connections to certain segments so that as the brush revolves the correct sequence of impulses is sent out for operating the selector whose code number is being called. whose code number is being called.

A small lamp located behind the square space in the lower center of the designation card remains lighted while the key is in operation.

The black keys designated A, B, C and D in the bottom row of both capacities of the key unit make it possible to produce selective ringing at the called selector. In other words, by depressing one of the four "letter" keys in question, the called selector will ring independently one of four annunciator bells local to the selector.

A schematic diagram of the smaller capacity key is shown on page 13.

Selector Keys (Continued)



No. 62A Selector Key-Rear View, cover removed

Drive

Each selector key also has a distributor panel with a telechron motor driving a brush arm, carrying a brush which wipes over a commutator consisting of 70 small segments. On the front of this panel a designation card is provided for listing the keys to be operated to make the selector call for each station.


110-120 volts, 50-60 cycles is required for the operation of the Telechron motor used in these selector keys. This current is connected directly to the terminals in the base of the Nos. 62A and 62B Selector Keys, and through a No. 335B Transformer for the Nos. 63A and 63B Selector Keys, the Nos. 63A and 63B Selector Keys, the No. 335B Transformer must be ordered separately and is used to step down the voltage to 24 volts so as not to require special insulation in the wiring for the keys in the PBX switchboard. The selector keys are arranged to use either 12 or 24 volts D.C. for the local operation of the relays and lamp. When a 24 volt battery is used, the strap shunting the 45 ohm resistor must be removed.

Features and Advantages

- 1. All selectors may be set for receiving time signals by depressing key No. 1 in the first (red) group and key No. 1 in the second (white) group.


 2. All selectors may be operated for a master call by depressing key No. 0 in the first (red) group and
- key No. 0 in the second (white) group.
- 3. Selectors may be called in groups by depressing corresponding keys in the first and second groups of keys
- 4. Since the keys used for calling are of the locking type, the last keys operated indicate the last call
- If it is desired to repeat the call of any given selector, it may be accomplished by depressing the black key "S."
- 6. Should the operator for any reason wish to prolong the ringing of the bell at a station, this can be accomplished by holding the "L" and "R" keys in the operated position as soon as the "answer back" tone is heard.
- 7. If, after a call is started, it is desired to break it up, this may be done by pushing the "R" key which will prevent the impulses from going out.
- 8. The new selector key unit is extremely flexible in that only one unit is necessary to call any number of selectors within the capacity of the unit. When, in the course of time, additional selectors, within the capacity of the unit, are added to the system they are handled by the original key without any changes or additions.
- The new selector key is interchangeable with the present Western Electric Nos. 60 and 61 Type Selector Keys and may be connected in multiple by connecting like terminals together, or may be substituted entirely for them.
- 10. One dispatcher, from a given position using a single key unit, may operate two or more systems during light load since the same key need simply be switched from one system to another as desired.
- Uniformity of impulse sending is insured by the use of a synchronous motor sweeping a brush arm over uniformly spaced contact segments.
 The key is entirely self contained, all relays and other mechanism being mounted compactly within
- its housing.

Selector Keys (Continued)



Schematic of No. 62A or 63A Selector Key

No. 60A Time Sending Set



Schematic of No. 60A Time Sending Set



No. 60A Time Sending Set

No. 60A TIME SENDING SET

In addition to the operation of selecting a station as described for the No. 60AP selector, the selector is provided with a second or time ringing terminal for receiving time. For this purpose a time sending set is used with the No. 60B Selector Apparatus Case for sending the time signals over selector circuits. The set consists of a No. 149AN and an R1971 Relay, a switch, and four No. 63C Resistances mounted in a black finished steel case approximately $6\frac{1}{4}$ " x $6\frac{1}{4}$ " x $6\frac{1}{4}$ ".

finished steel case approximately 6¼" x 6¼".

For normal operation of the circuit, the time switch is operated to the "calling position". When it is desired to send time signals, a Selector Key set to send 22 consecutive impulses for the 17 step code or 32 impulses for the 27 step code is operated. This steps all the code wheels of the No. 60AP Selectors on the circuit up to the time receiving position (code wheel contact within one step of closing the second or time contact) where it is retained by an insulated "time arm". The time switch is then operated to the "time position". This completes the circuit between terminals K1 and K3 and connects K2 to the pulsing contact of the R1971 Relay. Closing circuit to terminals K1 and K3 operates the No. 221JB Relay which connects the main battery to the line. Then as a time-repeating relay in the telegraph circuit operates and completes the circuit between terminals T1 and T2, the R1971 Relay will operate and on the opening of the T1-T2 Circuit, the No. 149AN Relay will operate. On the second closure of the T1-T2 Circuit, the R1971 Relay will release and on the second opening of the T1-T2 Circuit the No. 149AN Relay will release.

Thus on the first closure of the T1-T2 Circuit the No. 26A Relay in the selector apparatus case will be

Thus on the first closure of the T1-T2 Circuit the No. 26A Relay in the selector apparatus case will be operated by the closure of the pulsing contact of the R1971 Relay and send out a positive pulse on the line to advance all the No. 60AP Selectors one step. This momentarily closes the time contacts on all selectors and causes all bells to tap. The selectors on the line then fall back to a position within one step of closing the time contact and are held there as before by the "time arm" engaging with the holding spring.

Then as the time-repeating relay operates a second time to close the T1-T2 Circuit the pulsing contact of the R1971 Relay will be opened and release the No. 26A Relay to send out an impulse of the opposite polarity over the line, operating all the No. 60AP Selectors and causing all bells to tap as before. This series of operations is repeated for each two operations of the time-repeating relay, thus causing the bell to tap once each time the time-repeating relay operates.

The No. 149AN Relay is sufficiently slow release to prevent the time sending set from pulsing fast enough to cause the No. 60AP Selectors on the line to step off the "time arm" if the time sending set is connected to the time-repeating relay when telegraph impulses are being sent.

After the time signals have been sent, the time switch is operated to the selector calling position. The selectors on the line are then stepped off the "time arm" by the sending of four impulses or the operation of any selector key. The circuit is then in condition for regular calling.

The time sending set functions on the local battery of either 12 or 24 volts. The "time arm" of the No. 60AP Selector is insulated from the bell circuit to open the answer-back circuit and thus prevent the tone from interfering with telephone conversation while time signals are being sent.

Dispatcher's Telephone Equipment









No. 345A Jack Box

No. 502A SUBSCRIBER SET

The No. 502A Subscriber Set is a high efficiency set, designed with an anti-side tone feature arranged so that the dispatcher is at all times insulated from the line.

As the dispatcher wears his receiver continuously, his battery circuit is closed a large portion of the time. With the anti-side tone feature, the dispatcher's voice and other noises in the dispatcher's office are kept out of his receiver.

The two induction coils in the set insulate the dispatcher's telephone equipment from the line. These coils have a break-down test of approximately 1000 volts AC.

The arrangement of the condensers keeps down the thumps from signalling impulses, thus protecting the dispatcher's ears.


No. 345A JACK BOX

The No. 345A Jack Box permits the use of two operators' telephone sets in parallel.

Way Station Selector Equipment







No. 60BP Selector

SELECTOR SETS

No. 160C Selector Set. No. 160R Selector Set.

The No. 160C Selector Set replaces the Nos. 160AC and 160BC Selector Sets, and the No. 160R Selector Set replaces the Nos. 160AR and 160BR Selector Sets formerly furnished.

The sets are arranged to hold the selector and are completely wired and provided with terminals for connecting the line and local battery wires, as shown on page 16, for the No. 160C Selector Set when equipped with a No. 60AP Selector, and the 160R Selector Set when equipped with a No. 60BP Selector.

The Nos. 160C and 160R Selector Sets do not include the No. 60AP or No. 60BP Selector as part of the equipment. The selector desired must be ordered separately.


No. 160C SELECTOR SET

The No. 160C Selector Set is for use on standard circuits where condensers are required in series with the No. 60AP or No. 60BP Selector.

No. 160R SELECTOR SET

The No. 160R Selector Set is for use in a repeating coil circuit where no condenser is required in series with the selector. This set is the same as the No. 160C Selector Set except that the No. 138B Condenser is omitted.

Way Station Selector Equipment (Continued)



No. 60CG RINGER

The function of the No. 60CG Ringer which is a part of the above selector sets is to signal the way station operator and also to give the time signals. This ringer is a vibrating direct current type, operating from the transmitter battery and is provided with contact springs for opening its own circuit intermittently. The resistance of each ringer spool is 8 ohms and the ringer is adjusted to operate on the same battery as the telephone equipment.

60 TYPE SELECTORS

General

The function of the selector is to provide a quick and reliable means to call selectively one of a large number of way stations on the same telephone line without producing a signal at the other stations.

The D.C. resistance of the 60 Type Selector is 21,000 ohms. The selector may be operated in series with a 1½ or 1½ mf condenser or through a No. 341A Transformer or No. 70A Repeating Coil without a condenser. The impedance of the selector and condenser at the operating frequency of 3½ cycles is approximately 35,000 ohms. The impedance of the selector at talking frequency, 800 cycles per second, is approximately 2 megohms. Thus the loss in telephone transmission due to the selector bridge on the line is negligible.

No. 60AP SELECTOR (Not included with selector sets)

The No. 60AP Selector, shown on page 15, is of the step-by-step type and is operated by a definite code or sequence of alternating or reverse current impulses. It consists of a mechanism unit mounted on a magnet unit with a bakelite base and a glass cover.

The code wheels are set so that the same total number of steps is necessary to advance the code wheel to the ringing position on all selectors that are to be used on the same line. With the number of holes provided in the code wheel, this number of total steps may be any number from 8 to 32, which number would give a total of 6 to 378 code settings, respectively. The No. 60AP Selector, however, is normally set for a total of 17 steps which number gives a total of 78 code settings. Unless selectors are ordered for some other code setting than those given in Table No. 1, page 10, the selector is not stepped up by 17 consecutive impulses when selecting a station but by 3 sets of successive impulses totalling 17 in number as indicated in Table No. 1. (This number of impulses, 17, does not count the restoring impulse.)

The code pins on each selector are located so that after the first set of impulses the code wheel will be in position for the holding spring to engage with the first code pin. The second code pin is located so that after the second set of impulses the code wheel will be in position for the holding spring to engage with the second code pin. The third set of impulses then advances the code wheel so that the permanent code pin is in position to engage with the holding spring and at the same time the contact spring is directly over and makes contact with the first ringing terminal thus completing the bell circuit. Each selector is capable of being set for any station number given in Table No. 1, page 10, without any change other than the location of the two code pins in the code wheel.

In order to take care of cases where a greater number of code settings are required than those given in Table No. 1, the code settings for a No. 60AP Selector for 27 total steps in each code are given in Table No. 2, page 10, which gives a total of 241 code settings.

Way Station Selector Equipment (Continued)

No. 60BP SELECTOR (Not included with selector sets)

The No. 60BP Selector, page 15, is known as the multiple contact selector and differs from the No. 60AP Selector in that it is equipped with four selector ringing terminals instead of one so that any one of four local signal circuits can be closed by the same selector independently. Also, the selector is not equipped with a terminal for receiving time signals.

The method of setting the code numbers and the method of operation are the same as described for the No. 60AP Selector.

The terminals on the No. 60BP Selector are known by the letters Λ , B, C and D. Terminal Λ is the first terminal engaged by the contact spring on the code wheel as the code wheel is advanced. The last group of impulses in the code setting for selecting the first or Λ contact, is increased by two impulses to select the B contact, four impulses to select the C contact, and six impulses to select the D contact. The numbers marked on the code card on the selector indicate the code setting for the Λ contact. For example, a selector having a code setting of 8-5-4 for the first contact will be marked 8-5-4 and the contacts will be known as 8-5-4 Λ , 8-5-4 B, 8-5-4 C and 8-5-4 D.



No. 127J Extension Bell



No. 160 Type Selector Set



No. 501A Type Desk Set Box Cover Removed

No. 127J EXTENSION BELL

This bell is used as an extension signal in connection with the No. 60BP Selector. The No. 60CG Ringer in the No. 160C or R Selector Set in which the No. 60BP Selector is mounted, gives a signal for the first or A ringing terminal. One of these extension bells is required for each signal desired in addition to the one in the selector set.

The No. 127J Extension Bell consists of a No. 60CG Ringer and a condenser mounted in an oak box. These sets are arranged to be connected directly to the terminals in the No. 160C or R Selector Sct as follows:

Terminal L2 of the extension bell to be connected to terminal L2 in the selector set. Terminal B2 of the extension bell to be connected to terminal B2 in the selector set. Terminal S of the extension bell to be connected to terminal 3 or 4 or 5 on the base of the 60BP Selector as desired. These connections are shown on a circuit label furnished with the selector set and shown on page 16.

Way Station Telephone Equipment

No. 501 TYPE DESK SET BOXES

The Nos. 501A and B Desk Set Boxes are high efficiency sets designed for use on lines where a large number of sets are required. The secondary of the induction coil, in series with the condenser is permanently bridged across the line, so that the characteristics of the line do not materially change whether one or all of the stations are listening in at the same time. This also insulates the operator from the line as the telephone equipment is connected to the primary of the induction coil. The induction coil has a breakdown of approximately 1000 volts A.C. between the windings.

When the switch of the desk set box is closed to the transmitting position, the receiver is not cut out entirely, but is left across part of the coil so that the dispatcher can, in case of error, break in on an operator repeating an order.

In the No. 501Λ Set, the key for switching from listening to talking position is included in the box. The No. 501B Set is the same as the No. 501Λ , except that the key is omitted, the wiring being brought to terminals in the set so that a foot switch or separate key can be used.


Way Station Equipment (Continued)

Protection of Way Station Equipment

The function of the protector is to protect the inside apparatus against damage from high voltages by providing a shunt path from each side of the line through an air gap between the blocks to a well established ground connection. It is important that this ground connection be well and permanently made. A fuse in each side of the line is also provided to guard the drop wires against abnormal currents. Seven ampere fuses are generally used.

The No. 58BP Protector connected between the 60B Selector Apparatus Case and the line wires consist of

- 1-No. 29B Protector Mounting-for Blocks
- 1-No. 16 Protector Mounting-for Fuses
- 1-No. 48 Protector Mounting-Asbestos Pad
- 2-No. 11C Fuses-7 ampere
- 2 No. 26 Protector Blocks-Hard Carbon
- 2-No. 30 Protector Blocks-Porcelain with earbon insert




No. 58BP Protector

The spacing between the blocks is such that a break down will occur on an average of 700 volts. Thus a low impedance path is provided to lead the high voltages off to ground rather than through the calling or telephone apparatus. Damage to the apparatus is thereby avoided.

The fuses should always be connected on the line side and the blocks on the station side.

Loud Speaking Telephone Equipment



Schematic of Dispatcher's Loud Speaking Telephone Equipment

Dispatcher and Way Station

The loud speaking telephone amplifier is for use in Dispatcher's office, signal towers, and way stations to supplement the usual telephone outfit. It is designed to amplify the incoming conversation, so that the loud speaking telephone connected to it will produce sufficient volume to be heard at a distance of several feet, thus relieving the dispatcher or operator of the necessity of wearing a head set. The equipment is divided into two classes, that which is for use in dispatchers' offices and that which is for use at signal towers and way stations.

Loud Speaking Telephone Equipment (Continued)

DISPATCHER'S EQUIPMENT

The following loud speaking telephone equipment may be used in the Dispatcher's Office:

D.C. CURRENT SUPPLY

-No. 12A Loud Speaking Telephone Outfit -No. 345A Jack Box

No. 3B Foot Switch

A.C. CURRENT SUPPLY

1—No. 6052A Amplifier (for 60 cycle, 110 volt) or, No. 6040A Amplifier (for 25 cycle, 110 volt).
1—No. 579A Loud Speaking Telephone.
1—No. 147AC Transmitter Arm.

No. 34G Resistance.

-2


No. 3B Foot Switch. No. 6017B Key

No. 345A Jack Box.

WAY STATION **EQUIPMENT**

The following loud speaking telephone equip-ment may be used in Way Stations:

- -No. 6052A Amplifier (60 cycles, 110 volt) or, No. 6040A Amplifier (25 cycles, 110 volt).
- 1—No. 579A Loud Speak-ing Telephone.
- -No. 147AC Transmitter Arm.
- 1-No. 3D Foot Switch with
- 1-No. 1A or B Foot Switch Attachment, and
- 1-No. 2A Foot Switch Attachment.



Schematic of Way Station Loud Speaking Telephone Equipment

No. 12A LOUD SPEAKING TELEPHONE OUTFIT

The No. 12A Loud Speaking Telephone outfit consists of a No. 519A Subscribers Set, a No. 216A Vacuum Tube, and a No. 543W Loud Speaking Telephone. This Outfit is designed for use at Dispatchers' Stations and is operated on a direct current power supply.

Note: A No. 579 Loud Speaking Telephone or a KS-6368 Horn with a No. 549 Receiver may be used in place of the No. 543W Receiver in this outfit.



No. 6040A Amplifier No. 6052A Amplifier

No. 6052A AMPLIFIER

The No. 6052A Amplifier consists of a No. 52A Amplifier and two No. 205D Vacuum Tubes and may be used at either dispatcher or way stations. It is a single stage audio frequency amplifier with a self-contained current supply set operating from 110 volts 60 cycle AC supply. The power consumption is approximately 40 watts. No batteries are required for its operation.

Dispatcher & Way Station Equipment (Continued)

The apparatus is contained in a rectangular metal box approximately 11'' long, 9^{13} /6'' wide and 9^{3} /6'' high and is provided with a carrying handle. A cord switch and plug are provided for connecting to the 110volt 60 cycle AC supply.

The amplification given by this amplifier is, in general, sufficient to give satisfactory loud speaking tele-phone operation where good volume is obtained from the head set and where the line and external noises are not excessive.

The input impedance of the amplifier is such that a relatively large number of amplifiers may be counected across the telephone line without introducing excessive losses which might interfere with conversa-tions carried on between stations at extreme ends of the line. Also, in view of the possible use of the line for selector operation, the input impedance of the amplifier has been so arranged that it will not offer any considerable shunting effect to the selector currents.

When working from an impedance of 900 ohms, the gain of the amplifier is approximately 25 db at

which working from an impedance of 300 ohms.

The amplifier is designed for connecting across a telephone line where it will remain in operation at all times. When the operator desires to talk, the loud speaker may be made partially inoperative by means of a foot switch arranged to short circuit the output of the amplifier. The loud speaker and the foot switch are not a part of this amplifier.

The typical connection diagrams for this amplifier are shown on pages 18 and 19.

No. 6040A AMPLIFIER

The No. 6040A Amplifier used for train dispatching operates on 110 volt 25 cycle AC power supply circuits. It is otherwise the same electrically as the No. 6052A and may also be used at either dispatcher or way stations. It uses two No. 205D Vacuum Tubes as does the No. 6052A and is enclosed in a brown japan finished metal box about $11\frac{1}{2}$ " x 10" x $9\frac{1}{4}$ ".

No. 579A LOUD SPEAKING TELEPHONE

The No. 579A Loud Speaking Telephone consists of a No. 570A Loud Speaking Telephone mounted in a black finished cone shaped metal case approximately 10" in diameter and 4½" thick. It has a grilled front backed by a wire screen. Illustration page 18.

It is intended to mount on a No. 147AC Transmitter Arm and is arranged to take any cord equipped

with No. 80 Cord Tips.

No. 543W LOUD SPEAKING TELEPHONE

The No. 543W Loud Speaking Telephone consists of a brass base similar to a desk stand base, equipped

with a black finished fibre horn 20%" high.

The base is equipped with a felt cushion covering on the bottom, a hole is provided in the base for adjustment of the receiver unit. The No. 545 Receiver and the No. 762 Cord form parts of this loud speaking telephone.

No. 3B AND No. 3D FOOT SWITCHES

The No. 3B Foot Switch at the dispatcher's station and the No. 3D Foot Switch at the way station, are for use in disconnecting the transmitter from the line, and also changes the value of the shunting resistance across the output of the amplifier, as described below. The switch must be depressed to talk and released to receive, although at the dispatcher's station reception for "break in" purposes at a reduced volume may be had while the switch is depressed.

No. 34G RESISTANCE

The No. 34G Resistance at the dispatcher's station is for use in providing an adjustment for the loud speaker volume.

The connections to the No. 34G Resistance at the dispatcher's station are shown on page 18. The connections at "1" and "2" should be determined in the following manner:

With the power supply turned on, and the No. 6017B Key depressed, any talk on the line should be

with the power supply turned on, and the No. 6017B Key depressed, any talk on the line should be heard in the loud speaker, the volume of which can now be adjusted to a satisfactory level by placing connection No. 1 on a suitable tap. The proper tap will generally be one of the last two or three or it may be that the full output of the amplifier is required, in which case this connection may be left off altogether. The proper tap for connection No. 2 should be chosen with the foot switch depressed and a distant operator talking. This connection determines the loud speaker "break in" level and also is intended to prevent howling, which is caused by feed back from the loud speaker into the transmitter. This howling ordinarily occurs when the transmitter is in circuit unless the loud speaker volume is held below a certain critical value. The value of resistance which gives a satisfactory "break in" efficiency will usually be less than that required to prevent howling. required to prevent howling.

No. 6017B KEY

The No. 6017B Key at the dispatcher's station is used for switching from the loud speaking telephone to the head set telephone and vice versa.


Battery Requirements

The current supply for this system consists of a main DC battery of 150 to 400 volts and a local battery of 12 or 24 volts at the dispatchers' stations and a 4 volt battery at each way station.

The main battery furnishes the current for operating the selectors at the way stations. The voltage required depends on the loop resistance of the line wires and the location and number of selector sets on the required depends on the loop resistance of the line wires and the location and number of selector sets on the line. For standard circuits using No. 160 type Selector Sets with condensers in the sets, the voltage required for normal operation can be determined from the voltage line selector curves shown on page 21, figure 1. For transformer or repeating coil circuits the voltage required for normal operation can be determined from the curves shown on page 22, figures 2 or 3. These curves show the voltage required for different length lines of No. 9 B. & S. copper wires—8.3 ohms per loop mile—equipped with selector sets uniformly distributed. The voltage specified for normal operation is higher than the minimum operating voltage required. This insures the operation of the selectors when the line insulation is low during wet weather and allows for a slight decrease in the potential for any reason. The potential should in no case be allowed to decrease more than 15%. decrease more than 15%.

Dry cells, storage cells, a motor-generator set, or a Western Electric No. 60B Vacuum Tube Rectifier may be used for this main current source. When dry cells are used, frequent measurements should be made to determine the potential of the battery when the current is flowing under operating conditions. This is necessary because the gradual increase in internal resistance of the dry cells will lower the voltage available for operating the selectors.

No. 60B VACUUM TUBE RECTIFIER



The No. 60B Vacuum Tube Rectifier is operated from a 110 volt, 60 cycle, alternating current source and may be used instead of dry cells, storage cells, or a motor-generator set, to furnish the main power for operating one or two selector circuits. It does away with the periodic tests of dry cells, the charging of storage cells or the continuous large power drain of the motor-generator sets.

The Rectifier consists of a fuse-and-switch block, No. 72A Repeating Coil, No. F-11 Relay, eleven No. 138B Condensers, Vacuum Tube Socket for mounting the Western Electric No. 214E Vacuum Tube, and a terminal block mounted in a black finished sheet steel box 18" high, 12" wide and 6½" deep. It weighs approximately 60 pounds.


The 110 volt, 60 cycle, alternating current is connected through the switch block and the fuse (6 amperes) to the primary of the repeating coil shown below. The secondary of Open View the repeating coil is provided with taps (terminals S1-S6) for supplying alternating current of 60 to 540 volts potential in 60 volt steps to the plate circuit of the vacuum tube. To obtain these values the two flexible leads (black

and green) to the No. 72A Repeating Coils should be connected to the following terminals:

S1 and S2 for 60 volts SI and S4 for 300 volts S2 and S3 for 120 volts S2 and S5 for 360 volts SI and S3 for 180 volts S1 and S5 for 420 volts S2 and S4 for 240 volts S2 and S6 for 480 volts S1 and S6 for 540 volts


The steps permit of adjusting the DC output of the rectifier to the needs of the circuit as determined from the voltage-line selector curves shown elsewhere in this catalog. The direct current voltage output of the set equals the alternating current input to the tube with a small load on terminals B1 and B2 and decreases from 10 to 35 per cent in proportion with a larger selector load. Under maximum load conditions, 200 direct current output is approximately 0.300 ampere at 400 volts potential.

The tertiary winding of the repeating coil supplies current at 10 volts potential for lighting the vacuum tube filament, through the contacts of the F-11 Relay. The condensers tend to hold up the voltage of the rectified current during the interval between the rectified half-waves.



Schematic Diagram of No. 60B Vacuum Tube Rectifier

Western Electric



VOLTAGE LINE SELECTOR CURVES

Fig. 1
Voltage-Line Selector Curves
for No. 160 Type Selector Set




Fig. 2
Curves for No. 160 Type Selector Sets
Operated through a No. 341A Transformer




Fig. 3

Voltage-Line Selector Curves for No. 160
Type Selector Sets Operated through
No. 70A Repeating Coils

Vacuum Tube Rectifier—Battery Requirements (Continued)

The terminal block has five terminals for outside connection as follows: B1, B2 and B3 to be connected to B1, B2, B3 of one or two No. 60B Selector Apparatus Cases. One K3 to be connected to the K3 terminal of one No. 60B Selector Apparatus Case and a second K3 to be connected to the K3 terminal of the second No. 60B Selector Apparatus Case when used.

When using the No. 60B Rectifier as the line battery supply, and operating the selectors through a transformer the No. 221JB Relay in the No. 60B Selector Apparatus Case is not required and its line contacts should be closed permanently. Also the lead to terminal K3 in the No. 60B Selector Apparatus Case should not be connected. This allows the condensers in the rectifier to become discharged at the end of a call and thus prevent the possibility of two preliminary pulses through the selectors on the next call.

The filament of the vacuum tube lights only when the No. F-11 Relay is energized as a selector key is operated to make a call. The filament circuit is closed a second before calling impulses are sent out. This allows the filament to heat sufficiently to rectify a full potential impulse at the start. The average life of the No. 214E Vacuum Tube based on 200 to 300 calls per day, is approximately two years but this figure is not guaranteed. This life is with a filament current of 3.2 amperes. If the current is increased the life of the tube is shortened.

The set rectifies only when the filament of the tube is lighted. This decreases the drain on the alternating current source and lengthens the life of the tube. The drain during non-calling periods when the filament circuit is open is 8 watts and on the average selector circuit the drain is approximately 90 watts while calling. At the rate of 300 calls per day (8 seconds per call) the rectifier would require 250 watt-hours per day.

The No. F-11 Relay in the filament circuit is provided with two windings so that it may be operated by the selector keys of two selector circuits separately or at the same time.

LOCAL BATTERY

The local battery at the dispatcher's station furnishes current for operating the No. 26A and No. 221JB Relays. Dry cells or sufficient storage cells to give a voltage of 12 or 24 volts should be used. In no case should the voltage of this battery be allowed to decrease to less than 8 volts.

WAY STATION BATTERY

The way station battery furnishes current for operating the No. 60CG Ringer. It may consist of primary or secondary cells. The voltage of this battery should be from 3 to 5 volts. The transmitter battery of the way station telephone sets may be used as a common battery for the telephone transmitter and for the ringer of one or two selector sets.

Operation of Selector Circuits through Transformers and Repeating Coils



No. 70A Repeating Coil




No. 341A Transformer


In many cases it is of advantage to operate train and message circuits with No. 60 type Selectors through transformers or repeating coils to:

- (1) Obtain a low resistance in the simplex telegraph leg.
- (2) Operate two or more simplexed selector circuits from the common battery supply.
- (3) Operate one or more branch selector circuits from the main selector circuit without any metallic connection to it.
- (4) Allow two selector circuits to be used as side circuits for obtaining a composited or simplexed phantom with the physical and phantom telephone and the telegraph circuits terminated at the same or different points.

Operation of Selector Circuits Through Transformers and Repeating Coils (Continued)



Schematic of the Selector Circuit Operated through No. 341A Transformer



Schematic of the Selector Circuit Operated through Two No. 70A Repeating Coils in Series Aiding

No. 341A TRANSFORMER

The No. 341A Transformer has a shell type silicon steel core clamped between angle iron brackets which also provide a mounting for the transformer and for the terminal connecting block. The transformer is approximately 6'' long x $5\frac{5}{6}''$ wide x $5\frac{3}{4}''$ deep, and weighs approximately 20 pounds. It has four windings brought out to separate terminals. The primary windings (1-2 and 5-6) each have a resistance of approximately 90 ohms and the two secondary windings each have a resistance of approximately 175 ohms. The primary windings and the secondary windings are each balanced from a resistance, inductance and capacity standpoint to within 200 crosstalk units to permit the coil to be used on simplexed telephone circuits arranged for duplex telegraph without interference from the telegraph on the side or phantom telephone circuits.

The transformer is especially designed for repeating the low frequency $(3\frac{1}{2})$ cycles) selector impulses for long lines with a large number of selectors. The impedance at 900 cycles of the two secondary windings connected in series aiding is approximately 6,000 ohms, and of the two primary windings in series aiding is approximately 12,000 ohms. The loss of bridging the transformer on a line as a simplex bridge is, therefore, very small.

The loss in telephone transmission due to inserting a No. 341A Transformer in the center of a long line of No. 9 B. & S. gauge non-loaded open copper wire is approximately 5 decibels.

No. 70A REPEATING COIL

The No. 70A Repeating Coil is a toroidal type coil mounted on a wood base. The complete coil is approximately $8\frac{1}{2}$ " wide x 11" deep x 5" high, and weighs approximately 26 pounds.

The coil has four windings brought out to separate terminals. The two secondary windings (3-4 and 7-8) each have a resistance of approximately 40 ohms, and the two primary windings (1-2 and 5-6) each have a resistance of approximately 45 ohms. The primary windings and the secondary windings are balanced from a resistance, inductance and capacity standpoint to within 200 crosstalk units to permit the coil to be used on simplexed telephone circuits arranged for duplex telegraph without interference from the telegraph.

The No. 70A Repeating Coil is also designed for repeating the low frequency (3½ cycles) selector impulses and for telephone transmission frequencies. The loss in telephone transmission due to inserting a No. 70A Repeating Coil in the center of a long line of No. 9 B. & S. gauge non-loaded open copper wire is approximately 1¼ decibels. The impedance at 900 cycles of either the two primary or the two secondary windings of the coil connected in series aiding is approximately 8000 ohms. The loss due to bridging the coil on the telephone line as a simplex bridge is, therefore, very small.

TRANSFORMER AT DISPATCHER'S STATION

When the entire selector circuit is to be operated through a transformer, the No. 341A Transformer should be used and the connections should be as shown above. The telephone set should be connected to the line side of the transformer.

If it is desirable to talk through the transformer at the dispatcher's station and keep the transmission loss to a minimum, the No. 70A Repeating Coil may be used, connected as shown above.

Operation of Selector Circuits Through Transformers and Repeating Coils (Continued)

The capacity of the condenser shown at "C" in each case should be not less than 10 mf plus 1 mf for each selector on the circuit. A resistance of 2000 ohms (Ward-Leonard DM-2000) should be connected in parallel with the condensers to prevent oscillatory discharges of the condensers from interfering with the operation of the selectors.


When a No. 60B Rectifier is used as the battery supply with the circuit connections shown on page 24, the contacts of the 221JB Relay in the No. 60B Selector Apparatus Case should be closed permanently and the lead to terminal K3 not connected. This allows the condensers in the rectifier set to become discharged at the end of a call and thus prevent two preliminary pulses through the selectors on the next call.


A No. 160B Condenser has been especially designed for use for the condenser at "C".

The No. 160B Condenser is a black metal box approximately $7\frac{1}{2}$ " long x 6" wide x 5" deep, equipped with 16 No. 138B Condensers connected in parallel giving a normal capacity of 20 mf. As many of these condenser units connected in parallel should be used as required to give the total capacity required at "C".

The voltage of the main battery required is somewhat greater when operating through a transformer than shown on page 22, Fig. 1, for a standard circuit. The curves, page 22, Fig. 2, show the normal voltage required when using the No. 341A Transformer with different length lines of No. 9 B. & S. copper wires, 8.3 ohms per loop mile, and with selector sets uniformly distributed. Similarly, the curves, page 22, Fig. 3, show the normal voltage required when using one No. 70A Repeating Coil and when using two or three coils connected in series aiding as required.

It will be seen from the illustrations, page 22, Figs. 2 and 3, that the No. 341A Transformer is considerably more efficient than the No. 70A Repeating Coil in repeating the selector impulses to the lines. Even with very long lines only one coil will be required while with the No. 70A Coil two or three coils will be required.





Branch Line Operated Through Repeating Coil



No. 160B Condenser

INTERMEDIATE SIMPLEX TELEGRAPH STATION

When an intermediate simplex telegraph station is required, either the No. 341A Transformer or the No. 70A Repeating Coil may be connected in the line circuit as shown above, and the main selector line at the dispatcher's station should be operated through a No. 341A Transformer as shown on page 24. As stated above, the No. 341A Transformer is more efficient for transmitting the selector impulses, while on the other hand it will cause more transmission loss than one or two No. 70A Repeating Coils.

BRANCH LINE

When a branch circuit is required without any metallic connection to the main line and when the main line is not operated through a transformer, it should be connected as shown above. The capacity of the condenser at "C" should be not less than 10 mf plus 1 mf for each selector on the branch line. When the main line is operated through a transformer as shown on page 24 the primary of the No. 341A Transformer or the No. 70A Repeating Coil should be connected directly to the main line without any condensers or resistances in series. In this case, also, the No. 341A Transformer is more efficient for transmitting the selector impulses and not quite as good from the telephone transmission standpoint.

Operation of Selector Circuits Through Transformers and Repeating Coils (Continued)


SIMPLEX BRIDGE

For a simplex bridge at the far end of a train or message line operated through a transformer, a No. 70A Repeating Coil or a No. 341A Transformer should be connected as shown at the far end of each side circuit, note composite phantom circuit below.

When the selector circuit is not operated through a transformer at the dispatcher's station, a No. 34C Resistance connected to give 1000 to 2000 ohms should be connected between each side of the simplex coil and the line wires at both the near and far end of the line.

COMPOSITED PHANTOM

A general arrangement for using a train and message line for side circuits of a composited phantom, to give two simplex telegraph circuits and a through telephone circuit in addition to the two selector circuits is shown below.



Composite Phantom Circuit

Portable and Siding Telephone Sets

GENERAL



No. 1330 Telephone Set

Portable and Siding telephone sets are intended for use of conductors and trainmen for calling dispatchers from various points on the railway train dispatching telephone system. The circuits of these sets are arranged similar to the telephone circuits of way stations. The sets are usually equipped with pushbuttons for use when talking. Described in detail under "Telephone Sets."

SIDING TELEPHONE SETS

Siding telephone sets are wall type sets usually employing a head set receiver and equipped with or without a ringer or hand generator, depending upon whether one or two-way ringing service is required over the system.

PORTABLE TELEPHONE SETS

Portable telephone sets are for use of conductors and trainmen for calling the dispatcher from any point on the train dispatching system. These sets are

equipped with hand set telephones. Line connections to the sets are usually made by means of line-poles which are furnished separately.

Testing Equipment


No. 60B TEST SET

The No. 60B Test Set is a small portable set suitable for testing selectors or selector sets for their electrical operation. The set consists of a relay for reversing the current through the selector, a potentiometer for varying the current through the selector, three small keys to give test conditions, a meter and a condenser, all mounted on a removable panel in a black finished sheet steel box $8\frac{1}{8}$ " long, $7\frac{1}{4}$ " wide, and $5\frac{3}{4}$ " deep. The box is equipped with a carrying handle.

The panel is arranged to mount a No. 60 type Selector Key for operating the selector under test and there is space in the bottom of the box for mounting three No. 768 Eveready batteries to be connected in series and to the B1 and B2 terminals. The complete set including batteries weighs 14 pounds.

The schematic circuit of the No. 60B Test Set is shown below.

Other test sets for various purposes can be furnished, depending upon the requirements. Refer to description of "Apparatus."



NOTE: - KEY S CONSISTS OF S' AND S"
KEY C CONSISTS OF C' AND C"

Schematic of No. 60B Test Set



No. 60B Test Set

CHAPTER III

DESCRIPTION OF APPARATUS

BATTERY BOXES



No. 1A Battery Box


The Nos. 1 and 2 Type Battery Boxes provide a neat and convenient means of mounting dry cells and protecting them from injury. They are made of sheet metal, finished with black japan and are lined with insulating material. Pear-shaped mounting slots are provided to facilitate mounting the boxes on vertical surfaces, and for readily removing them. This permits of their being located at the sides of or under desks, and in other places where they will be out of the way and yet be accessible and adjacent to the telephone or apparatus to which they are connected.

Code	Dry Cell	Dimensions
No.	Capacity	Ins.
1A	3 No. 6 cells	3½ x 7 ¹⁵ / ₃₂ x 9 ⁷ / ₁₆
2Λ	4 No. 6 cells	31/4 x 73/8 x 12%-37/2 x 73/8 x 1219/4
2B	9 No. 6 cells	5 ²³ / ₃₂ x 7 ⁹ / ₁₆ x 14 ⁵ / ₃₂

BELLS



No. 127 Type



No. 101402 Bell



No. 392 Type Loud Ringing Extension Bell

Extension Type

These extension bells consist of a ringer mounted in an oak box with exposed gongs. The approximate overall dimensions are $6\frac{1}{2}$ inches wide by $5\frac{7}{8}$ inches high by $4\frac{7}{8}$ inches deep. The standard finish is golden oak.

The Nos. 127 E, F and G Extension Bells will operate on telephone ringing current.

The No. 127H Extension Bell has a split wound ringer for use on simplex circuits. This ringer also performs the function of a split retardation coil for such services.

Bells (Continued)

The No. 127J Extension Bell contains a direct current type of ringer to operate from one or two dry cells for use in connection with selector apparatus equipment.

If different tone gongs are required, the extension bells should be ordered in accordance with D specifications as shown below opposite the code number listings. For example, if the No. 127E Extension Bell is required equipped with a No. 3 cow gong, order as follows: No. 127E Extension Bell D-5979.

Special Gongs (See note above)

Code No.		Ringer No.	Resistance Ohms	Gong No.	No. 21 Sleigh Gong	No. 3 Cow Gong	No. 10 Tea Gong
127E	Ext. Bell	38AG	1020	26A	D-25816	D-5979	D-19344
127F	Ext. Bell	38BG	2500	26A	D-5980	D-7000	D-7009
127G	Ext. Bell	38FG	1620	26A			
127H	Ext. Bell	43NG	88	26A	******		
127J	Ext. Bell	60CG		26A-(H	Equipped with a N	lo. 21BA Conde	enser)

BELLS-LOUD RINGING EXTENSION TYPES

These bells are equipped with galvanized gongs and with a black finished metal base. The cover is moisture proofed.

Code No.	Resistance	Gong No.	Diameter of Gongs
392A Subscriber Set	1000 ohms	28A	6 inch
392B Subscriber Set	2500 ohms	28A	6 inch
392E Subscriber Set	1600 ohms	28A	6 inch

BELLS-LOUD RINGING EXTENSION TYPES-WITH BACKBOARD

Code No.	Ext. Bell No.	Resistance	Backboard No.
342J Sub. Set	No. 392A Sub. Set	1000 ohms	152A (replaces 149A)
342K Sub. Set	No. 392B Sub. Set	2500 ohms	152A (replaces 149A)

BELLS-VIBRATING TYPES

These are loud ringing vibrating bells for operation on direct current. The No. 101403 Bell differs from the No. 101402 Type in that it is equipped with an armature contact for operating a drop.


List No.	Resistance Ohms	Diameter of Gong	Used with Selector Sets
101402	1100	4 in.	No. 101A, No. 101B
101403	1100	4 in.	No. 101A, No. 101B
101404	5.3	4 in.	No. 102A, No. 102B

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS BINDING POSTS



Code No.	Description	Finis
1A	Thumbscrew connections, no soldering terminals	Bras
2A	Lock nut connections, one back soldering terminal.	Nick
2C	Similar to No. 2A but with wing nut instead of lock nuts.	Nick
2E	Lock nut connections, one front soldering terminal	Bra
3A	Lock nut connections, one back soldering terminal	Nick
3B	Wing nut connection; used in 1314A Telephone Sct. Screw Mounting.	Nick
3C	Wing nut connections; one back soldering terminal; used on the No. 1017 Test Set. Screw Mounting	Nick
16A	Wing flut confections, one back softening to the softenin	Nick
20A		Nick
	Screw connections, one front soldering terminal. Used in No. 8 and No. 14 Cable Terminals when the original binding posts break off above the lower nut.	INICE
29A	For 10-32 thread only	Tinne
30A	Screw connection, one soldering terminal.	Tinne
33D	Insulated Binding Post, arranged to mount on 1/2" panel	Blac
37A	Line Type for miscellaneous uses.	Bra
44A	Wing nut connections, one front soldering terminal	Nick
P-121382	wing nut connections, one front solutioning terminal. Line Type for miscellaneous uses.	Tinne
P-121382		
9	Cord fastener, Line Type for miscellaneous uses.	Tinne

TERMINAL PUNCHINGS



Code	No.
3	
6	
8	
9	
13A	
13B	
14	
15A	
17A	
21A	


Material
Nickel, silver
Brass, tinned ends
Brass, tinned ends
Brass, tinned ends
Brass, dip tin finish
Brass, dip tin finish
Brass, one end tinned
Brass, tinned ends
Brass, tinned ends
Brass, tinned ends
Brass, tinned ends

Use
On fuse posts and fuse blocks
For the ground side of ringing leads
On double sided connecting racks
On No. 10 switchboards
On double sided connecting racks
Similar to No. 13A, except ½" shorter
For screw connection on one end
On one sided connecting racks
On induction coils and telephone coils
On repeating coils, induction coils, and retardation coil

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS CABLES AND CABLE TERMINALS



Cable for Interior Use



B26 Cable Terminal



Lead Covered Cable

CABLES (INTERIOR) FOR WAY STATIONS

The following list of interior way station cables have tinned black enameled single silk served and cotton braided conductors and waxed cores and are covered with a cotton braid which is impregnated with fire proofing paint.

Code No.	No. of Conductors	B. & S. Gauge	Diamete
1450	6	No. 20	194"
1451	12	No. 20	19/11 25/11 31/41
1453	22	No. 20	3164"

Note: For a general line of textile insulated cables see Telephone Apparatus and Cable Catalog.

CABLES-LEAD COVERED AND SUBMARINE

Lead covered cables for aerial and underground use, also for submarine purposes are available. For further information refer to detailed description of these cables in Telephone Apparatus and Cable Catalog.

EMERGENCY CABLES-"CIRCULAR LOOM"

These are emergency cables adapted for use in case of breaks in the telephone lines. The cables can be strung on poles, laid on the ground or through water and are easily handled as they are furnished on reels which are provided with stands for unwinding. These circular loom cables are furnished with No. 19 B. & S. gauge and No. 14 B. & S. gauge solid copper wire as follows:

Description	Size	Lengths
CL Emergency Cable	{ 7 quads 19 quads	1000 foot 500 foot
CL Bridle Cable	3 quads 5 quads	As desired As desired

TYPE "B" CABLE TERMINALS

The B26 Cable Terminal will terminate both a 26 pair underground cable and a 26 pair aerial cable and provides for cross connection. The other sizes have similar capacity ratings.

— Includes


Code	Capacity	Cable Terminal	
No.	Pairs	Box No.	Equipped with
B26	26	B26	1 B26A Fuse Chamber and 1 B26A Binding Post Chamber
B51	51	B51	1 B51A Fuse Chamber and 1 B51A Binding Post Chamber
B76	76	B76	1 B76A Fuse Chamber and 1 B76A Binding Post Chamber
B101	101	B101	1 B101A Fuse Chamber and 1 B101A Binding Post Chamber
B152	152	B152	2 B76B Fuse Chambers and 2 B76B Binding Post Chambers
B202	202	B202	2 B101B Fuse Chambers and 2 B101B Binding Post Chambers
B304	304	B304	2 B76B Fuse Chambers and 2 B76B Binding Post Chambers 2 B76C Fuse Chambers and 2 B76C Binding Post Chambers
B404	404	B404	2 B101B Fuse Chambers and 2 B101B Binding Post Chambers 2 B101C Fuse Chambers and 2 B101C Binding Post Chambers

Note: B Fuse Chambers do not include the No. 7T Fuses which must be ordered separately.

Cable Terminals (Continued)



No. 18E Cable Terminal, Open



Closed Open No. 14C Cable Terminal



No. 12A Cable Terminal



Type C Cable Terminal Cover Removed

TYPE "BB" CABLE TERMINALS

This type Cable Terminal was designed for use in crossconnecting long sections of aerial cable or at points where aerial cables branch. A splicing chamber is provided at the bottom of the box for housing splices.

			-Includes -	
		Cable	Bindi	ng
Code	Capacity	Terminal	Post C	hambers
No.	Pairs	Box No.	Left Side	Right Side
BB26	26	BB26	1-B26A	1-BB26A
BB51	51	BB51	1-B51A	1-BB51A
BB76	76	BB76	1-B76A	1-BB76A
BB101	101	BB101	1-B101A	1-BB101A
BB152	152	BB152	2-B76B	2-BB76B
BB202	202	BB202	2-B101B	2-BB101B
DDaga	004	DDOG	12-B76B	2-BB76B
BB304	304	BB304	12-B76C	2-BB76C
DD	101	DD 404	2-B101B	2-BB101B
BB404	404	BB404	2-B101C	2-BB101C

TYPE "C" CABLE TERMINALS

The "C" Type Cable Terminal was designed for terminating lead covered cables and is provided with a cable stub which is attached to a terminal plate and sealed with compound. It is equipped with a cast iron mounting bracket arranged to mount with four screws.

Code No.	Capacity Pairs	Length of Stub	Dimensions in Inches	Replaces
C10	10	61/2 ft.	4 1/8 x 5 3/6 x 12 3/4	8A
C16	16	61% ft.	4 1/8x53/6 x14 5/8	*8B and 8D
C26	26	7 ft.	4 1/6x511/6x17 3/4	**8C and 8E

*Note: Two C16 Cable Terminals replace one No. 8D. **Note: Two C26 Cable Terminals replace one No. 8E.

No. 14 TYPE CABLE TERMINAL (Unprotected)

This terminal consists of a cast iron box with hinged cover, containing a porcelain terminal block with binding post for line connection. The back of the box is designed to permit mounting it on either a flat surface or a pole, by means of four screws.

The cover is arranged for charting the pairs on the inner surface.

This cable terminal can be ordered equipped with a $5\frac{1}{2}$, 8, 10 or 12 ft. cable stub, as required. This stub will enter from the top, unless otherwise specified.

Code	Capacity	Length	Width of Cover
No.	Pairs	Including Nipples	Inches
14B	11	103/32	71/2
14C	16	12^{2} $\frac{1}{32}$	915/16
14D	26	$17^{23}\frac{32}{32}$	$14\frac{1}{2}$

No. 18 TYPE CABLE TERMINALS (with Protectors)

This is a protected terminal for open wire distribution from underground or aerial cable. It is enclosed in a round black finished iron cover approximately 8% inches in diameter. The cover is equipped with a spring to hold it when raised to the top of the terminal and a safety chain fastening it to the base. The base is slotted at the back making the terminal suitable for either wall or pole mounting. Both cover and base are galvanized.

Terminals are equipped with:

No. 7A Fuses (7 ampere unless otherwise specified) No. 1 Protector Blocks No. 2 Protector Blocks No. 3 Protector Micas

2B

P-13549

P-166669

P-148240

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS

Cable Terminals (Continued)

A six-foot No. 22 B. & S. gauge cable stub is standard, and will be furnished attached to assembled terminal unless otherwise ordered.

Code	Capacity	Length,	Code	Capacity	Length,
No.	Pairs	Inches	No.	Pairs	Inches
18A	10	19%	18D	30	331/2
18B	15	221/32	18E	50	4625/2
18C	25	2829/32	18F	60	5321/2

No. 12 TYPE CABLE TERMINALS (Unprotected)

The No. 12 Type Cable Terminal is for interior distribution, and consists of a wooden base and a black finished metal cover. They are equipped with terminals having soldering connections at one end and screw connections at the other. Cable forms may be brought in from either end.

Code Capacity		——————————————————————————————————————			
No.	Pairs	Length	Width	Depth	
12A	13	1115/16	41/6	113/16	
12B	23	1115/16	41/16	213/16	
12C	33	1115/16	41/16	1^{13}_{16} 2^{13}_{16} 3^{13}_{16}	

NO. 2B CIRCUIT BREAKER

The No. 2B Circuit Breaker is an overload circuit breaker, designed for use in the main battery circuit of train dispatching lines to protect the relays and associated apparatus from excess currents, due to short circuits. It consists of a coil, armature and circuit breaker arm mounted on a black phenol fibre base, the overall dimensions being approximately 3¾" x 6", and extending out from the wall approximately 4", when the arm is in the open or operating position. The resistance of the circuit breaker is 2 ohms and it is normally adjusted to experte on 0.6"

Replacement Parts

2B

mally adjusted to operate on 0.6 ampere and not to operate on 0.4 ampere. These values can be increased or decreased by adjusting the air gap between the armature and the magnet by means of a knurled nut at the extreme end of the magnet. The best setting for the circuit breaker will depend somewhat on the local conditions for each installation.

The No. 2B Circuit Breaker is similar to the No. 2A Circuit Breaker formerly furnished except that it has a black phenol fibre base instead of a slate base, coin silver contacts instead of platinum contacts, and is equipped with alarm contacts.

Subject

Trunnion Screw Helical Spring

Trunnion Bracket Handle

Adjusting Screw

Adjusting Nut

Sub-base

Bas Binding Post

Screw

Screw Pivot Screw

Arm

B


C D

E

G

H

K



Circuit			Circuit
Breaker	Letter	Subject	Breaker
P-95346 P-227865	N	Armature	* P-95326 P-95327
P-229128	0	Coil	P-95316
P-228895	P	Adjusting Bracket	P-95330
P-95320	Q	Adjusting Nut	P-95333
P-95336	R	Tension Bracket	P-95331
P-95337	S	Bracket Screw	P-95832
P-95335	T	Alarm Stud	P-227868
P-95334			
P-132717		Spring Pileup	
* (P-227867		Screw	P-139931
P-95338		Insulator	P-133451
P-95339		Clamping Plate	P-107040

Upper Contact Spring

Lower Contact Spring

Bushing


*To be assembled.

P-95340

P-95321

P-95322

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS CONDENSERS



CONDENSERS-UNMOUNTED TYPE

Code No.	Rated Capacity Microfarads	Tested On Voltage	Use	Code No.	Rated Capacity Microfarads	Tested On Voltage	Use
31A	$\begin{pmatrix} 0.05 \\ 0.05 \end{pmatrix}$	500 D.C.	General	181A	$1 \left\{ \begin{array}{l} \text{Min85} \\ \text{Max. 1.15} \end{array} \right\}$	2000 D.C.	Railway (Replaces 21CB)

CONDENSERS-MOUNTED TYPE


The following condensers are composed of standard units mounted upon wooden bases as illustrated. The No. 33 Type mounts on a coil rack. These condensers are tested to 500 volts, direct current, except Nos. 33BJ and 33BS, which are tested to 1000 volts alternating current.


Code No.	Condensers Used	Rated Capacity Each	Overall Dimensions (Inches)	Code No.	Condensers Used	Rated Capacity Each	Overall Dimensions (Inches)
33A 33B 33C 33D 33E 33F	2 No. 21L 1 No. 21L 2 No. 21BW 1 No. 21BW 2 No. 21N 1 No. 21AS	2 (ea.) 2 1 (ea.) 1 0.5 & 1.0(ea.) 0.5	10 ³ 4x1 ⁷ 4x2 ³ 8 10 ³ 4x1 ⁷ 4x2 ³ 8 10 ³ 4x1 ⁷ 4x1 ¹ 1 ₆ 10 ³ 4x1 ⁷ 4x1 ¹ 1 ₆ 10 ³ 4x1 ⁷ 4x1 ⁵ 8 10 ³ 4x1 ⁷ 4x1 ⁵ 6	33G 33H 33L 128BA	2 No. 21AD 4 No. 21L 2 No. 21AS (1 No. 138A) 1 No. 27B Bracket	$\begin{cases} 1.0 \\ 1.0 \end{cases} \text{(ea.)} \\ 2 \text{ (ea.)} \\ 0.5 \text{ (ea.)} \\ 1 \begin{cases} \text{Min. } 1.00 \\ \text{Max. } 1.25 \end{cases}$	10¾x1½x2¾ 10¾x1½x4½ 10¾x1½x1½ 678x178x2

The overall dimensions of the mounted condensers listed below are the same as those given for the No. 33E Condenser. Each condenser is wired to two separate terminals on one end of the base.

Code	Condensers	Capacit Each	y—M.F. Unit	Code	Condensers		y—M.F. Unit
No.	Used	Minimum	Maximum	No.	Used	Minimum	Maximum
*33BJ	2 No. 138QA 2 No. 27B Brackets	1.07	1.09		2 No. 21QD 2 No. 21QE	$\frac{2.10}{2.12}$	$\frac{2.14}{2.16}$
**33BS	4 No. 138QA 2 No. 27C Brackets	1.07	1.09	*Rep	laces No. 33J Cond laces Nos. 33S and	lenser. 33T Condense	473 ers.

Condensers (Continued)-Mounting Plate Type







No. 160B Condenser

The following condensers are for use on relay type mounting plates:

The No. 138 Type Condensers require No. 24 Type Brackets when mounted in place of No. 57 Type Condensers, and No. 27A Brackets when mounted in place of the No. 21AA Condenser. Furnished with two nuts and washers for mounting. Arranged to mount on 1¾" vertical and horizontal centers on mounting plates. Safe continuously applied voltage either DC or effective AC at 60 cycles or less and of an approximate sine wave, is 300 volts.

The No. 139 Type Condensers require No. 24 Type Brackets when mounted in place of No. 57 or similar Type Condensers. Furnished with two nuts and washers for mounting. Arranged to mount on 1" horizontal and 1¾" vertical centers. Safe continuously applied voltage, 200 DC or 180 effective AC at 60 cycles or less and of an approximate sine wave.

The No. 141 Type Condensers require No. 24 Type Brackets when mounted in place of No. 57 or similar Type Condensers. Arranged to mount on ½" horizontal and 1¾" vertical centers. Furnished with two nuts and washers for mounting. Safe continuously applied voltage 200 DC or 180 effective AC at 60 cycles or less and of an approximate sine wave.

If the No. 141H Condenser must fill the space of the No. 21 Type Condensers, order should specify P-409556 Adapter.

If the No. 141QF Condenser must mount in the same position as the No. 21AM Condenser, order should specify two P-127145 Adapters.

The No. 142 Type Condensers require one No. 27A Bracket when mounted in place of the No. 21 or similar Type Condensers. Arranged to mount on ½" horizontal and 1¾" vertical centers. Furnished with two nuts and washers for mounting. Safe continuously applied voltage, either DC or effective AC at 60 cycles or less and of an approximate sine wave, is 300 volts.

			Capaci	ty M.F.			
Code	-17			ped ON enser At		Tested On	
No.	Fig. No.	Min.	A	В	Max.	Voltage	Remarks
57N 57QF		2. 2.14			2.18	500 D.C. 500 D.C.	Maximum variation M.F. plus 35%
138A	i	1.00	1.		1.25	1000 A.C.	Replaces No. 21AA Condenser except for "Additions and Maintenance Only"
138B		1.25	1.25		1.57	1000 A.C.	Used in No. 160C Selector Set
138QA	2	1.07	1.07	1.09	1.09	1000 A.C.	
138QB	2	1.04	1.04	1.12	1.12	1000 A.C.	
139A	1	2.00	2.		2.50	500 D.C.	Replaces No. 90B Condenser
139C	2	$\begin{cases} 1.00 \\ 1.00 \end{cases}$	1.	1.	$\{1.25 \\ 1.25 \}$	500 D.C.	Replaces No. 90A Condenser
139QA	3	2.14	2.14	2.18	2.18	500 D.C.	Replaces No. 90C Condenser
139QC	3	2.16	2.16	2.22	2.22	500 D.C.	Replaces No. 21BE Condenser
141 A	2	1.00	1.		1.25	500 D.C.	Replaces No. 89H Condenser
*141H	1	{ .02	.02	. 02	.03	500 D.C.	Replaces No. 21AH Condenser
1410F	2	1.08	1.08	1.14	1.14	500 D.C.	Replaces No. 21AM Condenser
141OP	2	.26	.26	.28	.28	500 D.C.	
142B	2	.25	.25		.32	1000 A.C.	Replaces Nos. 21Y and 21AL Condensers
142D	2	.05	. 05	TEN MA	.06	1000 A.C.	Replaces No. 21U Condenser
*Va	luos stampo			hetween ter			"R" are measured between terminals 2 and

*Values stamped at "A" are measured between terminals 1 and 2 and values at "B" are measured between terminals 3 and 4. Consists of two separate condensers insulated but not shielded from each other. These condensers should be used bridged off or across two separate transmission circuits and should not be used in the same circuit where the effect of the capacity between separate units will be detrimental to transmission.

CONDENSERS—CABINET TYPE

Code No. 160B Description
Consists of 16 No. 130AB Condensers
mounted in a steel cabinet. Overall
dimensions including mounting
lugs, 8¼" long x 6¼" wide x 5"
deep. Has a capacity of 20 M.F.
For illustration, see above.

Use
In A.C. Train Dispatching Circuits
when selectors are operated through
a transformer or repeating coil and
are connected in series with the
primary winding of the repeating
coil. Replaces the No. 160A Condenser.

Condensers (Continued)—Unmounted

These condensers are of the tinfoil and paper type. The paper dielectric used in separating the tinfoil plates is prepared under rigid specifications from specially selected stock and its high and uniform quality contributes materially to the excellence of the product obtained.




Fig. 1 Bent Terminals

Fig. 2 Straight Terminals

No. 21 Type

Code	Capacity	Fig.	Dimen	sions, I	nches	Voltage	
No.	Microfarads	No.	A	В	C	Tested On	Used in Sets
21H	0.1	1	1	5/32	1/8	1200 D.C.	Interrupters
21J	0.3 & 0.3	2	1			500 A.C.	3 terminals
215	.125, .25 & .5	2	1	13/32		500 D.C.	Telegraph, 4 terminals
21AA	1.0	1	121/32	11/32 13/32 5/32 5/32 7/32	7/32 1/8	1000 A.C.	160, 295, 300, 1293, 1317 & 1336
21AK	0.5	1	1	5/32	1/8	1000 A.C.	Telegraph
21BA	0.01	1	- 1	7/32	1/8	1000 A.C.	160
21BJ	${{ m Max. 2.512} \choose { m Min. 2.488}}$	2	$1^{21}/_{32}$	11/32		500 D.C.	("For Additions and Maintenance Only" Nos. 139QC and 141QP in parallel recommended

The Nos. 147 and 149 Type Condensers are equipped with mounting tabs at lower edge of condenser and may be mounted by means of this tab and a mounting strap.

Safe continuously applied voltage either DC or effective ΛC at 60 cycles or less and of an approximate sine wave, is 180 volts.

If No. 147 Type Condenser when substituted must fill space of No. 21 Type, order should specify P-409555 Adapter, and for the No. 149 Type Condenser, specify P-409556 Adapter.

		Capaci	ty M.F.			
Code		Stamp	ped At		Voltage	
No.	Max.	A	В	Min.	Tested On	Used in Sets
147A	2.50		2.00	2.00	500 D.C.	General, 311A, 1312A, 1314A Sets. Replaces Nos. 21D, E and L Condensers
147B	${1.25} \ 1.25$	1.00	1.00	$\left. \begin{array}{c} 1.00 \\ 1.00 \end{array} \right\}$	500 D.C.	General. Replaces No. 21BG Condenser
*147C	$\begin{cases} 1.25 \\ 1.25 \end{cases}$	1.00	1.00	$\left. \begin{array}{c} 1.00 \\ 1.00 \end{array} \right\}$	500 D.C.	Composite. Replaces No. 21AD Condenser
*147D	1.25	1.00	.5	1.00	500 D.C.	Coil Racks. Replaces No. 21N Condenser

*Values stamped at "A" are measured between terminals 1 and 2, values stamped at "B" are measured between terminals 1 and 3.

		Capacity M.F.			
Code No.	Max.	Stamped On Condenser	Min.	Voltage Tested On	Used in Sets
149A	1.25	1.	1.0	500 D.C.	General, 502, 1311A, 1312, 1314, 1330, 1331, 1332 Sets. Replaces Nos. 21F, K, W and BW Condensers
149B 149C 149D	.62 .13 .80	.5 .1 .65	.50 .10 .65	500 D.C. 500 D.C. 500 D.C.	General. Replaces Nos. 21AC and AS Condensers General. Replaces No. 21R Condenser General. Replaces No. 21BF Condenser

CONDENSER MOUNTINGS

Condenser Adapters


P-127145 Galvanized iron, overall dimensions 11/2" x 1/2".

P-409555-Wood, overall dimensions 41/16" x 111/16".

P-409556-Wood, overall dimensions 41/16" x 111/16".

Condenser Brackets







24A—Steel, aluminum finish, overall dimensions $31\frac{1}{16}$ x $\frac{1}{16}$ x $\frac{1}{16$

24B—Steel offset, aluminum finish, overall dimensions 311/16" x 1/16" x 11/2".

24C—Steel offset, aluminum finish, overall dimensions $3^{11}/_{6}'' \times 7'_{6}'' \times 1^{1}/_{2}''$.
24D—Steel offset, aluminum finish, overall dimensions $3^{11}/_{6}'' \times 7'_{6}'' \times 1^{1}/_{2}''$.

27A-Steel, aluminum finish, overall dimensions 11/2" x 11/8" x 1".

27B-Steel, aluminum finish, overall dimensions 11/2" x 115/6" x 1".

27C—Steel, aluminum finish, overall dimensions $1\frac{1}{2}$ " x $3\frac{1}{4}$ " x 1".

27D-—Steel, aluminum finish, overall dimensions $1\frac{1}{2}$ " x $2\frac{7}{16}$ " x 1".



No. 27 Type

Condenser Straps

P-43065—A straight galvanized iron strap, overall dimensions 415/6" x 1/2".

P-43121—A galvanized iron clamp, overall dimensions 5\%" x \%".

P-49022—A straight galvanized iron strap for mounting two condensers, overall dimensions 95%" x 1/2".

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS CONNECTING BLOCKS AND BRIDGING CONNECTORS



No. 1A







No. 11A



No. 30A




No. 12E

CONNECTING BLOCKS

Code No.	No. of Connectors	Type of Connector	Size Length	of Base, Width	Inches Thickness	Material Base
1A 8A	3 6	(Binding Post Type Cord tip terminal	$\frac{217}{32}$	$\frac{21}{32}$	13/32 5/8	Composition Ebonized Wood
11A 11B	$\frac{2}{2}$	Two screw terminals on each con- nector electrically connected	$\frac{1\frac{1}{8}}{1\frac{1}{8}}$	$\frac{1\frac{5}{32}}{1\frac{5}{32}}$	5/8 9/16 9/16	Composition Composition
TI	he No. 11B C	onnecting Block is the same as the N	io. 11A, o	except th	at it is equip	oped with a black
finished	d metal cover.					
12E 12F	3 3	Two screw terminals on each con- nector electrically connected. Equipped with Cord Fasteners.	1^{11}_{16} 1^{15}_{16}	$1\frac{5}{32}$ $1\frac{5}{32}$	916 916	Composition Composition
	he No. 12E C d metal cover.	onnecting Block is the same as the N	lo. 12F, e	except th	at it is equip	oped with a black
30A 30B	$\frac{12}{22}$	Consists of sets of binding posts molded into the block arranged	$\frac{4\frac{3}{16}}{7\frac{5}{16}}$	$\frac{1\frac{1}{2}}{1\frac{1}{2}}$	1/2 1/2	Composition Composition
30C 30D	32 52	in 5/8" centers in two rows, 3/4" apart and staggered	$10\frac{7}{16}$ $16\frac{11}{16}$	$\frac{1\frac{1}{2}}{1\frac{1}{2}}$	1/2	Composition Composition
Ti wires.	he No. 30 Typ	pe Connecting Blocks are equipped w	ith nuts a	and wash	ers for conne	ecting distributing
31A 31B	12 22	Each connector has one lock nut binding post and one soldering	43/16 75/16	11/2	1/2	Composition Composition
31C 31D	32 52	terminal, brought out on the side, otherwise same as No. 30 Type	10 ⁷ / ₁₆ 16 ¹ / ₁₆	$\frac{11/2}{11/2}$	1/2 1/2	Composition Composition

CORDS



Note: The length of receiver, desk stand and transmitter arm cord is measured between the points where the conductors emerge from the external braiding.


Desk Stand and Transmitter Arm Connecting Cords

			Cord T	ips				
Code No.	Type and Covering	Conduc- tors	Trans. or Rec. End	Set End	Tracer Colors	Standard Length		d with Transmitter Arm
409	Moisture-proofed	3	103	103	Red, Yellow, Green	6′	1020AB, 1120AB, 1042AB & 1142AB	1048DA, DB, DC & DD, 1148DA, DB, DC & DD, 1020C & 1120C
416	Moisture-proofed	4	103	103	Red, Green, Blue, Yellow	6'	1020BR & 1042BR	1048GA, GB, GC & GD
423 426	Moisture-proofed Moisture-proofed	1	61 98	103 103	Maroon Yellow	91/2" 97/8"	1020 & 1042BR 1020AB & BR, 1120AB, 1042AB & BR & 1142AB	1048 & 1148 Type 1020C & E, 1120C, 1048DA, DB, DC & DD, 1148DA, DB,
427	Moisture-proofed	1	98	103	Black	91/8"	(Replaces 330 cord) 1020AB & BR, 1042AB & BR & 1120AB & 1142AB	DC & DD 1048DA, DB, DC & DD, 1020E, 1148DA, DB, DC & DD
541	Water-proofed	3	105	105	Red, Yellow, Green	5'6''	1020 & 1042 Type	1048 & 1148 Type
550	Tinsel Silk	3	103	103	Red, Yellow, Green	5'6"	1020AL, 1040AL	1020CC
554	Moisture-proofed	2	69	103	White, Green	2'6"	1020AB & BR, 1042AB & BR, 1120AB & 1142AB	1048DA, DB, DC & DD, 1148DA, DB, DC & DD using No. 186 & 189 Receivers, 1020C & 1120C
571	Tinsel Silk	2	69	103	White, Red	5'6"	1020 or 1040 Type (us ing 190 Receiver)	
450	Combination cord T1A Cords, 9 1/8 inc		h 1020AL a	nd 104	10AL Desk Stand,	consists o		Cord 2½ ft., and two

The following are new coded type cords. The first letter of the code number indicates the type of apparatus with which the cord is used and the middle number represents the number of conductors in the cord. For example, D4E is a desk stand cord having 4 conductors.

			Cord T	ips				
Code No.	Type and Covering	Conduc- tors	Trans. or Rec. End	Set End	Tracer Colors	Standard		with Transmitter Arm
D3A	Moisture-proofed	3		103	Green, Red, Yellow	5'6''	1020AL	
D3D	Moisture-proofed	3	• •	103	Green, Red, Yellow	6'	1020AB, 1042AB, 1120AL & 1220PC	1020C, D, E and 1120C
D4E	Moisture-proofed	4	103	103	Green, Red, Yellow, Blue	5'6"	1020U & 1040U (Replaces 365 Cord)	
D4G	Moisture-proofed	4	103	103	Green, Red, Yellow, Blue	6'	1020BR & 1042BR	1020E
R2A	Tinsel Silk	2	103	103	Green, White	2'6''	20 & 40 Types (Replaces 549 Cord)	1020CC
R2U	Moisture-proofed	2	69	103	Green, White	2'6"	1020AB, 1042AB, 1020BR, 1120AB, 1142AB & 1042 BR	1020C, D, E, 1120C
R2Y	Tinsel Silk	2	103	103	Green, Red	2'6''	1020U & 1040U (Replaces 412 Cord)	
T1A	Moisture-proofed	1	98	103	Yellow	1'	1020U & 1040U (Replaces 547 Cord)	1020CC

Telephone Set Cords (Continued)



Note: The length of receiver, desk stand and transmitter arm cord is measured between the points where the conductors emerge from the external braiding.


Wall Telephone Transmitter and Receiver Cords

			Cord Tips				
Code No.	Type and Covering	Conduc- tors	Trans. or Rec. End	Set End	Tracer Colors	Standard Length	Used with Telephone Sets
329	Tinsel Silk	1	98	103	Brown	9 1/8"	1293 Type
384	Water-proofed	2	105	105	White, Green	101/2"	1336F & H, 1314A
385	Water-proofed	1	56	105	Black	7"	1336F & H, 1305AC
422	Water-proofed	3	62	62	Yellow, Red, Green	6'	1278G & H (for hand set)
446	Moisture-proofed	2	29 & 76	103	White, Green	101/2"	1317W & AD, 1305AC, 1293AD & AK
521	Tinsel Worsted	2	105	105	White, Green	2'6''	1312A, 1317P, S, AH, BK, CN, CR, CP, CS & CG
540	Stranded Cotton	1			Brown	5"	1317 Types, 1336F & H, 1330E & F Battery Cord
546	Moisture-Proofed	2	69	103	White, Green	2'	1317 Type, 1293AE & AL with 186 Receiver
TIA	Moisture-proofed	1	98	103	Yellow	978"	1375B & I398A (Replaces 547 Cord)

Portable Telephone, Test Set and Hand Set Cords

			Cord	Tips			
Code No.	Type and Covering	Conduc- tors	Rec. End	Set End	Tracer Colors	Standar Length	
243	Tinsel Cotton	1	103	103	Brown	8"	1375B & 1398A with 1001H Hand Sets
366	Water-proofed	3	105	105	Red, Yellow, Green	6'	1330, 1331 & 1332 Types with 1001C Hand Set
384	Water-proofed	2	105	105	Green, White	101/2"	1336F & H, 1314A
422	Water-proofed	3	62	62	Yellow, Red, Green	6'	1278G & H with 1001F Hand Set
509	Water-proofed	2	105	22	Black	6'	1330 & 1331 Types, using 146 Plug
523	Water-proofed	2	30	30	Red, White	2'	1017B, C, E and 1006D Test Sets
537	Water-proofed	2	30	30	Red, White	4'	19A Test Set
545	Tinsel Silk	2	104	103	Green, Red	6'	Portable Telephone with 148 Plug
572	Water-proofed	2	78	30	White, Red	2'	1017 Test Set with 515 Receiver
574	Water-proofed	1	105	Special	Black	5'	1375B, 1398A using 1001A Hand Set
MIA	Water-proofed	1	Special	22	Black	100'	No. 4 Line Pole
M2J	Water-proofed	2	62	22	Black	100'	No. 3 Line Pole
M2K	Water-proofed	2	62	22	Black	100'	No. 5 Line Pole

Cords (Continued)



Note: The length of receiver, desk stand and transmitter arm cord is measured between the points where the conductors emerge from the external braiding.

Dispatchers' and Operators' Head Set Receiver Cords

			Cord	Tips		
Code No.	Type and Covering	Conduc- tors	Trans. or Rec. End	Set or Plug End	Standard Length	Used with
363	Tinsel Cotton	4	29, 106 & 98	104	6′	137 Plug on 147W or 153W Double Head Receiver and 283W or 386 Transmitter, series connection (see 566)
364	Tinsel Silk	2	29	103	6′	147W Double Head Receivers in series, and 20 or 40 Type Desk Stand
375	Moisture-proofed	4	29 & 98	104	6′	137 Plug for dispatchers head receiver and chest transmitter (see 565)
565	Moisture-proofed	4	69 & 98	104	5'6''	137 Plug for dispatchers head receiver and chest transmitter where 189 receiver is used (see 375)
566	Moisture-proofed	4	69 & 98	104	5'6''	137 Plug on 190 Receiver and 283W Transmitter, 1010A Head Set and 386 Transmitter (series con- nection; see 363)
L2B	Moisture-proofed	2	69	104 & 77	5'6"	189 or similar type receiver
L2C	Moisture-proofed	2	*98	104 & 77	5'6"	386 or similar type transmitter
L6A	Tinsel Silk	6	29 & 98	38 & 104	6′	Operators parallel double head receiver and breast transmitter

^{*}The shanks of the 98 Cord Tip are insulated.


Test Board and Switchboard Patching Cords


			Core	d Tips		
Code	Type and	Conduc-	Rec.	Set	Standard	
No.	Covering	tors	End	End	Length	Used with
*513	Moisture-proofed	1	-	103	2'	116 Plug with test boards.
*519	Moisture-proofed	1	-	103	3'	116 Plug with Test Board 2A, 2B and 3A
525	Tinsel Cotton	2	_	_	3'	Double conductor patching cord with W. U. 3A Plug
526	Tinsel Cotton	2	-	-	5′	For joining two duplex sets terminated at switchboard jack for use as a repeater
527	Tinsel Cotton	2			3'	"Y" patching cord to connect two loops or sets to one loop- ing jack or to transfer a group of loops or sets from one circuit to another
537	Water-proofed	2	30	30	4'	19A Test Set using receiver
584	Water-proofed	2	80	30	4'3"	Two 528 Receivers on 19A Test Set
736	Water-proofed	2	62	62 & 27	6'	17 type Test Sets
747	Water-proofed	2	80	30	4'	19C Test Set for receiver. (528)
P1A	Moisture-proofed	1	75	75	2'	116 Plug for switchboard patching. (Replaces 510)
P1B	Moisture-proofed	1	104	104	2'	47 Plug for switchboard patching. Tip connection only (Replaces 637)
P2A	Moisture-proofed	2	104	104	3'	47 Plug for switchboard patching. (Replaces 516)
P2B	Moisture-proofed	2	101 & 102	101 & 102	3'	110 Plug for switchboard patching. (Replaces 515)
S1A	Moisture-proofed	1	75	93 & 45	6'3"	116 Plug for switchboard. (Replaces 511)
SIB	Moisture-proofed	1	102	93 & 45	6'3"	110 Plug for switchboard. Tip connection only. (Replaces 723)

^{*}External braiding of glazed cotton furnished in red, white, black and green. White will be furnished unless otherwise specified.

CORD TIPS

All cord tips are made of brass





Cord Tips

Code

No.

Tinned. For use on switchboard cords in connection with Nos. 8 and 9 cord fasteners. Replaces No. 42.

Flat, tinned for fastening under binding post or screw. Slotted for No. 12 screw. Re-22 places No. 43.

29 Nickel plated. Ordinarily used on silk covered cords in connection with drilled binding posts. Replaces No. 10. Recommended in place of No. 31.

Nickel plated. Ordinarily used on worsted or cotton covered cords in connection with drilled binding posts. Replaces Nos. 13 and 30 20. Recommended in place of No. 31.

Nickel plated. For use in connection with bracket transmitters. Slotted for No. 12 35

Nickel plated, nickel silver tip with nickel plated brass shank; for use in connection with bracket transmitters. Slotted for No. 8 37 screw. Replaces No. 25.

Tinned, eyelet tip; for use on plug end of switchboard cords. Replaces No. 41. 38

45 Eyelet tip; for use on stay cord end of switchboard cords.

Code

No.

Tinned, eyelet tip; for use on plug end of switchboard cords. Replaces Nos. 23 and 27. Tinned; for use with transmitter cords.

59 Nickel plated, brass spring tip with one-piece

Nickel plated; for use with drilled binding posts where a short tip is required. Replaces No. 60.

Tinned. Slot beveled to admit either a No. 6 62 or No. 8 screw. Replaces Nos. 1, 53, 54 and 58.

Tinned; for use in connection with battery 70 gauges

Tinned; for fastening under binding post or 72 screw. Ordinarily used on transposition leads in subscriber sets.

Open end tinned, with a soldering lug of semicircular section bent up at an angle of 45 degrees. Intended for use as a connection between the ends of the bridle wires and the upper ends of the No. 51A Fuse, both of which are a part of the No. 93A Protector. Tinned; for fastening under No. 116 plug con-

75 necting screw.

Semi-hard rubber sleeve intended to cover the 76 exposed portion of the No. 30 cord tip.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS Cord Tips (Continued)

Code		Code	
No.	The same transfer of the same	No.	
78	Nickel plated; for drilled binding posts. Used on such cords as the No. 572.	98	Solderless, nickel-finished; having two tangs for making contact with tinsel conductor.
79	Tinned; for fastening under binding post or serew.		For use on transmitter cords. Slotted for No. 4 screw. Partially replaces No. 56.
80	Nickel plated; for use with high efficiency receivers.	100	Solderless, nickel-finished; having two tangs for making contact with tinsel conductor.
85	Tinned; for fastening under binding post or screw. Slotted for Nos. 6 or 8 screw.	101	For use on hand set cords. Slotted for No. 4 screw. Solderless nickel-finished; having two tangs
86	Tinned; for fastening under binding post or screw. Slotted for Nos. 6 or 8 screw.	and 102	for making contact with tinsel conductor. For use on ring and tip conductors respec-
87	Tinned; for fastening under binding post or screw. Slotted for No. 4 screw.	102	tively of cords arranged for Nos. 109 and 110 type plugs.
91	Tinned. Slotted for No. 4 screw.	103	Solderless nickel-finished; having two tangs
92	Solderless, nickel finished; having two tangs for making contact with conductors on cords		for making contact with tinsel conductors. Slotted for No. 6 screw.
	having tinsel conductors. Slotted for Nos. 6 or 8 screw.	104	Solderless nickel-finished; having two tangs for making contact with tinsel conductor.
93	Solderless, nickel finished; having two tangs for making contact with conductors on		For use on cords arranged for Nos. 47 and 137 type plugs.
	switchboard cords having tinsel conductors. Used in connection with Nos. 8 and 9 cord	105	Tinned, for use on station cords. Slotted for No. 6 screw.
	fasteners.	106	Semi-hard rubber sleeve intended to cover
97	Tinned; for use on transmitter and hand set	***	the exposed portion of the No. 29 cord tip.
	cords. Slotted for No. 4 screw. Partially replaces No. 56.	109	Solderless nickel-finished; having two tangs for making contact with tinsel conductor.

DESIGNATION STRIPS

No. 8G Designation Strip

These consist of a black finish metal retaining strip.

The No. 8 type has a transparent celluloid strip for protecting a strip of printed figures. Mounting screws are furnished.

The 43 type is arranged to mount a strip of printed figures. Furnished with mounting screws.

The Nos. 90A and 90B have a transparent celluloid strip for protecting a strip of printed figures. Mounting screws are furnished.

The No. 90A is intended to mount on Nos. 184, 185 and 194A Jack Mountings and No. 262 Lamp Socket Mountings. Is arranged to accommodate a designation card for each pair of jacks or lamps.

The No. 90B is intended to mount on Nos. 128 and 129 Jack Mountings and arranged to accommodate a designation card for each pair of jacks.

Code No. 8G	Width	Length Specify	Code No. 8P	Width 7/6"	Length 2213/6"	Code No. 43B	Width	Length 1½"
8H	3/8"	Specify	8R	7/6"	275/6"	43C	39/64"	11/4"
8K	5/8"	61/8"	8S	7/6"	1947/64"	43D	3/4"	11/4"
*8L	7/6"	Specify	*8U	5/8"	Specify	90A	7/6"	151/16"
*8M	3/8"	Specify	**8AB	7/6"	Specify	90B	5/8"	63/6"

^{*}Ends of metal retaining strip are turned up to prevent strips from slipping out.

^{**}Replaces No. 8N.

DESK STANDS



No. 1042AB Desk Stand



No. 1020AL Desk Stand

Desk Stands

The following Bower-Barff finished steel desk stands with the exception of the 1020AL which is a brass desk stand with a black japan finish, are for use with the various telephone circuits, as indicated. The entire terminal plate and switch hook assemblies of these stands may be withdrawn from the stem and base assembly for inspection without disconnecting the cords or interrupting the service in any way. This is accomplished by removing one screw from the bottom of the base plate.

The bottom and edge of the base plate is covered with felt. All current carrying parts are insulated from the frame.

The No. 1020AL Desk Stand is for local and central battery lines.

The No. 1040U Desk Stand is for railway composite service and replaces the No. 1020U Desk Stand.


The No. 1042AB Desk Stand is used in train dispatching circuits, where insulated transmitters and head receivers are required and where a foot switch or a No. 465C Key is used. This desk stand replaces the No. 1020AB.

The No. 1042BR Desk Stand is used in train dispatching circuits where it is desired to insulate the primary circuit from the secondary to prevent noises from the ringing selector. Replaces 1020BR.

The No. 1142AB Desk Stand is for use with the Nos. 501A and B Desk Set Boxes at way stations of train dispatching lines. This desk stand replaces the No. 1120AB Desk Stand.


Code	Transmitter	Receiver	Cords	Cords	Cords
No.	No.	No.	Receiver	Transmitter	Desk Stand
1020AL	323	144	R2A-2½'	2-T1A-91/8"	D3A-5½'
1040U	323	144	R2Y-21/2'	2-T1A—91/8"	D4E-51/2'
1042AB	349	186	R2U-2½'	2-427-97/8"	D3D-5½'
1042BR	349	186	R2U—2½′	2-427-97/8"	D4G-8'
1142AB	349	189	R2U-21/2'	2-42797/8"	D3D— $5\frac{1}{2}$

Desk Stands (Continued)



Desk Stands-Replacement Parts

*Replacement part numbers for the Handle and Base of the No. $1020\mathrm{AL}$ Desk Stand are as follows. Handle P-98886, Base P-98891.



Contact Springs-Replacement Parts

Note: The receiver, transmitter, etc., are given in the code number listings of the desk stand. (Page 45.)

Note: The rec	ceiver, transmitter, etc., are given ir	the code number ustings of the desk stan	(1. (Page 45.)
	Note 1	Note 2	Note 3 Terminal Plate
	Hook	Laigholder	Assembly
1020AL	P-98883	P-98862	P-98247
1040U	P-97343	P-97372	
1042AB	P-97348	P-97374	P-98247
1042BR	P-97348	P-97842	
1142AB	P-97348	P-97374	P-98247

DESK SET BOXES

(Subscriber Sets)



No. 295AJ Desk Set Box



No. 300 Type Desk Set Box



No. 502A



No. 501A Desk Set Box Cover Removed

Dispatchers' Stations Desk Set Boxes

The following desk set boxes are used on train dispatching circuits in dispatchers' telephone sets, with head set telephone equipments consisting of the No. 386 Transmitter and the No. 189 Receiver:

Code No.	Condenser No.	Induction Coil No.	Remarks
295AJ	*138A	29	Replaced by No. 502A for new installations
502A	*1—No. 149A and 2—No. 21AK	43 and 44	Replaces No. 295AJ for new installa- tions. See page 15 for open view

*When ordering this condenser to replace 21 type used in earlier equipment see notes under "Condensers" for type of bracket or adapter required.

Way Station Desk Set Boxes

The following desk set boxes are used on train dispatching circuits in way station telephone sets with desk stand, Flexiphones or transmitter arm, equipped with No. 349 Transmitter and No. 189 Receiver.

The No. 501B Desk Set Box, together with the No. 501A, replaces the No. 295AK on new installations.

Code No.	Retardation Coil	Condenser No.	Induction Coi	l No. Remarks
295AK Spec. 300K per D-11275	51A 51A	*138A *138A	29 29	Used with earlier type equipment Also equipped with No. 38BG Ringer and one No. 48A Hand Generator
501A		*142B	42	Equipped with one No. 1014A Push Button
501B		*142B	42	Arranged for No. 3C Foot Switch

*When ordering this condenser to replace 21 type used in earlier equipment see notes under "Condensers" for type of bracket or adapter required.

Composite Telephone Desk Set Box

The following desk set box is for use with the No. 1040U Desk Stand for desk type composite telephone set, for same class of service as the No. 1312A Telephone Set:

Code	Retardation	Condenser	Induction	Interrupter	Howler
No.	Coil No.	No.	Coil No.	No.	No.
311A	12G	21D, H & U	-5	P-101594	1C

Desk Set Boxes (Continued)

Magneto Telephone Desk Set Boxes


The following magneto telephone desk set boxes are for use where code ringing is employed, for the various line conditions as indicated.


The Nos. 300M and N Desk Set Boxes are the same as the Nos. 300K and L respectively, except having a condenser in series with the receivers.

Code No.	Ringer No.	Resistance	Condenser No.	Induction No.	Hand Generator No.	Remarks
300K	51BG	2500 ohms		13	48A	For heavily loaded lines
300L	51FG	1620 ohms		13	48A	For moderate loaded lines
300M	51FG	1620 ohms	*149A	13	48A	For moderate loaded lines
300N	51BG	2500 ohms	*149A	13	48A	For heavily loaded lines
315H	51AG	1020 ohms		13	22A	For light loaded lines

*When ordering this condenser to replace 21 type used in earlier equipment see notes under "Condensers" for type of bracket or adapter required.

FUSES





Non-Alarm Type

These phenol fibre fuses will mount on one inch centers by means of Fuse Posts or individual porcelain mountings as in the No. 62D Protector. The overall dimensions are: length 1½", width ¾".

The current carrying capacities and operating current values are given in the table below. In ordering, it is necessary that both the code number and rated capacity be given.

	Rated	Operates in	Tern	ninals
Code No.	Capacity Amperes	Less Than One Minute on Amperes	Finish	Slotted for Screw No.
24A	{11/2	1	Tinned Tinned	10 10
	1/3	1	Copper	6
24B	$\begin{cases} \frac{1}{2} \frac{1}{3} \end{cases}$	$\frac{2}{3}$	Copper Copper	6
210	(3	4	Copper	6
24C	2	ō	Copper	10

Indicator Alarm Type

These phenol fibre fuses have the fuse wire so mounted that one end is fastened to a coiled spring and the other to a flat spring on the opposite side of the base. The terminal ends have a copper tinned finish. When the fuse operates, the coiled spring causes a glass bead to be brought into a prominent position where it acts as a visible indication of the blown fuse. The mounting of the fuse may be so arranged as to cause the flat spring on the bottom of the fuse to make contact with an alarm circuit when the fuse wire is backen. is broken.


Fuses, Indicator-Alarm Type (Continued)

No. 35 Type Fuses may be mounted as in the No. 62C Protector or by means of Fuse Posts. They operate on currents fifty per cent in excess of those for which they are rated.

When ordering, both the code number and rated capacity should be specified.

		Ope	erates On		49476	7.75
Code No.	Rated Amperes	Amperes	In Less Than	Color of Bead	Slotted For Screw	Mounting Center
35A	1 1/3	2	1½ Min.	White	No. 10	11/4"
35B	113	2	11/2 Min.	White	No. 6	11/4"
35C	2	3	3 Min.	Yellow	No. 10	11/4"
35F	1/2	3/4	11/2 Min.	Red	No. 10	11/4"
35G	3	$4\frac{1}{2}$	5 Min.	Blue	No. 6	11/4"
35H	5	$6\frac{1}{2}$	5 Min.	Green	No. 6	114"

Tubular Fuses



These fibre shell type fuses are carefully made from especially selected materials. The use of lead fuse wire prevents the possibility of overheating the shell. These fuses will carry their rated currents indefinitely without injury and will act reliably on one and one-half times their rated current values. Fuses of the same code number and rated capacity will give consistent performance as to rated and operating current values.

Code No.	Rated Capacity Amperes	Used With
7A	1 to 7 as specified	Nos. 61, 77, 1074A, 1075A and 1078A Protectors
7T	7	"B" Cable Terminals and Fuse Chambers
11C	7	Nos. 58AP and 1079AP Protectors
11D	7	No. 25 Protector Mounting (No. 12 Type Protector)

PORCELAIN SHELL FUSES



No. 47A

In certain cases where lines are exposed to high potential crosses, it is advisable to insert a fuse in the drop wire near the cross arm in addition to the No. 60AP Protector installed at the telephone station. In such cases the No. 47 Type is recommended; the procelain shell used on this type of fuse will break upon the passage of a large current or upon the continued flow of smaller current. The wires in which the fuses are inserted will fall apart as the shells break, and the line end of the wire, being close to the cross arm, will not come in contact with objects on the ground. These fuses operate on one and one-half times their rated capacity.

Code No.	Capacity
47A	7 amperes
47B	14 amperes

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS GENERATORS








No. 29E

The following generators are used with desk set boxes and telephone sets as indicated. All of these generators are open circuit type. For repair part information on these generators refer to Telephone Apparatus and Supplies Catalog.

Code No.	No. of Bars	Voltage and Current	Used With
22A	3	60 AC	No. 303A, No. 315H Desk Set Boxes, No. 1317AH, No. 1331E and F Telephone
			Sets
29E	2	65 AC	No. 1375B and No. 1398A Telephone Sets
29F	2	60 AC	Nos. 1017D and E Test Sets
48A	5	80 AC	Nos. 300K, L, M, N Desk Set Boxes, Nos. 1317P, S, W, AD, AE, AW, BU, No.
			1330E and F Telephone Sets
48C	5	80 AC	Nos. 1278G and H, No. 1336F and H Telephone Sets
48R	5	80 AC	No. 1317BK Telephone Set
50A	3	60 AC	Magneto Telephone Sets where a more efficient generator than the No. 22
			Type is required
50F	3	60 AC	Nos. 1317CG, CN, CP, CS Telephone Sets








Hand Generator Box

A hand generator box consists of a generator mounted in an oak cabinet having a hinged cover. The leads from the generator are connected to terminals mounted close to the inside edge of the box.

Code			———Dir	nensions of	Box
No.	Generator	Current	Width	Depth	Length
299F	48.1	Alternating	8"	6''	9"

GONGS AND GONG MOUNTINGS



Code No.	Diameter	Height	Metal and Finish	Where Used
3	2"	15/8"	Metal, Nickel Plated	Cow gong Tea gong. (A. & M. Only, 31A, 32A and 33A Recommended)
10	215 ₃₂ "	111/16"	Metal, Nickel Plated	
20	3"	1" 134" 1" 11332" 5164"	Brass, Black Finish	1336 Telephone Set
23A	8"		Steel, Galvanized	292 Type Extension Bell
26A	3"		Brass, Black Finish	1317 Type Telephone Sets
28A	6"		Steel, Galvanized	392 Type Extension Bell
29A	2½"		Brass, Black Finish	Telephone Sets
31A 32A 33A	$2\frac{1}{2}''$ $2\frac{1}{2}''$ $2\frac{1}{2}''$	51/64" 51/64" 51/64"	Brass, Black Finish Brass, Black Finish Bell Metal, Black Finish	Differs from the 29A, in that each has a different tone intended for use where a number of telephones are placed close to each other Recommended in place of Nos. 3 and 10

GONG MOUNTINGS


Each gong mounting consists of a pair of gong posts or gong post extenders together with the necessary mounting screws.

Code No.	Length of Post or Extender	Used With Gongs	Finish
3	111/6"	Nos. 3 and 10	Nickel plated
7	1 11 16'' 13 16''	Nos. 3 and 10	Brass

GONG NUTS

			 Dimensions – 		
Code No.	Description	Thread	Diameter	Height	Finish
P19097	Knurled thumb nut used with No. 3 Gong Mounting	10-32	7/16"	1/2"	Nickel plated

HAND SETS, HEADSETS AND HOWLERS Hand Sets



				Cords	D 1 D 44
Code No. 1001C	Transmitter 285	Receiver 131	Code No. 366	Length 6' (water-proof)	Push Button Spring Combination 2 make
1001H	244	131	422	5'2" (water-proof)	2 make
1004B	244 per D-51130	131 per D-51129		.,,	2 make

Principal Use
Used with Nos. 1330 and 1331
Portable Magneto Telephone Sets
Used with No. 1375B Portable Magneto Telephone Set
Train Dispatching Circuits

HEADSETS


Code No.	Description	Use
1010A	Consists of two 565A Receivers assembled on a 1C Headband. This headset replaces the 190 Receiver	For use in train dispatching way stations
1010B	Consists of one 565A Receiver assembled on a 1C Headband. This headset replaces the 191 Receiver	For use in train dispatching way stations

HOWLERS

Howlers consist of a special bipolar receiver with an adjustable diaphragm and a horn mounted on a wooden base. They are designed for use in calling in signal circuits.

Code No. 1C Approximate Total Resistance 1000 ohms Approximate Overall Dimensions $3^{1}\%6'' \times 6\%6'' \times 614'''$

INDUCTION COILS AND INTERRUPTERS Induction Coils







No. 13 Induction Coil

Induction Coils and Interrupters (Continued)


No.	Size	Used In
5	429/2" x 19/6"	Nos. 1312A, 1314A, 6023A Telephone Sets and 311A Desk Set Box
13	3¼" x 1"	Nos. 300K, L, M, N and 315H Desk Set Boxes, 1317P, S, AH, BK, CN, CR, CP, CS and CG Telephone Sets, 1017B, C and E Test Sets
29	3¼" x 1"	Nos. 295AJ, AK and special 300H and K Desk Set Boxes, 1278G, H, 1293AD, AE, AK, AL, 1317W, AD, AE, AW, 1330E, F, 1331E, F, and 1332A, and E Telephone Sets
30	41/4" x 13/8"	No. 1336H Telephone Set
31	3½" x 1"	No. 1375B Telephone Set. Moisture-proofed No. 13 Coil
32	3¼" x 1"	No. 1336F Telephone Set, and No. 1004B Hand Set. Moisture-proofed No. 29 Coil
42	41/4" x 123/32"	No. 501 Desk Set Box for way stations, No. 1317 BU Telephone Set
43	41/4" x 123/32"	No. 502 Desk Set Box in transmitter circuits
44	41/1" x 123/2"	No. 502 Desk Set Box in receiver circuits

Interrupters



No. 62A Interrupter





No. 84H Interrupter

Open View

Code No.

Description


- An electrically operated interrupter for furnishing alternating current for Railway Telephone Service from a direct current source. Especially adapted for use in block towers, on yard lines, etc., where several telephones are connected to the same line. Operates on five cells of dry battery and only when battery key is closed.
- An electrically operated automatic pole changer producing alternating current from a source of direct electromotive force for ringing purposes. Operates on one Edison Type S No. 502 Cell. Ringing battery varies according to line conditions.
- 84.J Same as 84H excepting that it will give pulsating currents. Ringing battery varies according to line conditions.
- A circuit interrupter attachment used in the No. 1017E Test Set. The attachment is associated with the generator to provide high frequency ringing current for signalling on composite lines and consists of:
 - 1-Commutator with bracket and mounting screw
 - 1-Switch with mounting screws
 - 1-No. 21K Condenser with mounting strap and screws
 - 1-No. 3 Binding Post with mounting screws
 - 1-8-inch standard wire transposition lead
 - 1-Diagram of connection
- P-101495 High frequency interrupter used with No. 5 Induction Coil for signalling on composite circuits.

 Furnished with Nos. 1312A, 1314A and 6023A Telephone Sets.

JACKS

Singly Mounted-Welded Frame Jacks

The following singly mounted, electrically welded frame type jacks replace the corresponding punched frame types as indicated in the code number listings. The terminals of the jacks are regularly arranged to accommodate two No. 19 B & S gauge wires unless otherwise specified. Mounting screws are furnished.



Singly Mounted - Welded Frame Jacks (Continued)

Code letters A, B, C and D of the code numbers of jacks listed below indicate the number of mounting lugs (single or double) and their arrangement with respect to the plane of the springs (horizontal or vertical) as illustrated in figures A, B, C and D on the preceding page.

JACKS FOR USE WITH PLUGS Nos. 47, 116, 137, 144, 151, 153D, 154, 217, 220, 221, 241 AND 246

	Dimen-			1		Dimen-			
	sions	Mountin	g Centers,	Re-				g Centers,	Re-
Code	Page 54		ches	places	Code	Page 54		ches	places
No.	Fig No	Horizont	al Vertical	Jack No	No.	Fig No	Horizont	al Vertical	Jack No.
(a) 215A	1	5.6	7/8	215	(h) 227C	9		*	206
(a) 215B	1	5/8 5/8	11/8		(i) 230A	ĩ	5%	7%	
	1	7.2	5%	111	(i) 230C	1	7%	7/8 5/8	146
	1	58	72	216	(i) 231A	i	5 8 5 8 7 8 5 8	7%	
	1	58	118	210	(j) 231B	1	5%	11%	
1-1	1	78	1 78	204	(j) 231B	1	78	5%	147
	1	5.8	7.8	217	(j) 231D	1	11/8	58	168
(b) 217A	1	78	78		232A	1	5.8	78	
(b) 217C	L	1/8	78	209	232B	1	58	11/8	
(c) (b) 217E	1	28	78	218	232B 232C	1	78	178	148
218A	1	2/8	118	218	232D	1	118	5 8	169
218B	1	28	1 28			1	1/8	78	109
218C	1	28	28		(k) 232E	1	28	78	
(d) 218E	1	7/5/7/5/6/6/6/6/6/6/6/6/6/6/6/6/6/6/6/6/	78	010	233A	1	58	118	* • 104
219A	1	2/8	11/8	219	233B	1	78	1 /8	140
219B	1	2/8	11/8	122	233C	1	1/8	28	149
219C	1	1/8	5/8 5/8 5/8 5/8 5/8 11/8	155	233D	1	11/8	78	170
219D	1	11/8	2/8	175	(L) 234A	1	28	8	iżi
220A	1	3/8	1/8	220	(L) 234C	1	1/8	2/8	
220C	1	/8	2/8	154	(L) 234D	1	1 28	28	172
220D	1	11/8	2/8	176	(j) 235A	1	28	28	:::
221A	1	2/8	1/8	221	(j) 235C	1	. 18	28	153
221B	1	5/8	11/8		(j) 235D	1	11/8	28	174
221C	1	7/8	5/8	152	236A	1	2332	1/8	
221D	1	11/8	2/8	173	(m) 236B	1	23/32	11/8	100
(e) 223A	1	5/8	7/8	223	236C	1	1/8	2/8	189
(e) 223B	1	5/8	11/8		236D	1	11/8	2/8	188
(f) 225A	1_	5/8		225	237A	1	2/8	1/8	27.5
(f) 225B	1	5/8	11/8		237C	1	7/8	5/8	185
(f) 225C	1	5/8	*	156	(n) 281A	2	5/8	7/8	• • •
(f) 225D	1	5/8	118	177	(n) 297A	1	5/8	7/8	
(g) (f) 225E	1		*	229A	303A	1	5/8 5/8 5/8 7/8	148888888888888888888888888888888888888	
(a) 226A	1	5/8	*	226	(o) 303AK	1	5/8	3/8	
(a) 226C	1	5/8	*		361C	1	7/8	5.8	
(h) 227A	2	5/8	*	227					
,		, .							

- (*) Vertical center 5%" when mounted in double horizontal rows with lugs in opposite directions and 7%" when mounted in double horizontal rows with lugs in the same direction.
- (a) The terminal of the tip springs is arranged to accommodate two No. 16 B & S gauge wires.
- (b) The terminal of the tip spring and the terminal of the spring which makes contact with it are arranged to accommodate two No. 16 B & S gauge wires.
- (c) Same as No. 217A Jack except it has a nickel-silver sleeve.
- (d) Same as the No. 218A Jack except equipped with platinum contacts.
- (e) Same as the No. 221 type except the terminal of the tip spring is arranged to accommodate two No. 16 B & S gauge wires.
- (f) The terminals of all springs are arranged to accommodate two No. 16 B & S gauge wires.
- (g) Same as the No. 225A Jack except equipped with platinum contacts.
- (h) The terminals of the tip and ring springs are arranged to accommodate two No. 16 B & S gauge wires.
- (j) Local contacts not designed for use in talking circuits.
- (k) The same as the No. 232A Jack except equipped with platinum contacts.
- (L) Normally closed contacts are not designed for use in talking circuits.
- (m) Cannot be used with Nos. 137, 152, 154, 209, 217, 218, 220, 241, 246 and 249 Plugs.
- (n) Heavily insulated jacks.
- (o) Same as No. 303A Jack except equipped with platinum contacts.

Singly Mounted-Welded Frame Jacks (Continued)

JACKS FOR USE WITH No. 109 TYPE PLUG

Code	Dimensions Page 54	——Mounting Cen	ters, Inches—	Replaces
No.	Fig. No.	Horizontal	Vertical	Jack No.
246A	3	5/8	7/8	126
246B	3	5/8	11/8	
(a) 246E	3	5/8	7/8	
248A	3	5/8	7/8	134
248B	3	5/8	11/8	
248D	3	11/8	5/8	
(b) 248E	3	5/8	7/8	
249A	3	5/8	7/8	143
249B	3	5/8	11/8	

- (a) Same as the No. 246A Jack except equipped with nickel-silver sleeve.
- (b) Same as the No. 248A Jack except equipped with nickel-silver sleeve.


JACKS FOR USE WITH Nos. 110, 150, 184, 202 AND 213 TYPE PLUGS

Code No.	Dimensions Page 54 Fig. No.	Ind	g Centers, ches al Vertical	Replaces Jack No.	Code No.	Dimensions Page 54 Fig. No	Mounting	g Centers, ches al Vertical	Re- places Jack No.
238A	2	5/8	7/8	159	243B	2	3/4	11/8	184
238B	2	3/8	11/8	178	245A	2	29/32	7/8	
238C	2	7/8	5/8	274	245B	2	29/32	11/8	
238D	2	11/8	5/8		245C	2	29/32	5/8	
(a) 238E	2	5/8	11/8		(d) 267A	2	11/16	5/8	
239A	2	5/8	7/8	160	280A	2	7/8	7/8	
239B	2	5/8	11/8	179	280B	2	7/8	11/8	
239C	2	7/8	5/8	260	280C	2	7/8	5/8	
239D	2	11/8	5/8		284A	2	1	7/8	
(b) 239E	2	5/8	7/8		284B	2	1	11/8	
240A	2	3/4	7/8	161	285A	2	13/16	7/8	
240B	2	3/4	11/8	180	285B	2	13/16	11/8	77.
240C	2	7/8	5/8		285C	2	7/8	5/8	
241A	2	3/4	7/8	162	289B	4	15/16	11/8	
241B	2	3/4	11/8	181	290B	4	15/16	11/8	
241C	2	7/8	3/8		291B	2	1	11/8	
241D	2	11/8	5/8		293B	2	15/16	11/8	
242A	2	3/4	7/8	163	300A	2	5/8	7/8	282
242B	2	3/4	11/8	182	360A	2	23/32	7/8	
242C	2	7/8	5/8	259	387B	2	13/16	11/8	* * *
(c) 242CK	2	7/8	5/8		387D	2	11/8	5/8	
243A	2	3/4	7/8	165	- 1				

- (a) Same as the No. 238B except equipped with a nickel-silver sleeve.
- (b) Same as the No. 239A except equipped with a nickel-silver sleeve.
- (e) Equipped with platinum contacts.
- (d) Heavily insulated jack.


Jacks (Continued)

Singly Mounted-Miscellaneous Types



Code No. Description


- 77 Operator's telephone set. Makes one separate contact when a No. 148 Plug is inserted; has tip, ring and sleeve terminals.
- 78 Same as No. 77 Jack, except that the make contact is omitted. Diameter of mounting plate 11/16 inches.
- 389A-3 This jack is intended for use in locations where it is desirable to move a desk stand from place to place. The No. 273A-3 Plug is used with this jack; it is provided with tip, ring and sleeve connections. The cover is 1½ inches square and 1 inch deep, and is finished black. The base and cover are slotted to allow wires to be brought in from wire moulding.



The Nos. 200, 203, 208 and 224 are fibre insulated jacks having micanite bushings. They will mount on any thickness of wood from ¾ to ¼ inch, the jack shank being threaded and the jack held in place by means of a nickel finished nut.

Code	Mounting Cer	nters, Inches	Used with	Used in
No.	Horizontal	Vertical	Plugs	Jack Boxes
200	15/16	1	1A, 47 & 116	
203	15/16	11/4	1A, 47 & 116	
208	15/16	11/8	1A, 47 & 116	385, 386 & 389
224	15/16	11/2	1A, 47 & 116	385, 386 & 389

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS Dispatcher's Station



- 1. No.160B Selector Apparatus Case
 - 1.1 No. 221JB Relay 1.2 No. 152A Retardation Coil 1.3 No. 63F Resistance 1.4 No. 138B Condensers (4) 1.5 No. 63C Resistance

 - 1.6 No. 138A Condenser1.7 No. 26A Telegraph Relay


 - 1.8 No. 141A Condenser
 - 1.9 No. 2B Circuit Breaker
- 1.10 No. 709 Trumbull Switch DPST
- 2. Nos. 60A, B, C, D or E Selector Key Cases 2.1 Nos. 60A or B Selector Keys

- No. 50A Selector Key Spaces, or Nos. 61A or B Selector Key, or Nos. 62A or B Selector Key, or Nos. 63A or B Selector Key
- 3. Use when Transformer Circuit is required by connecting the "T" Leads to the "L" Leads 3.1 No. 341 Transformer or
 - No. 70A Repeating Coil 3.2 DM-2000 Ward Leonard
 - Resistance 3.3 No. 160B Condensers or No. 138B Condensers as required
- 4. No. 502A Desk Set Box 4.1 No. 43 Induction Coil


- 4.2 No. 44 Induction Coil 4.3 No. 140B Condenser 4.4 No. 141B Condenser 4.5 No. 141A Condenser

- 5. No. 345A Jack Box
- 6. Dispatcher Head Telephone Set
 6.1 No. 137 Plug
 6.2 No. 565 Cord
 6.3 No. 386 Transmitter
- 6.4 No. 189 Receiver 6.5 No. 3A Transmitter Attach-
- 7. No. 6000A Key or No. 1B Foot Switch

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS Way Station




Singly Mounted-Miscellaneous Type Jacks (Continued)



Replacement Parts

		No. 200 Jack				No. 203 Jack	
Piece Part No.	No. Req.	Material	Name	Piece Part No.	No. Req.	Material	Name
P128224	1	Brass	Sleeve Nut	P128224	1	Brass	Sleeve Nut
P112770	1	Brass	Washer	P112770	1	Brass	Washer
				P112721	1	Micanite	Bushing
P112724	1	Ger. Silver	Tip Spring	P112720	1	Ger. Silver	Contact Spring
P112725	1	Ger. Silver	Contact Spring	P112719	1		Contact Spring & Stud
P112726	1	Brass	Stop Spring	P112724	1	Ger. Silver	Tip Spring
P112722	1	Brass	Frame	P112725	1	Ger. Silver	Contact Spring
P161576	6 &	Phenol		P112726	1	Brass	Stop Spring
			2 1	P112722	1	Brass	Frame
	As Req.	Fibre	Insulator	P118464	2	Brass	R.H.M. Screw
P112729	2	Micanite	Bushing	P112717	2	Micanite	Bushing
P118460	2	Brass	R.H.M. Screw	P112727	1	Ger. Silver	Terminal
F118460	4	Drass	n.n.w. screw	P161576	10 &	Phenol	
P112727	1	Ger. Silver	Terminal		As Req.	Fibre	Insulator

Singly Mounted-Miscellaneous Type Jacks (Continued)



Replacement Parts

		No. 208 Jack		1		No. 224 Jack	
Piece	No.			Piece	No.	20	
Part No.	Req.	Material	Name	Part No.	Req.	Material	Name
P124438	1	Brass	Sleeve Nut	P124438	1	Brass	Sleeve Nut
P124439	1	Brass	Washer	P124439	1	Brass	Washer
P124440	1	Brass	Frame	P124440	1	Brass	Frame
P124435	1	272 (4.5.0)	Contact Spring	P129775	1	Micanite	Bushing
P124433	1		Contact Spring				(Separator)
0.	1	TT 1 TO 11		P129782	1		Contact Spring
P124601	1	Hd. Rubber	Separator	P129780	1		Contact Spring
P124436	1	Nickel Silver	Tip Spring	P129781	2		Contact Spring
P112726	1	Brass	Stop Spring	P129779	1	400	Tip Spring
P124454	2	Micanite	Bushing	P129778	1	Brass	Terminal
P210776	2	Steel	R.H.M. Screw	P129776	2	Micanite	Bushing
P131035	1	Nickel Silver	Terminal	P118469	2	Brass	R.H.M. Screw
P161576	9 &	Phenol	- 0	P112727	1	Ger. Silver	Terminal
L 1019/0	formal Parado	71 70 1 100 1	Insulator	P161576	13	Phenol Fibre	Insulator
	As Req.	Fibre		P129777	1	Brass	Terminal
P124437	2	Brass	Terminal	P124437	2	Brass	Terminal
P129848	2	Brass	Washer	P113883	4	Brass	Button H.M.
P113883	2	Brass	Button H.M.				Screw
			Screw	P129848	4	Brass	Washer
				111			

Singly Mounted-Miscellaneous Type Jacks (Continued)



No. 186 Jack





No. 186 Jack (open)

Code No.

Description

186

A jack designed for mounting on poles as a means of connecting a portable telephone to the line. Has a cast frame and cover; black rust-proof finish. The plug hole is protected against insects by covering with spring flap; equipped with:

Two 500 volt, 1 ampere, Gem fuses

Two No. 1 Protector Blocks

Two No. 2 Protector Blocks

Two No. 3 Protector Micas

A lock will be supplied when specified as a separate item. This jack is used with the No. 146 Plug.

187 Same as No. 186 Jack except that it is not equipped with protective apparatus.


JACK BOXES



No. 60A JACK BOX

The No. 60A Jack Box, as shown above, equipped with ten No. 60A or No. 60D Combined Jack and Signals is for use at way stations where it is desired to connect a single telephone set to one of several telephone lines. Incoming calls are indicated visually by means of drop signals and also, if desired, announced audibly by a buzzer.

Jack Boxes (Continued)



Schematic of No. 60A Jack Box

No. 60A Jack Box (Continued)

The operator's telephone set is put into circuit by inserting a plug into the jack indicated by the fallen shutter. The signal is restored automatically to its original position by this operation.

In addition to the combined jack and signals, the jack box contains a ringing key, buzzer, termina plate, and a solid plug attached to the box by a cord.

The cabinet is made of brass finished in black and is $10'' \log_{10} 7\frac{1}{2}''$ high, and $7\frac{1}{2}''$ deep.

The No. 60A Combined Jack and Signals have a low resistance of 82 ohms for use on train lines and the signals should be connected in multiple with the ringer in the selector set as shown for Signal 5 of the above schematic. Whenever the selector is operated to its local ringing position, the No. 60CG Ringer in the selector set and the associated signal in the jack box will both be operated.

The No. 60D Combined Jack and Signals have a resistance of 1000 ohms and should be connected directly to a local or block line as shown for Signal 1 in the above schematic. In this case the signal will be operated directly by a hand generator or a ringing interrupter over the line wires and the buzzer in the local circuit of the signal contact will follow the code ringing.

The winding of each signal is brought out to two separate terminals on the terminal plate in the top of the box so that the signals may be connected to the local circuit of the selector sets on train and message lines that are part of the phantom circuit. The connections from the train and message wires to the jack springs are open when the plug is not in the jack and thus cause no interference on the phantom circuits.

The ringing key has three positions. The normal position is for incoming calls and the talking position. When the key handle is operated down to the "R" position, the outgoing ringing circuit is completed through the jack springs of the jack in which the plug is inserted to the corresponding line. Also the circuit to the operator's telephone set is opened. When the key handle is operated to the "C" position, the code ringing circuit to the buzzer is opened. The key is locking in the "C" position and non-locking in the "R" position.

Provision is made in the wiring so that on lines, where ringing is not desired, this may be accomplished by disconnecting the black wires from the bottom terminal in the jack spring pileup associated with that line.

When less than full capacity of ten combined jacks and signals is required, the unequipped positions are fitted with No. 70A Apparatus Blanks. However, in all cases, the jack box is furnished completely wired for ten combined jacks and signals.



No. 345A Jack Box



No. 385A Jack Box

NO. 345A JACK BOX

Oak box primarily for use in train dispatching circuits at dispatcher's office and is so arranged that two headsets can be connected to the line at the same time.

Equipped with one No. 30 Jack Mounting, two No. 237C Jacks and two No. 221C Jacks.

Approximate dimensions, length 51/2", width 43/4", height 2".

Jack Boxes (Continued)

Cordless Jack Boxes

Oak boxes with nickel trimming for miscellaneous purposes. Each box is equipped with hinge cover and a No. 1A Plug attached by means of a dummy cord. The No. 389 Type is split and hinged on a line midway between the upper and lower jack levels.


Telephone Jack Boxes Nos. 385A, B, 386A, B, C, and 389A are so arranged that one telephone line can be terminated in each jack. A telephone set can be connected to any of these lines by inserting the plug in the proper jack.


Telegraph Jack Boxes Nos. 385C, D, 386D, E, F, and 389B are so arranged that one telegraph line can be looped through each jack. Resonator set can be connected to any of these lines by inserting the plug in the proper jack. When this is done, the calling set is disconnected.

Code	Line		Equipped	Name of the last		Dimensions, Inches	D = 43
No.	Equipment	Capacity	with Jacks	Service	Width	Height	Depth
*385A	2	3	208	Telephone	41/2	23/4	61/4
385B	3	3	208	Telephone	41/2	23/4	614
*385C	2	3	224	Telegraph	41/2	23/4	614
385D	3	3	224	Telegraph	41/2	234	614
*386A	4	6	208	Telephone	7%	234	61/4
*386B	5	6	208	Telephone	7%	234	614
386C	6	6	208	Telephone	73/6	234	614
*386D	4	6	224	Telegraph	75/6	234	61/4
386E	5	6	224	Telegraph	75/16	23/4	61/4
386F	6	6	224	Telegraph	73/6	23/4	61/4
389A	12	12	208	Telephone	79/6	45/8	614
389B	12	12	224	Telegraph	75/16	458	614

^{*} No. 17C Apparatus Blank, illustrated in the center jack position on the cut of the No. 385A Jack Box, is furnished in all unequipped positions.


Combined Jacks and Signals SHUTTER TYPE





Combined Jacks and Signals (Continued)

Code	D. C. Leese	M	11J W:41
No.	Resistance	Mounting	Used With
22C	350	Single or 5 per strip.	Special jack boxes.
60A	82	Single or 5 per strip.	No. 60A jack box.
60D	1000	Single or 5 per strip.	No. 60A jack box.



Replacing Jack Sleeve for Combined Jacks and Signals

The above illustration outlines the parts necessary for replacing the sleeve assembly of the Combined Jacks and Signals.



Jack Mountings

Code	Description	Dimensions, Inches	Used With
No.	Description	Thenes	Cod with
30	Composition mounting for 4 Nos. 99, 185, 220, 221 or 234 Jacks.	$3\frac{3}{4}$ x $1\frac{1}{4}$ x $\frac{5}{8}$	Dispatcher's telephone equipment. In No. 345A Jack Box.
80	Composition mounting for 2 Nos. 99, 185, 220, 221 or 234 Jacks.	23/8x11/4x5/8	Head Telephone Sets with No. 137 Plug

KEYS







No. 465 Type Key

Code		
No.	Description	Used
92A	Single mounted push button key. Non-locking. For 1½ inch shelf. Makes two and breaks two contacts.	As a ringing key.
92B	Same as No. 92A except that it is a locking key.	As a listening key.
136B	A horizontal switching key with two sets of springs. Locks in both positions.	To connect one telephone to any one of three lines. Part of the No. 6000B Key.
272A	Single mounted locking key. Makes two and breaks two contacts. Key is operated by a turning movement of button. For 5_8 and $1\frac{1}{4}$ inch shelf.	In Nos. 1A and 1B test boards.
375A	Push button ringing key; makes two and breaks two contacts and is non-locking.	As part of the No. 6002C Key.
377A*	Plunger type key used with key lever. Makes two contacts.	In No. 6000A Key.
378A*	Plunger type key used with key lever. Makes two and breaks two contacts.	Used as a listening key.
392A*	Plunger type key used with key lever. Makes four and breaks four contacts.	In No. 335A Blocking Set.
393C	Non-locking, push button key, makes three contacts, breaks two contacts.	In the No. 6003A Key.
465A	Push button key mounted in an oak box. Makes three and breaks one contact. Dimensions: 411 k x 31 k x 113/22 inches.	In old type way station telephone circuits (non- insulated transmitter) and No. 6023A Telephone Set.
465C	Push button type key mounted in an oak box. Dimensions 411% x 31% x 115% inches. Makes two and breaks one contact.	In train dispatching circuits for way-station opera- tors to cut in transmitter.
465D	Push button key, similar to the No. 465A, except that it makes one and breaks one contact.	With the No. 1317 Telephone Sets.
465E	Similar to No. 465C, except makes three and breaks two contacts.	In train dispatching circuits for way stations with No. 501B Desk Set Boxes.

Note. When ordering keys Nos. 92A, 92B, or 272A unmounted, specify the thickness of the shelf or table top in which key is to be mounted.

^{*}Are either locking or non-locking, depending on the type of lever used.

Keys (Continued)



1

No. 6A Key Lever



No. 6000A Key

No. 6000B Key



No. 6017 Type Key



No. 6017A



No. 6017B



No. 6017C

Code No.	
6000A	

Description

Plunger type key. No. 377A with No. 6A Key Lever mounted in a box 4¾ x 3¾ x 11¾ ins.

6000B

Consists of No. 136B Key mounted in a No. 334 Key Mounting. Dimensions approximately 61/4 x 31/4 x 2114 ins.

6017A

Consists of a 2BF Key Unit and connecting block mounted in a black finished metal box. Dimensions of box 61/2 x 311/2 x 13/2. Spring combination locking-locking.

6017B

Consists of a 2GP Key Unit and connecting block mounted in a black finished metal box. Dimensions same as 6017A. Spring combination locking.

6017C

Consists of a 2F Key Unit and connecting block mounted in a black finished metal box. Dimensions same as 6017A. Spring combination non-locking. Used

In dispatcher's telephone circuit.

Where it is desired to connect one telephone set to any one of three separate lines.

Intended for use as a switching key to connect a telephone instrument on either one or both of two lines.

Intended for use as a switching key to connect a telephone instrument on either one or two lines.

Intended for use as a ringing key at sub-station.

Key Levers

Code No.	Operated Position of Lever
6A	Vertical
6B	Vertical
14A	Horizontal
23A	Horizontal

Used with lever type keys. Black handle. Locking.

Same as No. 6A, except red handle. Otherwise same as No. 6A.

Switch key. Locks in all positions. Normally all contacts are open. When thrown to the left the inner contacts are closed; when thrown to the right, the outer contacts are closed.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS LINE POLES












Part of End Section Showing Method of Clamping to Wire No. 4 Line Pole

End Section with Spreaders Extended No. 3 Line Pole

Part of End Section with Spreaders Closed No. 3 Line Pole


No. 4 - Pole

Line Poles



Contact with the line wires is made by means of a connecting clamp which consists of a metal hook equipped with a spring. When the hook engages the line wire the spring forces the wire into contact with the hook and at the same time scrapes the wire slightly so that a good contact is obtained.





Code No.

Cord For Makng Coniact with t2 metallic conductors. Telephones.

1 metallic conductor (grounded

2 metallic conductors.

100 feet of M2J two conductor cord For use with 1330E, 1331E, 1332A & E

100 feet of M1A two conductor cord. For use with 1314A Telephones.


100 feet of M2K two conductor cord. For use with 1330E, 1331E, 1332A & E Telephones.

Description


The top section is equipped with two arms hinged at the lower end. These are each equipped with a connecting clamp and are of such length that they will span wires spaced up to 2 feet horizontally.

The top section has one connecting clamp only.

The top section is equipped with two connecting clamps. One of these is fixed to the pole and the other free but under control of the user by means of a long cord. This is intended for making connections between two line wires spaced up to 5½ feet, either horizontally or vertically.



Part of End Section Showing Free Clamp. No.5 Line Pole




Code No.	Con-		Dimen	sions		Used with	Used with		Replace	ment Part	s (See Cut))
	ductors	A	В	C	D	Jack Nos.	Cords	Notes	Е	F	G	St.
1A 3A	Fig. 1 Fig. 2	35 16 35 16	13/16 13/16	5/6 5/6	916 916	Same as for 47A Plug Same as for 47A Plug (99, 200, 201-203,	536	(Shell Frame (Fully Insulated	P-146711 P-147704	P- 82233 P-162652	P- 84662 P-162653	& 1
47A 47B }	Fig. 2	3%6	1%6	5 <u>16</u>	9 16	208, 215-221, 223, 225-227, 230-237, 281, 297, 303A, 309, 327, 353, 355, 361, 364	P2A, W2F,	47A has Red Shell 47B has Black Shell	P- 81335 P-110576			
109	Fig. 3	31/2	1%	762	3.6	(92, 292, 246, 248, 249, 323, 358A (49, 50, 70, 141,	S3A	*Has Red Shell	P- 81319	P- 81212	P- 82341	
110	Fig. 3	31/4	1%	%	2764	259, 260, 274, 275, and Types 238-245, 267, 280, 284, 285, 289-291, 293, 295, 300, 308, 324, 326, 347, 358B, 359, 360, 362, 363, 365	W3C, W2C, S2B, S1B, P1C, P3E	*Has Red Shell	P- 81200	P- 81299	P- 82311	
116 136 144	Fig. 1	35%	13 ₁₆	516 316	916	Same as for 47 Plug 99, 152	513, 519 369	*Has Red Shell Red Shell	P- 81335		P- 82239	
145 146 150	Fig. 1 Fig. 2 Fig. 2	3 % 3 17 7 1 22 3 7 62	13/16 17/4 23/4 13/4	964 576	918 2784 1516 2784	Same as for 47 Plug 186 Same as for 110 Plug	658, S2D 509	Has Cord Bushing 1330, 1331 Tel. (For plugging out	P- 81200 P-143217	P- 81299	P- 84662 P- 82341 P-127343	
151	.,	31961	13/6		33 64	Same as for 47 Plug	Nonerequired	signals in lines in trouble	P-141307	P-123581	*******	• • •
153A 153B 153C	Fig. 4	441/64	13/6		37/64	Same as for 47 Plug			P-143232 P-143233 P-143234			
165 221	Fig. 2	21 16 37 16	1316	5 ₁₆	716	Same as for 47 & 116 Same as for 47		See Note 2 ¶Has large red linsulating shell	P-203388	P- 82233	P- 82239	
273A-3	Fig. 3	1 1/8	1			77, 78, 190		Replaces 148	P-238714	P-299033		


Note 1. The No. 153 Type Plug has a resistance unit connected so that when the plug is inserted in a jack the resistance unit is bridged across the tip and sleeve spring. The resistance unit will carry \(^{1/10}\) ampere continuously without injury. The values are as follows: No. 153A Plug, 400 ohms. No. 153B Plug, 600 ohms. No. 153C Plug, 800 ohms. Used in Morse circuits for limiting the amount of battery current.

Note 2. No. 165 is a wooden dummy for opening jacks which use the Nos. 47 or 116 Plug.

*The following shells can be furnished for the Nos. 109, 110, 116 Plugs when specified on order:

Plug No. 109 110 116 Black Shell P- 91143 P-107872 P-110576 Gray Shell P- 90065 P-107882





Circuit Arrangements

Twin Plugs

When an operator's headset is to be used at a switchboard, it is convenient to wire two adjacent jacks for providing the necessary connections into the switchboard circuit and to use a twin plug in these two associated jacks in order that the necessity for the operator handling two separate plugs may be avoided. This practice is now standard and the Nos. 30, 78, and 80 Jack Mountings are designed for use with jacks so mounted that a twin plug may be inserted only in those jacks which are to be used together.

These plugs include a self-adjusting or flexible feature which allows sufficient movement of each plug in the shell to take up any slight off-centering present in the jacks.

Code No.	Con- ductors (Each Plug)	Dimensions		ensions			Used with Cords	Used for	Replacement Parts (See Cut)		
		A	В	C	D				E	F	G
137	2	3114	13/6	3/8	115/4	\$\begin{cases} 99, 215-237, 281, 297 \end{cases}\$	(87, 371, 555, 562, 565, 745, 748, 749, 848, L2E, L3E, L3F, P4C	tor's head tele-	P-124076	P-124071	P-82239
152	2	376	1316	3964 to 4164	11/4	Same as 137	(87, 550, 568, W2G,)674	Same as No. 137 but has ridges in shell to identify one side from other	P-142984	P-124071	P-82239
186 211	2 3	12362 3362	1961	7/16 3/16	119/14	No. 19C Test Set	747	No. 19C Test Set	P-205776 P-163952	P-158989 P-81299	P-82341
213	3	374	1%	11/16	13/6	49, 50, 70, 141, 259,260,274,275, 295, 238-245			P-164090	P- 81299	P-82341
241A 241B 241C	2	317/2	11364	3/8	13/6	\$99, 297, and similar types	[520, W3D, P3G, 855, P2T (See Note 1)	Black Shell Red Shell Black Shell	P-206009 P-206010 P-206009	P-229777	
241C)	2	211/16	13/16	5/8	15/16	(215 or similar type	LAA	Operator's telephone set	P-2060097 P-212688		P-82239


Note 1. No. 241 Type Plug has brass frames of the two plugs electrically connected to the two plug sleeves; the tips are separately insulated.


RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS **PROTECTORS**











No. 1079AP Protector



No. 1074A Protector

			-Consists of		
Code No.	Line Protection	Protector Mountings	Protector Blocks	Fuses	Protects Against
*58AP	2-Wire	1 No. 29B 1 No. 16 1 No. 48	{2 No. 26 2 No. 27	$ \begin{cases} 2 \text{ No. 11C} \\ (7 \text{ amp.}) \end{cases} $	High potential (lightning) and abnormal currents.
58BP	2-Wire	1 No. 29B 1 No. 16 1 No. 48	{2 No. 26 2 No. 30	$\begin{cases} 2 \text{ No. } 11\text{C} \\ (7 \text{ amp.}) \end{cases}$	High potential currents (light- ning.)
76AP	2-Wire	1 No. 29B	{2 No. 26 2 No. 27		Same as 58AP, less No. 16 and No. 48 Mountings and fuses.
86B	2-Wire				High potential and abnormal currents.
93A	{10 per { strip	10 No. 72A	10 No. 20 10 No. 25 10 No. 11 (mica)	10 No. 51A and 10 No. 74 cord tips	Units for mounting in wood cable terminals. Furnished 10 per strip, each strip supplied with a strap for connecting to others mounted in tiers and a strap hook for connecting the ground wire.
1074A	{As Required	74A	1 No. 20 1 No. 11	$ \begin{cases} 1 \text{ No. 7A} \\ (7 \text{ amp.}) \end{cases} $	High potential and abnormal currents.
**1079	4-Wire	{1 No. 79A 1 No. 80A	(mica) {4 No. 26 4 No. 27	{4 No. 11C (7 amp.)	High potential (lightning) and abnormal currents for group mounting. Fuses mount on 1/8 inch centers. Common ground strips are furnished for interconnecting two or more units.


Note: *Two No. 60A Fuses and one No. 16 Protector Mounting may be used with the No. 58AP Protector as a sneak current arrester for private branch exchange protection.

**Four No. 60A Fuses and one No. 80 Protector Mounting may be used with the No. 1079AP Protector as a sneak current arrester for private branch exchange protection.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS PROTECTOR BLOCKS









No. 27

NOS. 19, 20 AND 25 TYPES

The Nos. 19 and 20 Protector Blocks are used together and form an open-space cutout suitable for protection against high potential due to lightning. A mica separator is placed between the blocks to secure the necessary air gap, the No. 10 Protector Mica usually being used for this purpose; when a higher breakdown voltage is desired the No. 11 Mica which is twice as thick may be used, thereby raising the voltage necessary to produce an arc across the air gap to approximately double the usual value. An open space cutout having a fusible metal plug in one side may be obtained by using the Nos. 20 and 25 Protector Blocks and a mica separator.



Nos. 26 and 27 (Full size)



No. 10 Protector Mica

Code No.	Description	Used with Protectors
19	Plain copper block with two pins	60B and 80A
20	Grooved copper block with two bushings	60B and 80A
25	Plain copper block with two pins and fuse metal	Used in place of No. 19 Protector Block when fuse metal is desired.

NOS. 26 AND 27 TYPES

The Nos. 26 and 27 Protector Blocks are of new design and embody several advances in construction which greatly reduce maintenance costs and provide better telephone service through fewer interruptions of operation. They are used together without a separator (protector mica) and form an open space cutout which will afford the highest grade of protection against high potentials due to lightning. The two blocks differ in construction as follows:

The No. 26 Protector Block is a solid piece of hard non-dusting carbon. The face of the block is especially ground to present a smooth surface. The No. 26 Protector Block is mounted on the ground side of the protector mounting.

The No. 27 Protector Block consists of a porcelain frame with a countersunk hard carbon plug which is fastened in place with low temperature fusing cement. The surface of the frame which bears against the No. 26 Block, when assembled in a mounting, is finished by grinding. The air gap between the carbon insert in the No. 27 Block and the face of the No. 26 Block is held to close limits by this grinding process and the consistent operation of the cutouts at the proper voltage is thereby insured.

Ordinary lightning discharges will cause an arc across the air gap between the carbon blocks but will not heat them sufficiently to melt the cement used for holding the carbon plug in place. A cross with an electric light or power line, however, will cause a discharge or repeated discharges, of such duration that the heating of the carbon insert of the No. 27 Blocks will melt the cement holding it in place and allow the mounting spring to push it into direct contact with the No. 26 Block, thus permanently grounding the line.

Code No.	Description	Used with Protectors
26	Carbon block	Nos. 12AP, 58AP, 60AP, 76AP, 1079AP, 1268A and 1269A. No. 83A Protector Mounting.
27	Porcelain frame with carbon insert	Same as No. 26, except No. 83A Protector Mounting.
28	Carbon block	For use with 29 Block.
29	Porcelain frame with carbon insert	Central Office protectors on 3/8 inch centers.
30	Porcelain frame with carbon insert	83A Protector Mounting.

Protector Blocks and Micas (Continued)

The Nos. 26 and 27 Protector Blocks are interchangeable with the old combinations of Nos. 1 and 2 Protector Blocks and No. 3 Protector Mica both at subscribers' stations and central offices, and are therefore available for improving protective equipment already in service. This practice will result in fewer visits of the trouble man. All orders for replacements of Nos. 1 and 2 Protector Blocks and No. 3 Protector Micas should specify the Nos. 26 and 27 Protector Blocks; no separator (protector mica) is needed for the new design of block.


In addition to the above replacements, tests on cable protection have shown that Nos. 26 and 30 Protector Blocks require less attention and replacement due to grounded blocks than the Nos. 19 and 20 Blocks with the regulation .010-inch mica separators; therefore, the Nos. 26 and 30 Protector Blocks can be used advantageously wherever metal (Nos. 19 and 20) blocks are now used.

PROTECTOR MICAS

Code No.	Used with Protector Blocks	Used with Protectors
10	Nos. 19 and 20	Nos. 60B and 80A
*11	Nos. 19 and 20	No. 17B

*No. 11 Mica is twice as thick as the No. 10.

VACUUM TUBE RECTIFIER



60B VACUUM TUBE RECTIFIER

The No. 60B Vacuum Tube Rectifier as shown above is operated from a 110 volt 60 cycle alternating current source and may be used instead of dry cells, storage cells, or a motor generator set to furnish the main power for operating one or two selector circuits. It does away with the periodic tests of dry cells, the charging of storage cells, or the continuous large power drain of the motor generator set.

Description

The No. 60B Vacuum Tube Rectifier consists of a fuse and switch block, one No. 72A Repeating Coil, one No. F11 Relay, eleven No. 138B Condensers, vacuum tube socket for mounting the Western Electric No. 214E Vacuum Tube, and a terminal block mounted in a black finish steel box 18" high, 12" wide, 6½" deep. The weight is approximately 60 pounds.


For further information regarding the operation of this rectifier refer to pages 21 and 23 of this catalog.

RELAYS

Code No.	Resistance (Ohms)	Description	Used
F11	2 windings 55 ohms each		In No. 60B Vacuum Tube Rectifier.
M3		Two "R" type relays mounted on an individual mounting.	By railways in selector circuits.
R323	3600		No. 60B Test Set.
R332	2250		
R1027	95	2.71.4.5	Nos. 62 and 63 type Selector Keys.
R1971	100	Equipped with platinum contacts.	No. 60A Time Sending Set.
26A	25	Code repeating relay.	In No. 60B Selector Apparatus Case.
27A		Code repeating relay (replaces Relay List No. 100865).	In Nos. 51A and 53A Apparatus Cases.
122EW	100	Holding relay.	In No. 60B Selector Apparatus Case.
149AN	167		No. 60A Time Sending Set.
221JB	335	Holding relay.	In No. 60B Selector Apparatus Case.
120281	50	Selector sending.	On inter-calling selector circuits. No. 52 Selector Apparatus Case.



No. 27A Relay



No. 26A Relay

	No. 26A Relay Repair Parts	
Symbol	Subject	26A Tele- graph Relay
A	Sub-base	P-95884
n D	Base	P-97467
C	Adjusting Nut	P-95889
5		
B C D E F G	Coil Mounting Screw	P-95965
E	Coil	P-98584
F	Coil Shell	P-95919
G	Stop Screw	P-97484
H	Check Nut	P-95899
1	Bearing	P-95930
J	Bearing Serew	P-99930
K	Armature	*P-97470
		P-97471
L.	Contact Spring	*P-92339
		P-97481
M	Contact Spring	*P-92341
		P-97481
N	Bone Stud	P-97471
0	Contact Screw	*P-97482
i.e.		P-97483
P	Binding Post	P-97927
Q R	Binding Post Washer	P-97937
R	Binding Post Screw	P-118454
	Clamp Plate	P-92343
	Pileup Screw	P-116879
	Bushing	P-93293
	Small Insulator	P-97478
	Large Insulator	P-97477
	Base Terminal Clip	P-95903
	Coil Support	P-95904
a To be	geemblad	



No. 221JB Relay

	No. 221JB Relay Repair	Parts
		221JB
Symbol	Subject	Relay
A	Coil	P-250737
B	Armature Travel Screw	P-250207
C	Armature Travel Nut	P-250211
D	Armature	P-250218
E	Armature Screw	P-126075
F	Clamping Washer	P-250208
D E F G	Pileup Screw	P-250150
H	Clamping Plate	P-250095
ī	Insulator	P-250212
	THIS GIVE OF	# (P-250646
J	Contact Spring	P-250891
	Contact Spring	P-250310
K	Contact Spring	P-250678
L	Contact Spring	P-250223
M	Contact Spring	P-250636
N	Armature Stop	P-250206
Ö	Pole Piece	P-250260
P	Armature Plug	P-250213
		1-200213
* To be	assembled.	





No. 131 Received



No. 186 Receiver (3B Headband)

Code	HEAD TYP	E
No.	Description	
186	A metal case, black finish, single head receiver with a rubber ear piece, and No. 3B Headbands. Approximate resistance 400 ohms. Replaces	
189	No. 156W. Similar to the No. 186 except wound to a low resistance. Approximate resistance 45 ohms. Replaces No. 148W.	

Brass, black finish. Approximate resistance 45 515 ohms. 528

Brass, black finish, single head receiver with No. 11A Headband. Approximate resistance 80 ohms.

Used

Used
With Nos. 1042AB, BR Desk Stands, 1293AE,
AK, 1317AW, AE Telephone Sets, 1020C,
E, 1048DA, DB, DC, DD, GA, GB, GC, GD
Arms. With Nos. 546 and 554 Cords.
With Nos. 1042AB Desk Stand, 1017B, C, E,
1020A Test Sets, 1120C, 1148DA, DB, DC,
DD Telephone Arms, and 1317 BU Telephone Set. At way stations with No. 501
Type Desk Set Boxes. Also with No. 565
Cords.
With No. 1017 Type Test Sets

With No. 1017 Type Test Sets.

With cords having No. 80 Cord Tips at receiver end. (See Test Board Cords, page

No. 528 Receiver (11A Headband)

HAND TYPE



144, 508, Equipped with Cord

No.	Description
133	Insulated bipolar hand receiver with rubber case. Resistance 70 ohms.
144	A concealed binding post hand receiver. Hard rubber case. Approximate resistance 83 ohms.
508	A concealed binding post hand receiver. Same as the 144 except that it is wound to an impe- dance of approximately 2,000 ohms at 800 cycles.

Used With No. 1314A Telephone Set.

With Nos. 1040U, 1040AL deskstands, 1305AC, 1312A, 1317P, S, AH, BK, CN, CR, CP, CS, CG, 1336H and 6023A Tele-phone Sets, and 1020CC Telephone Arm. With Nos. 1317W, AD, 1293AD, AK and 1336F Telephone Sets.

•			
ode	HAND S	ET	TYP

Code	TIAND SET	1 1 1 1 1
No.	Description	Used
131	Black or nickel finish. Resistance 71 ohms.	With No. 1001 Type Hand Sets.

Receivers (Continued)

Receiver Replacement Parts




Fig. 1




Fig. 2

Sym bol	Name of Piece Part	Receiver (186, 189, 515 (See Fig. 1) (Sym- bol	Name of Piece Part	Receiver Code No. 133 (See Fig. 2)
**	Receiver Cap Diaphragm { Right Coil Left Coil. Case. Case Screws Magnet. Magnet Machine Screw Nuts. Receiver Block Assembly. Binding Post Block Binding Posts. Terminal Lugs. Terminal Lug Machine Screws Round Head Machine Screws Nut. Ring Pole Piece. P-207461 for the 189 and 515. [P-215906 for the 189 Receiver. [P-215905 for the 515 Receiver. Locking Nut.	**P-207460 **P-215907 P-97053 P-97064 P-97056 P-132958 P-132958 P-132958 P-132958 P-98974 	P-213314 P-98387 P-230412 P-230411 P-98949 P-99862 P-99541 P-99754 P-98762 P-233887 P-98358 P-229679 P-99794 P-99100 P-99101	1 2 3 4 5 6 7 8 9	Receiver Cap Diaphragm Case Right Coil Left Coil. Magnets Magnet Machine Screws Magnet Machine Screw Nuts Magnet Clamp Receiver Block Assembly Binding Post Block. Binding Post Screw Round Head Machine Screws. Terminal Cap	P-95118 P-95718 P-80724 P-80723 P-87383 P-107062 P-87115 P-87410 P-93592 P-87411

Receiver Replacement Parts (Continued)




Fig. 3




Fig. 4

Sym- bol	Name of Piece Part	Receiver Code Nos. 131 (See Fig. 3)	Sym	Name of Piece Part Receiver Block (Continued)	131 (See Fig. 3)	r Code Nos.
1 2 3 4 5	Cap. Ring Nut. Diaphragm Right Coil Left Coil.	P-98439 P-81525 P-95265 P-95276	11 12 13 14 15 16	Binding Post. Washers. Nuts. Terminal Lugs. Terminal Lug Machine Screws Round Head Machine Screw.	P-132152 P-82275 P-81500 P-82027	
8	Core Screws Case Magnets Magnet Machine Screws	P-98956 P-81488 (2) P-81489 (1)	1 2	Receiver Cap Diaphragm	144 (See Fig. 4) P-98948 P-95114	508 (See Fig. 4) P-99073 P-95114
10	Receiver Block	P-82028 (1) P-81499	3 4 5	Case Machine Screw	P-220224 P-93799	P-93518 P-93799 P-99071

HEAD BANDS (Receivers)

Code	Description
1B	Consists of a wire head band with olive drab textile covering, equipped with adjustable yokes for holding two No. 528 Receivers (less the No. 3A Head Band ordinarily furnished).
1C	Similar to No. 1B, except for use with two No. 128 Receivers.
3B	Wire head band covered with black sleeving; for use with 186 Receiver.
11A	Wire head band and head band pad; used as part of No. 528 Receiver.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS REPEATING COILS



NOS. 70A, 76A, 77A, AND 78A TYPES

The following coils are intended for use in phantom and simplex circuits. The No. 70A is for use in connection with A.C. selectors.

The No. 72A is used in the No. 60B Rectifier. Is mounted on a wooden base $4^{11}/_{6}'' \times 4^{11}/_{16}''$. The No. 76A has two coils mounted on a wood base.

The No. 76A has two cons mounted on a wood base.

The Nos. 77A and 78A are each equivalent to one-half of No. 76A.

The No. 78A also consists of two resistance units enclosed in shell, each unit is non-inductively wound and is adjusted to have approximately the same D.C. resistance as the corresponding repeating coil windings. Intended for use at intermediate stations on phantom lines where one side of phantom circuit is terminated, the phantom circuit and the other side circuit going through.

Code	No. of	No. of Windings	R	esistances, Oh	ıms ——	Impedance	Dimensions of
No.	Coils	Each Coil	Primary	Secondary	Tertiary	Ratio	Wood Base, Inches
70A	1	4	2 of 45	2 of 40		1 to 1	11 x 85/8
76A	2	4	2 of 20	2 of 21		1 to 1	$10\frac{3}{4} \times 4$
77A	1	4	2 of 20	2 of 21		1 to 1	6 x 4
*78A		4	2 of 20	2 of 21		1 to 1	$10\frac{3}{4} \times 4$

^{*} Has two resistance units. See above notes.

121A

NO. 25 TYPE

The No. 25E Coil is intended for use in Nos. 1278 and 1302 Types of railway telephone sets. Base of coil provided with mounting lugs.

Code	No. of	Windings	R	esistances, Oh	ms-	Impedance	Dimensions of
No.	Coils	Each Coil	Primary	Secondary	Tertiary	Ratio	Wood Base, Inches
25E	1	2	42	42		1 to 1	$3\frac{7}{8} \times 4\frac{7}{8}$

NO. 56 TYPE

The No. 56 Type Coils are intended for use in circuits designed for obtaining ringing current from central office storage batteries, in conjunction with No. 84 Type Interrupters.

Code	No. of	No. of Windings	R	esistances, Oh	ıms——	Impedance	Dimensions of
No.	Coils	Each Coil	Primary	Secondary	Tertiary	Ratio	Wood Base, Inches
56A	1	3	2 of .85	1 of 22.5			$11 \times 8\frac{5}{8}$
56B	1	3	2 of 2.35	1 of 27.7			11 x 85/8

NO. 121 TYPE

The No. 121A Repeating Coil is intended for protecting subscribers sets from high potential hazards when the telephone lines are located in the exposure area of high tension power lines.

Consists of toroidal type coil potted in a cast iron case arranged for panel and telephone pole mounting. Average D.C. resistance of the set winding 131 ohms and of the line winding 37 ohms. Optimum terminating impedance of the subscriber's set winding and the line winding is 600 ohms each. Case is furnished with 6' leads. Height 1434", width 1314". Replaces the No. 50A Repeating Coil except for additions and maintenance purposes.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS RETARDATION COILS









No. 5AF



No. 51A



No. 152A

Code	No.
5A/	1

Description

- Toroidal type coil enclosed in a crosstalk-proof shell and mounted on a wooden base. It has two independent groups of windings; resistance of windings 74 ohms each. Base 11 x 8% inches.
- 5AF Torodial type coil, in crosstalk-proof shell. Equipped with mounting brackets and has wooden base with 3 terminals. It has 4 windings, connected series aiding with tap brought out from the middle point of the series arrangement. Total resistance 330 ohms, base 3 ½ x 3 ½ inches.
- 12G Consists of winding with a resistance of 2.3 ohms and is equipped with movable core for varying the impedance. Size 31% x 1 x 11% inches.
- 12M Resistance 2.3, similar to No. 12G but for portable sets. Base 3½ x 1 inches.
- Two toroidal coils, each enclosed in a crosstalk-proof shell and mounted on a single wooden base. Each coil has 4 inductive windings connected permanently in series (inductive aiding); the maximum resistance of the series arrangement (L-1-L-2) is 330 ohms. Terminals arranged so protector blocks on No. 53 mounting can be associated with the coil. Same as two No. 5AF coils on one base. Base 1134 x 436 inches.
- 51A Retardation coil of one winding equipped with two brass terminals bent up to an angle of 90 degrees with the head of the coil. Resistance 520 ohms. Height 1½ inch, diameter 1½ inch.
- 51B Similar to No. 51A excepting it is moisture-proof. Height 11/8 inch.
- 78A A laminated steel core mounted between two split wooden spool heads. Resistance 525 ohms. Mounted by means of angle pieces. Size 5 x 5 x 10 inches.
- 152A A shell type laminated silicon steel core provided with an air gap. Has an average effective inductance of approximately 2.7 henries with a superimposed direct current of .5 ampere.

 The DC resistance at 68 degrees Fahrenheit of the two windings in series is approximately 18.4 ohms. Size approximately 4 1/8 x 4 3/4 x 8 inches.
- Potted in a sheet steel case, arranged for stud mounting. Core and windings are divided in two parts and the winding parts so interconnected as to obtain two independent inductive windings having substantially the same electrical characteristics and very low mutual coupling. Average DC resistance of windings (1-2) and (3-4) is 73 ohms each. Effective inductance of windings (1-2) and (3-4) connected in parallel ranges between 1.345 and 1.555 henries.

Used With

- Composite circuits in place of two No. 5K or two No. 5L Retardation Coils.
- Simplexing telephone line. Replaces No. 5AC Coil.
- Nos. 1312A and 6023A Telephone Sets.
- No. 1314A Telephone Set
- Used as phantom retardation coil; replaces No. 44C.
- Nos. 295AK, special 300H and K Desk Set Boxes, Nos. 1293AD, AE, AK, AL and 1317W, AD, AE, and AW Telephone Sets.
- No. 1336F Telephone Set.
- No. 61A Selector Apparatus Case.
- No. 60B Selector Apparatus Case. Entirely replaces the No. 5AD Retardation Coil.
- Intended for use in place of Nos. 5AA and 77A Retardation Coils in stud mounted DC Telegraph Composite Sets.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS RESISTANCES



No. 1



No. 34A



No. 35D



No. 1



No. 31A



No. 63

Code No.	Resistance (Ohms)	Used, With
1F	1,000	Nos. 101A and 101B Selector Sets.
18A	37	No. 52A Selector Apparatus Case.
18G	200	No. 60A Selector Apparatus Case.
18AK	60	Nos. 51A, 52A, 53A and 60A Selector Apparatus Cases.
31A	1,200	Telegraph relays on composite circuits. Steel tube enameled resistance.
34A	200 to 30,000 9 terminals	Nos. 101A, 101B, 102A and 102B Selector Sets.
34B	100 to 3,100 6 terminals	Nos. 51C, 51D and 53A Selector Keys on intercalling circuits.
34C	4 to 3,124 9 terminals	Simplexed train dispatching circuits.
34G	700 to 2,900 7 terminals	Dispatcher's Loud Speaking Telephone Circuit.
35D	250	Nos. 51A and 53A Selector Apparatus Cases. Enameled resistance.
38A	48,000	No. 160A Selector Sets.
63C	50	No. 60B Selector Apparatus Case.
63F	200	No. 60B Selector Apparatus Case.

Note—Resistance units in No. 34 Type Resistances are arranged so that various values may be obtained as follows:
No. 34A values from 200 to 30,000 ohms in steps of 200 ohms each.

No. 34B values from 100 to 3,100 ohms in steps of 100 ohms each.

No. 34C values from 4 to 3,124 ohms in steps of from 4 to 64 ohms each.

No. 34G values from 700 to 2,900 ohms in steps of from 200 to 500 ohms each.






No. 60CG Ringer

Nos. 4, 32, 38, 43, 45, 51, 53 and 60 Types

Code No.	Resistance in Ohms	Gong No.	Used in
4BG	2500	29A	Nos. 1293AD and AE Telephone Sets.
32BG	2500	13	Nos. 1330E and F Telephone Sets.
38AG	1020	26Λ	Nos. 127E and 127 Special Extension Bells and No. 1317AH Telephone Set.
38BG	2500	26A	Nos. 127F Extension Bell, 1317P, S, W, AW and BK Telephone Sets.
38FG	1620	26A	No. 127G Extension Bell.
43NG	88	26A	No. 128H Extension Bell.
45BG	2500	20	Nos. 1336F, H and 1305AC Telephone Sets. Moisture-proofed.
*51AG	1020	29A	Nos. 1278G, and H Telephone Sets and 315H Desk Set Box.
*51BG	2500	29A	Telephone Sets and 300K and N Desk Set Boxes.
*51FG	1620	29A	Telephone Sets and 300L and N Desk Set Boxes.
53AG	1000	29A	No. 1317CG Telephone Set.
53BG	2500	29A	Nos. 1317CP and CS Telephone Sets.
53FG	1600	29A	Nos. 1317CN and CR Telephone Sets. No. 127J Extension Bell and Nos. 160A, B, C, R and 161A Selector Sets.
60CG	16	26A	Nos. 160C, R, AC, AR, BC and BR Selector Sets.

*The No. 51 Type Ringers have bent gong posts which permit of their use in woodwork drilled for ringers having three inch gongs; for example, drilled for the No. 38 Type Ringer.

Ringers (Continued)



Repair Parts of Ringers

Repair parts for the Nos. 38, 51, 53 and 55 Type Ringers are the same as shown above with the following exceptions:

Ringer 38FG P-133729 51FG (800 ohms)

Coil Mounting Screw (Note 2)

38 Type
51 Type
P-40837

50 Type—P-38973


Note 3—Gongs for various type ringers are listed with the code numbers on the preceding page.

*Part of P-205284.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS

Ringers (Continued)


No. 45 BG Ringer



REPLACEMENT PARTS

	T.	EFLACEMENT FARTS	
Piece	No.	Material	Name
Part	Required	Material	
P-108452	1		Armature Adj. Assem.
P-138638	1		Clapper & Arm. Assem.
P-205284	2	_	Gong Post Assem.
P-203063	2		Coil Assem.
P-26700	1	-	Conductor, 1½" long
P-101697	2	Brass	Eccentric
P-101698	1	Brass	Pivot Screw
P-101699	1	Brass	Hex. Nut
P-101706	1	Brass	Clamping Plate
P-203971	2	Brass	Button H. Mach. Screw
P-106888	2	Iron	Rivet
P-166881	1	Iron	Washer H. M. Screw
P-108210	1	Steel	Heel Iron
P-108454	1	Brass	F. H. Mach. Screw
P-109804	$\frac{2}{2}$	Iron	F. H. Mach. Screw
P-112179	2	Brass	R. H. Mach. Screw
P-107896	1		Magnet
P-12713	4	Brass	Eyelet
P-46610	2	Brass	Terminal
P-203105	2	Phenol Fibre	Spool Head
P-101701	2	Iron	Core
P-106887	2	Brass	Terminal
P-107836	4	Paper	Washer
P-112807	2	Paper	Insulator
*P-205275	2	Steel	Adj. Plate
P-127918	2	Brass	Special Hex. Nut
P-203060	4 2 2 2 2 4 2 2 2 2	Phenol Fibre	Spool Head
P-145369	2	Steel	R. H. Mach. Screw
P-145364	$\frac{2}{2}$	Steel	Washer
	ALCO DE LA CONTRACTOR DE		

Ringers (Continued)




No. 60 Type Ringer

REPLACEMENT PARTS FOR No. 60CG RINGER

A	P-140855	Armature Adjuster	M	P-140847	Contact Terminal
В	P-108454	Adjusting Screw	N	P-101697	Eccentric
С	(P-101698	Pivot Screw	0	P-112962	R.H. Machine Screw
C	P-101699	Set Nut	P	P-140850	Heel Iron
D	P-140835	Spring	Q	P-205284	Gong Post
E	P-145539	Contact Arm	R	P-107918	Gong Mounting Screw
F	P-145541	Clapper and Armature	S	P-124456	Gong
G	P-140849	Clamping Plate	Т	P-140894	Clamping Plate
H	P-140859	Coil Assembly	-	P-140862	Pile-up Screw
I	P- 40837	Coil Mounting Screw	**	P-140852	Terminal
J	P-140844	Contact Spring	U	P- 92956	Terminal Screw
K	P-140845	Contact Spring	v	P-140851	Bushing
L	P-140848	Rubber Separator	•	P-140857	Insulator

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS SELECTIVE APPARATUS



No. 50B Selector




No. 60AP Selector

Selectors

Code		Resistance	
No.	Description	in Ohms	Used
*50A	Bridging selector mounted on a porcelain base and protected by a glass cover. Capacity 48 stations.		At way stations on train dispatching circuits in Nos. 101A and 102A Selector Sets.
*50B	Group selector, first selects a group and then from this group the particular station desired. Capac- ity 65 stations.		At way stations on train dispatching circuits in Nos. 101A and 102A Selector Sets.
*50C	Same as No. 50A except it is of low resistance and operates from a local battery in the set. Capacity 48 stations.		At way stations in No. 102C Selector Sets.
60AP	Alternating selector, mounted on phenol base and supplied with a glass cover. Operates on 17 impulses which give a total of 78 code settings. Also equipped for receiving time signals.		At way stations in No. 160C or R. Selector Sets.
60BP	Similar to No. 60AP except it is equipped with 4 ringing terminals so that four bells in the same station can be rung by the same selector. Not equipped for receiving time signal. Regularly set to operate on a total of 17 impulses to the first ringing terminal. Total code settings 28.		At way stations in No. 160C or R Selector Sets.

*Specify on order the number of stations for which the selectors are desired. In the No. 50B Selector specify the group number and number of stations.


Selective Apparatus (Continued)




Replacement Parts for No. 60 Type Selectors

Syr	mbol Subject	60AP Selector	60BP Selector	Sym	abol Subject	60AP Selector	60BP Selector
A	Felt Washer	P-91966	P-91966	W	Stepping Pawl Spring	P-93202	P-93202
В	Clamping Stud	P-207899	P-207899	X	Ratchet	P-137678	P-137678
C	Code Pin	P-137652	P-137652	Y	Terminal Plate	P-137658	P-137658
D	Code Nut	P-137651	P-137651	Z	Terminal Bridge Screw	P-94505	P-94505
E	Code Wheel	P-146196	P-146199	AA	Terminal Plate Screw	P-93836	P-93836
D E F	Code Wheel Screw	P-137650	P-137650	AB	Spiral Spring	P-137649	P-137649
G	Insulator Bushing	P-207896	P-207896	AC	Base	P-207897	P-207898
H	Clamping Plate	P-146610	P-146610	AD	Base Terminal	P-137683	P-137683
I	Clamping Plate Screw	P-93833	P-93833	AE	Terminal Screw	P-137685	P-137685
J	Insulator	P-137632	P-137632	AF	Core Lock Nut	P-121772	P-121772
K	Holding Spring	P-137636	P-137636	AG	Coil	P-228520	P-228520
L	Upper Plate	P-146308	P-146308	AH	Frame	P-146145	P-146145
M	Upper Plate Screw	P-147796	P-147796	AI	Frame Screw	P-121770	P-121770
N	Adjusting Screw	P-92642	P-92642	AJ	Magnet	P-145918	P-145918
N O	Hexagon Nut	P-137686	P-137686	AK	Core	P-147431	P-147431
P	Armature	P-146148	P-146148	AL	End Play Washer	P-137641	P-137641
Q	Middle Plate	P-146306	P-146306		Card	P-92152	P-92152
R	Holding Pawl	P-137643	P-137643	AM	Card Holder	P-101963	P-101963
Q R S T	Holding Pawl Spring	P-137648	P-137648	Alvi	Face Strip	P-101964	P-101964
	Rocker Arm	P-146152	P-146152		Retaining Screw	P-223064	P-223064
U	Rocker Arm Spring	P-137692	P-137692		Glass Cover	P-162258	P-162258
V	Stepping Pawl	P-146149	P-146149				

Selective Apparatus (Continued)






Photograph 60B Selector Apparatus Case

Schematic Wiring of No. 60B Selector Apparatus Case

Selector Apparatus Cases

Code No.	Equipment	Overall Dimensions	Used At
60B	2 No. 152A Retardation Coils	1 ft. 41/8 in. x	Dispatchers office on train
	1 No. 26A Relay	1 ft. 8½ in. x	dispatching systems
	1 No. 221JB Relay	61/16 in.	(metal cabinet). Re-
	1 No. 2B Circuit Breaker		places No. 60A Selector
	1 No. 629A Mounting Plate		Apparatus Case.
	4 No. 63C Resistances		
	1 No. 63F Resistance		
	4 No. 138B Condensers		
	1 No. 138A Condenser		
	1 No. 141A Condenser		
	3 No. 709 Trumbull Knife Switches DPST		
61A	1 No. 47A Repeating Coil	2 ft. 5% in. x	Battery stations on inter-
	2 No. 21AA Condensers	125% in. x 67/8	communicating mes-
	1 700 ohm Ward Leonard Resistance DM 700 Type	in.	sage circuits.
	1 No. 78A Retardation Coil		
	3 No. 709 Trumbull Porcelain Switches		
	2 No. 9171 Bryant Porcelain Receptacles		
	2 No. 12061 Ballast Lamps		

Selector Keys




NOS. 50, 53, 60 AND 61 TYPES

Code N	No.	Description	Used In
*50A	Individual key. from 1 to 35.	Can be adjusted to select any station	Nos. 50A, B or C Selector Key Cases. At dispatcher's office. With No. 50A Selectors.
*50B	Individual key. from 1 to 48.	Can be adjusted to select any station	Nos. 50A, B or C Selector Key Cases. At dispatcher's office. With No. 50A Selectors.
*50C	Individual key. from 6-1 to 1:	Can be adjusted to select any station 2-5.	Nos. 50A, B or C Selector Key Cases. At dispatcher's office. With No. 50B Selectors.
*50D	Individual key. from 13-1 to	Can be adjusted to select any station 18-5.	Nos. 50A, B or C Selector Key Cases. At dispatcher's office. With No. 50B Selectors.
*50F	Individual key. from 1-3 to 2	Can be adjusted to select any station 1-1.	Nos. 50A, B or C Selector Key Cases. At dispatcher's office. With No. 50F Selectors.
53A	Master calling I No. 34B Resi	xey. Capacity 55 stations. Mounts 2 stances.	Test boards in connection with No. 50B Selectors. Also at way stations on inter-calling circuits.
60A	Individual key. from 1 to 78 a receiving posi	Can be adjusted to select any station and advancing all selectors to the time tion.	Nos. 60A, B, C, D or E Selector Key Cases. At dispatcher's office. With No. 60AP Selectors.
60B		Can be adjusted for calling any of the given for the No. 60B Selectors.	Nos. 60A, B, C, D or E Selector Key Cases. At dispatcher's office. With No. 60BP Selectors.
61A	for all codes to mechanism ar and control sp nished with a tend allowing	ontrol the sequence of calling impulses of talling 17 steps. Consists of a driving ad impulse wheel mounted on a shaft orings mounted on the base. It is furslotted cover through which levers exchanges to be made in the code setpond with the codes of the Nos. 60AP tors.	Circuits equipped with the Nos. 60AP and BP Selectors when set for a total of 17 steps to the first or A terminal. Also used on the inter-call circuits.
61B	No. 60A Selection and for the 60	me as 61A except arranged to control of calling impulses for all codes for the tor when set for a total of 27 impulses DB Selector when set for a total of 27 to first or A terminal.	On circuits equipped with 60AP and BP Selectors when set for a total of 27 steps to the first or a terminal. Also used on inter-call circuits.

*These selector keys are of the older type and are listed for convenience in ordering for maintenance purposes and for extensions to existing circuits.


Selector Keys (Continued)



Symb	No. 60	60A Selector Key	60B Selector Key
A	Impulse Wheel	P-140791	P-140944
В	Bent Up Segment	P-140789	P-140942
C	Flat Segment	P-140788	P-140941
D	Segment Screw	P-115851	P-115852
E.	Contact Spring	P-140782	P-140782
E F	Contact Spring	P-140784	P-140784
G	Insulator Bushing	P-140787	P-140787
H	Insulator	P-93019	P-93019
1	Pileup Screw	P-115587	P-115587
J	Governor Pivot	P-93028	P-93028
K	Governor Pivot	P-93044	P-93044
L	Pivot Lock Nut	P-92122	P-92122
M	Main Spring	P-93040	P-93040
N	Stop	P-219298	P-219298
0	Stop Screw	P-219300	P-219300
P	Handle	P-94751	P-94751
0	Governor	P-93393	P-93393
Q R S T	Governor Shaft	* (P-93020	P-93020
S	Governor Worm	P-93021	P-93021
T	Governor Cup	P-92113	P-92113
Ū	Mounting Screw	P-92132	P-92132
V	Ratchet Gear	P-93033	P-93033
W	Gear and Pinion	P-93036	P-93036
X	Gear and Pinion	P-93050	P-93050
Y	Face Plate	P-98914	P-98914
Z	Worm Wheel	P-93024	P-93024
AA	Screw	P-93487	P-93487
AB	Card	P-92152	P-92152
AC	Card Holder	P-101963	P-101963
AD	Face Strip	P-101964	P-101964
AE	Retaining Screw	P-107474	P-107474
	Large Flat Segment		P-142175
	o be assembled.		

No. 61 Type

		140. 01	Type
Sym	bol	Subject	61A Selector Key
A	Code	Lever	Det. 49, A-121562
В	Code	Lever	Det. 34, A-121560
C	Interlock Arm		Det. 61, A-121563
D	Gove	rnor	*Det. 2 & 4, A-121555
E.	Gove	rnor Screw	P-115577



No. 61 Type (Continued)

Syml	ool Su	bject	61A Selector Key
F	Pivot Screw		Det. 55A, A-121562
G	Pivot Screw		Det. 55, A-121562
H	Pivot Nut		P-95329
i	Locking Spr	ina	Det. 47, A-121561
Ĵ	Contact Spr		*Det. 39 & 46, A-121561
K	Contact Spr		*Det. 40A, A-121561
L	Contact Spr		*Det. 38, A-121561
M	Insulator	mg	Det. 41, A-121561
N			Det. 43, A-121561
	Bushing		
O	Pileup Screw		P-116861
P	Pawl Assem		*Det. 28, 29, 30, 32, A-121559
Q R	Pawl Spring		P-93204
R	Impulse and	Ratchet Wheels	*Det. 34, 35, 36, 37, A-121560
S	Main Spring		Det. 21, A-121558
S		er and Ratchet	*Det. 19, 20, 22, 23, 25, A-121558
U	Governor G	ear	*Det, 8, 9, 10, 11, 10A, A-121556
V W X Y Z AA	Ratchet Spr	ing	P-93030
w	Hub Screw		.138"-32 x 5/2", A-121569
X	Base		Det. 1, A-124869
Ÿ	Handle		P-101504
7	Handle Scre	w	P-101482
AA	Operating L		*Det, 12, 13, 14, 16, 17, 18
rara.	Operating D		19, A-121557
AB	Latch Spring	7	P-93203
AC	Position Spr		Det. 50, A-121562
AD	Fixed Segme		Det. 51, A-121562
AE	Carina Caron	:116	P-115578
AL	Spring Screv	Y	
	Cover		Det. 1-A, A-124867
Syml	ool Su	bject	**61B Selector Key
A	Code Lever		Det 49, A-121566
В	Code Lever		Det. 34, A-121565
R		Ratchet Wheels	
AD	Fixed Segme	ent	Det. 51 A-121566
	Cover	77.6	Det. 1-A. A-124868

Other parts same as for 61A Selector Key.

* To be assembled as per drawing A-121569.


** Parts same as for No. 61A Selector Key except as noted

Selector Keys (Continued)

Nos. 62 and 63 Type



No. 62A Selector Key



No. 63B Selector Key

61/4" deep. The metal frame and

cover are finished in aluminum.

The Nos. 62 and 63 Type Selector Keys are master calling keys arranged to operate any or all selectors on a line to their ringing position by pushing one small locking key in each of the two groups of keys.

The Nos. 62A and 62B Selector Keys are arranged for desk or table mounting and the main apparatus unit is arranged so that it can be removed from its base by means of a jack connection.

The Nos. 63A and 63B Selector Keys are arranged for mounting in the face equipment of a No. 604 P.B.X. switchboard between the stiles (10½" face mounting). They are arranged so that they may be removed from the switchboard either from the front or rear.


Code No. Description Remarks 62A Arranged for desk or table mounting. Provides means The overall dimensions are approximately 12½" high, 10¼" wide and 6½" deep. The metal frame and for calling all selectors in the 17 step selector code as given in Table No. 1, page 10. These keys have two groups of 14 keys each and one group of 7 keys. cover are finished in black. 62B Desk or table mounting. Provides means for calling The overall dimensions are approximately 12½" high, 10¼" wide and 6½" deep. The metal frame and cover are finished in black. all selectors in the 27 step selector code as given in Table No. 2, page 10. These keys have two groups of 21 keys each and one group of 7 keys. 63A Switchboard mounting. Provides means for calling all The overall dimensions are approximately 1058" high, 934" wide and 614" deep. The metal frame and selectors in the 17 step selector code as given in Table No. 1, page 10. These keys have two groups of 14 keys each and one group of 7 keys. cover are finished in aluminum. 63B Switchboard mounting. Provides means for calling all The overall dimensions are approxiselectors in the 27 step selector code as given in mately 105%" high, 934" wide and

Note: For further information regarding the operation of these keys, refer to page 11.

Table No. 2, page 10. These keys have two groups

of 21 keys each and one group of 7 keys.


Selector Keys (Continued)



62 Type Selector Key

Sym	ool Subject	62A Selector Key	62B Selector Key	Symb	ol Subject	62A Selector Key	62B Selector Key
ABCDEFGHIJKLMNO	Distributor Panel, Complete Terminal Plate, Complete Inner Segment Outer Segment Segment Screw Contact Arm Contact Spring Contact Spring Screw Gear Gear Mounting Screw Pinion Mounting Screw Pinion Designation Card Window Terminal	P-235886 P-235866 P-235866 P-115586 P-235869 P-114485 P-235867 P-119251 P-157519 P-235870 P-244445 P-235883 P-124619	P-235861 P-235866 P-235865 P-115586 P-235869 P-235869 P-114485 P-235867 P-119251 P-157519 P-235870 P-2444445 P-235883 P-124619	P QR S T U V X Y Z AA	Resistance—Ward Leonard Relay—Start Relay—Stop Telechron Motor— Type B3, 1 RPS Lamp Lamp Socket Base Terminal Spring Key Panel—Red Buttons Key Panel—White Buttons Key Panel—Black Buttons Base—Complete Cover Circuit Label	Type O- 45 Ohms R-1027 R-332 60 cycles 110 volts No. 2F No. 13A P-235856 542A Key 542B Key P-235859 P-235843 P-235843	Type O- 45 Ohms R-1027 R-332 60 cycles 110 volts No. 2F No. 13A P-235856 543A Key 541A Key P-235859 P-235843 P-244442

Selector Keys (Continued)



63 Type Selector Key

Symb		63A Selector Key	63B Selector Key	Symbol	Subject	63A Selector Key	63B Selector Key
ABCDEFGHIJKLMNO	Distributor Panel, Complete Terminal Plate, Complete Inner Segment Segment Segment Segment Serew Contact Arm Contact Spring Contact Spring Gear Gear Mounting Screw Pinion Mounting Screw Pinion Designation Card Window Terminal	P-235886 P-235866 P-235866 P-115586 P-115586 P-235869 P-114485 P-235869 P-119251 P-157519 P-235870 P-244445 P-235887 P-235887	P-235886 P-235866 P-235866 P-235865 P-115586 P-235868 P-235869 P-114485 P-235867 P-1157519 P-235870 P-235870 P-244445 P-235883 P-124619	Q R R R S T T L U L V C X K Y K Z K	esistance—Ward Leonard telay—Start telay—Stop elechron Motor— Type B3, 1 RPS amp amp Socket over Support tey Panel—Red Buttons tey Panel—White Buttons tey Panel—Black Buttons over ircuit Label	Type O- 45 Ohms R-1027 R-332 60 cycles 22 volts No. 13A P-235850 542A Key 541A Key F-235842 P-244443	Type O-45 Ohms R-1027 R-332 60 cycles 22 volts No. 2F No. 13A P-235850 543A Key 541B Key 5-43B Key P-235842 P-244444

Selector Key Cases



No. 60E Selector Key Case



No. 60A Selector Key Case

Code No.	Capacity Keys	Description	Dimensions
60A	24	Cabinet for mounting No. 60 Type Selector Keys. Four rows of six keys per row. Woodwork golden oak finish.	$12^{3}\%_{4}$ in. x $15\frac{1}{4}$ in. x $5\frac{5}{6}$ in.
60B	36	Cabinet for mounting No. 60 Type Selector Keys. Four rows of nine keys per row. Woodwork golden oak finish.	123% in. x 21¼ in. x 55% in.
60C	48	Cabinet for mounting No. 60 Type Selector Keys. Four rows of twelve keys per row. Woodwork golden oak finish.	$12^{3}\%_{4}$ in. x $27\frac{1}{4}$ in. x $5\frac{5}{8}$ in.
60D	60	Cabinet for mounting No. 60 Type Selector Keys. Four rows of fifteen keys per row. Woodwork golden oak finish.	123%4 in. x 331/4 in. x 55% in.
60E	12	Cabinet for mounting No. 60 Type Selector Keys. Three rows of four keys per row. Woodwork golden oak finish.	128% in. x 55% in. x 55% in. x

Selector Key Spaces

Code No.	Description	Used In
50A	Key spaces, black finish.	Nos. 50A, B and C, and Nos. 60A, B, C, D and E Selector Key Cases in spaces not equipped with keys.

Selector Sets

The following selectors and associated apparatus are the older type DC and are listed for convenience in ordering sets for maintenance and extensions to existing circuits:

Code No. *101A	Equipment Box equipped with: 1 No. 101402 Bell. 2 No. 51F Retardation Coils. 1 No. 21U Condenser. 1 No. 1F Resistance. 1 No. 50A Selector.	Dimensions $13\frac{3}{4}$ in. $\times 9\frac{1}{4}$ in. $\times 6\frac{1}{4}$ in.	Used At Way stations on train dispatching circuits operated on central energy basis.
*101B	Same as No. 101A, except equ	ripped with No. 50B Selector	
**102A	Box equipped with: 1 No. 101404 Bell. 2 No. 51F Retardation Coils 1 No. 5G Resistance. 1 No. 50A Selector. Arranged for, but not equipped with two dry cells.	19¾ in. x 9¼ in. x 6¼ in.	Way stations on train dispatching circuits operated on local battery basis.

Selector Sets (Continued)

**102C

**102C

**102C

**102C

**102C

Similar to No. 102A

Similar to No. 102Z.

1 No. 50C Selector.

1 No. 101404 Bell.

1 No. 190M Relay.

1 No. 5G Resistance.

2 No. 51F Retardation Coils.

1 Special No. 43 Retardation Coil.

*Nos. 101A and 101B Sets are arranged for, but not equipped with, two No. 34A Resistances.

**Nos. 102A and 102C Sets are arranged for but not equipped with, one No. 34A Resistance. These resistances are ordered separately in accordance with the circuit requirements.

AC Selector Sets

RECOMMENDED FOR ALL NEW INSTALLATIONS



No. 160C Selector Set Equipped with No. 60 Type Selector

Code No

Equipment

2 No. 26A Gongs.

Code No.	Equipment	Dimensions	Used At
160C	Metal Box equipped with: 1 No. 60CG Ringer. 1 No. 138B Condenser. 1 No. 141H Condenser.	13 in, x 7 in, x 5⅓ in.	Way stations on AC train dispatching and message circuits when condensers are desired in the selector circuit. For use with No. 60AP or BP Selector. Replaces Nos. 160AC and BC Selector Sets.
160R	Metal Box equipped with: 1 No. 60CG Ringer. 1 No. 141H Condenser.	13 in. x 7 in. x 5⅓ in.	Same as No. 160C except it is used when selectors are operated through repeating coils. For use with No. 60AP or BP Selector. Replaces Nos. 160AR and BR Selector Sets.

Note: The Nos. 160C and 160R Selector Sets consist of a housing and the necessary associated apparatus and wiring for mounting a No. 60AP or BP Selector. The selector, however, is not furnished as a part of the set and must be ordered separately.


the	set and must be ordered separately	
161	Wooden Box equipped with 1 No. 60AP Selector 1 No. 47A Repeating Coil. 2 No. 21AB Condensers. 1 No. 21U Condenser. 2 No. 51F Retardation Coil 1 No. 60C Ringer	Way stations in intercall circuits with No. 61A Selector Apparatus Case and No. 61A Selector Key.



No. 1B Foot Switch



No. 1A Foot Switch Attachment



No. 1A Booth Switch

Booth Switch

Description

Code No.

1A For disconnecting siding telephones from the line when the telephone is located in a locked booth. Operates when hasp is placed over the staple and held in place by padlock.

Foot Switches


Code No.	Springs	Used
1B	Makes one contact.	In dispatcher's telephone set.
3B	Makes two and breaks one contact.	In way station telephone sets.
3C	Makes three and breaks two contacts.	In way station telephone sets with No. 501B Desk Set Boxes.
3D	Makes four and breaks two contacts.	In towers with No. 501B Desk Set Boxes and No. 6052A Amplifier.

Foot Switch Attachments

Use and Description


No.	Inches	
1A	12	With all types foot switches.
1B	24	With all types foot switches.
2A	23	A ¾ inch black enameled conduit equipped with a ¾ inch T. & B. bushing (List No. 97760) at one end also includes pipe strap No. 97295 and two wooden screws for mounting. Used to protect wires entering foot switches.

Switchhooks






No. 140AG Nos. 143AA & AC Switchhooks



Nos. 140S, 143J, Nos. 140W and Y and AE 143AB Switchhooks



No. 140S Switchhook

Switches (Continued)

Code No.	Description		
140S	Black finished, self contained switchhook. See illustration for spring arrangement.		
140W	Black finished. Similar in design to No. 140S. See illustration for spring arrangement.		
140AG	Black finished. Similar in design to No. 140S. See illustration for spring arrangement.		
143J	Black finished, self contained switchhook. All parts treated to effectively resist the action of moisture and fumes. See illustration for spring arrangement.		
143Y	Same as No. 143J except not moisture-proofed.		
143AA	Black finished, self contained switchhook. Similar in design to No. 143Y. See illustration for spring arrangement.		
143AB	Black finished. Similar in design to No. 143Y. See illustration for spring arrangement.		
143AC	Black finished, self contained switchhook. For use with the head band type of receiver. See illustration for spring arrangement.		
143AE	Black finished. Similar in design to No. 143AC. See illustration for spring arrangement.		

Push Button

Code No.	Description	Used In
1003A	Breaks one and makes two contacts	Nos. 1293AD, AE, AK, AL, 1317W, AD, AE, AW and 1336F Telephone Sets.
1006A	Breaks one and makes one contact.	No. 1317BA Telephone Set.
1013A	One break before make and one break before two make contacts are operated.	No. 1317BU Telephone Set.
1014A	One set of break before make-make contacts and one set of break before make contacts.	No. 501A Subscriber Set.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS TELEPHONE SETS



No. 1278G Telephone Set

No. 1293AD Telephone Set

No. 1305AC Telephone Set

NOTE: Batteries are not supplied with telephone sets and should be ordered separately.

1293AK 1293AL 1293BC

1305AC

1312A

6023A

Code No.	Description		
1278G	Weatherproof metal set particularly adringer. Includes:	apted for street railway service. Five bar AC generator and 1000 ohm unbias	sed
	1 No. 48C Generator	2 500 volt, 1 ampere Fuses.	
	1 No. 25E Repeating Coil.	1 No. 5B Lock.	
	1 No. 29 Induction Coil.	1 Door Switch for opening circuit when door is closed.	
	2 No. 1 Protector Blocks.	1 Special No. 51AG Ringer.	
	2 No. 2 Protector Blocks.	1 No. 1001H Hand Set.	
*******	2 No. 2 Protector Micas.	2 Dry Cells furnished only when ordered. battery mounted separately. Provided with high efficiency transmission circumstance.	iit
1293AD	For use as siding telephone on train	dispatching circuits. Employs push buttons for use when talking. Contains	:
	1 No. 4BG Ringer.	1 No. 143AA Switch Hook for 13 in. mounting.	
	1 No. 21AA Condenser.	1 No. 3E Transmitter Bracket.	
	1 No. 29 Induction Coil.	1 No. 508 Receiver with 2 ft. No. 446 Cord.	
	1 No. 51A Retardation Coil.	1 No. 349 Transmitter.	
	1 No. 1003A Push Button for 1/8 in.	mounting 2 No. 329 Cords, 6 in.	
	Code No.	Description	
	1293AE	For use on sidings. Contains:	
		1 No. 349 Transmitter 1 No. 29 Induction Coil.	
	THE RESERVE OF THE PARTY OF THE	1 No. 186 Receiver. 2 No. 329 Transmitter Cords,	



No. 1312A Telephone Set

For use on sidings. Contains:	
1 No. 349 Transmitter	1 No. 29 Induction Coil.
1 No. 186 Receiver.	2 No. 329 Transmitter Cords.
1 No. 546 Cord, 2 ft. long.	6 in. long.
1 No. 4BG Ringer.	1 No. 1003A Push Button.
1 No. 21AA Condenser.	1 No. 51A Retardation Coil.
1 No. 143AC Switchhook.	1 No. 3E Transmitter Bracket.
Same as the No. 1293AD, less ringer.	
Same as the No. 1293AE, less ringer.	
	attery telephone set designed for use or
lines where a large number of sets a	re required. Black finished. Contains
1 No. 3E Transmitter Bracket.	2 No. T1A Cords, 6 in.
1 No. 21AL Condenser.	1 No. 189 Receiver.
1 No. 42 Induction Coil.	1 No. 349 Transmitter.
1 No. 1013A Push Button.	1 No. 546 Cord, 2 ft.
1 No. 143AE Switchhook.	
Code ringing, insulated magneto set in and other miscellaneous circuits. A	ntended to be used on railroads in block rranged so that a condenser can be con-

and other miscellaneous circuits. Arranged so that a condenser can be connected in the receiver circuit if desired. Consists of:

1 No. 48BG Ringer.

1 No. 48G Generator

(insulated crank)

1 No. 3B Transmitter

Bracket per D-6169.

1 No. 446 Cord, 2½ ft.

Bracket per D-6169.

2 No. 385 Cords, 7 in.

1 Special Induction Coil per D-757.

Arranged for but not equipped with No. 21 type Condensers.

Standard wall type composite telephone set. Contains:

1 No. 21D Condenser.

1 No. 21D Condenser.

1 No. 21D Condenser.

1 No. 21D Condenser.

1 No. 121D Condenser.

1 No. 21D Condenser.

1 No. 21D Condenser.

1 No. 21D Condenser.

2 No. 390B Key.

1 No. 5 Induction Coil.

1 Interrupter P-101495.

2 ½ ft. No. 521 Receiver Cord.

1 No. 604A Transmitter.


1 No. 144 Receiver.

Desk type composite telephone. Consists of:

1 No. 311A Desk Set Box

Desk type composite telephone. Consists of:

: 1 No. 311A Desk Set Box. 1 No. 1040U Desk Stand. 1 No. 8D Connecting Block. 1 No. 465A Key



No. 1317 Telephone Set (Closed)

Telephone Sets (Continued)



No. 1317 Telephone Set (Open)

```
Description
  Code No.
                           Local battery wall telephone for heavily loaded lines where code ringing is employed. Contains:

1 No. 323 Transmitter.
1 No. 144 Receiver.
1 No. 144 Receiver.
1 No. 521 Receiver Cord, 2½ ft.
2 No. 143 Y Switchhook.
2 No. 540 Cords.
1 No. 13 Induction Coil.
1 No. 8A Transmitter Bracket.
  1317P
  13175
                           Same as No. 1317P, excepting that a No. 21W Condenser is wired in series with the receiver.
                           Same as No. 1317P, excepting that a No. 21W Condenser is wired in series with the receiver.

Wall type telephone set for use on standard railway dispatcher's telephone circuits at sidings and similar places for use of conductors and trainmen. Provided with high efficiency transmission circuit. Employs push button for use when talking. Five bar AC generator and 2500 ohm unbiased ringer. Contains:

1 No. 48A Generator.

1 No. 18A A Switchhook.

1 No. 103A Push Button for % in. woodwork.

1 No. 21AA Condenser.

1 No. 29 Induction Coil

1 No. 349 Transmitter.

1 No. 446 Receiver Cord, 2 ft.

1 No. 349 Transmitter.

1 No. 508 Receiver.

2 No. T1A Cords, 6 in.

2 No. 500 Cords.
  1317W
                          Same as No. 1317W Telephone Set, excepting No. 38BG Ringer is omitted. Can be equipped with No. 38 Type Ringer if desired.
 1317AD
 1317AE
                          Same as No. 1317W Telephone Set, excepting No. 38BG Ringer is omitted and set is equipped with head receiver.
                           Wall type local battery telephone for moderately loaded lines where code ringing is employed. Three bar AC generator and 1000 ohm unbiased ringer. Contains:
 1317AH
                               1 No. 22A Generator.
1 No. 38AG Ringer.
1 No. 143Y Switchhook.
1 No. 13 Induction Coil.
1 No. 8A Transmitter Bracket.
                                                                                                                                                               1 No. 521 Cord, 2½ ft.
1 No. 323 Transmitter.
1 No. 144 Receiver.
2 No. T1A Cords, 6 in.
2 No. 540 Cords.
 1317AW
                          Same as No. 1317W, excepting that it is equipped with:
                               1 No. 143AC Switchhook for ½ in. mounting. 1 No. 186 Head Receiver.
                                                                                                                                                                2 No. 546 Receiver Cords.
                          For use on telephone lines exposed to high tension wire. Ringer is omitted and generator handle is insulated. All metal parts arranged for grounding. Contains:
1317BK
                              1 No. 359 Transmitter.
1 No. 144 Receiver.
1 No. 521 Cord, 2½ ft.
2 No. 540 Cords.
2 No. T1A Cords, 6 in.
1 No. 21W Condenser.

    No. 13 Induction Coil.
    Special No. 48R Generator
per D13730.
    Switchhook D19513 for

                                                                                                                                                               ½ in. woodwork.
1 No. 8A Transmitter Bracket.
1317BU
                          A highly efficient telephone set designed for use on lines where a large number of sets are required. For use primarily in railroad work and employs a head band receiver. Contains:
                             in railroad work and employ

1 No. 42 Induction Coil.

1 No. 21AL Condenser.

1 No. 143AE Switchhook.

1 No. 1013A Push Button

1 No. 1013A Push Button

1 Special No. 48A Generator.
                                                                                                                                                              1 No. 349 Transmitter.
1 No. 189 Receiver.
1 No. 546 Cord, 2 ft.
2 No. T1A Cords, 6 in.
2 No. 540 Cords.
1 No. 584 Transmitter
Bracket.
```


Telephone Sets (Continued)

Code No.	Description
1317CN	For use on medium loaded code ringing lines. Arranged for two cells of dry batteries. Contains: 1 No. 143Y Switchhook for ½ in. woodwork. 1 No. 323 Transmitter. 1 No. 144 Receiver. 1 No. 521 Cord, 2½ ft. 1 No. 8A Transmitter. 1 No. 8A Transmitter. 1 No. 540 Cord. Bracket. 1 Special No. 53FG Ringer. 1 Special No. 53FG Ringer.
1317CG	Same as No. 1317CN, except furnished with No. 53AG Ringer. For use on lightly loaded lines, code ringing.
1317CP	Same as No. 1317CN, except furnished with a Special No. 53BG Ringer (2500 ohms). For use on heavily loaded lines, code ringing.
1317CR	Same as No. 1317CN, except equipped with a Special No. 40F Generator and a Special No. 21W Condenser in the receiver circuit.
1317CS	Same as No. 1317CP, except equipped with No. 21W Condenser in receiver circuit.
1317DU	Same as No. 1317BU, except No. 48 type Generator is omitted.

Portable Telephone Sets



No. 1314A Portable Set



No. 1314A Set Open front view)

Code No.

1314A

Portable composite telephone set. Contains:

ortable composite Relephone set. Co.

1 No. 12M Retardation Coil.

1 No. 140F Switchhook.

1 Special No. 390 Key per D11567.

1 No. 21D Condenser.

1 No. 21H Condenser.

1 No. 1B Howler.

1 No. 3B Binding Post.

3 Special No. 3C Binding Posts per D51199
1 No. 384 Cord, 3 ft.
1 No. 179 Cord, 8½ in.
1 No. 267 Cord with rail clamp, 10 ft.
1 No. 5 Induction Coil.
1 Interrupter P101495.
1 No. 606A Transmitter
1 No. 133 Receiver.

Arranged for but not equipped with four standard dry batteries unless specified in order. The weight of the set complete is about 26 lbs. Approximate dimensions 11½ x 12 x 7½ inches. No. 4 Line Pole used but should be ordered separately.

Description



No. 1330E Telephone Set



No. 1330F Portable Set

Portable Telephone Sets (Continued)

Code No.

1330E

Portable railway magneto telephone set. For use on long heavily loaded lines. Used with Nos. 3 or 5 Line Poles. Five bar AC generator and 2500 ohm biased ringer.

1 Special No. 48A Generator.
1 No. 32BG Ringer.
2 Special No. 2C Binding Posts.
1 No. 29 Induction Coil.
1 No. 1001C Hand Set.
The weight of the set complete is about 28 lbs. The size is 12½ x 13½ x 5½ inches.

1 No. 1330E Telephone Set, except that it is equipped with:
1 No. 146 Plug and One 6 ft. No. 509 Cord for making connection with line through No. 186 Jack.
Condenser furnished only when specified.

1 No. 38 2500 ohm Buzzer.
1 No. 39 2500 ohm Buzzer.
1 No. 39 2500 ohm Buzzer.
1 No. 29 Induction Coil.
2 No. 20 Binding Posts.
1 No. 21F Condenser.
1 No. 21F Condenser.
2 No. 790 Eveready dry batteries furnished only when specified in order.
The weight of the set complete is about 17 lbs. The size is 11½ x 10½ x 4¾ inches.

1331F

Same as No. 1331E Telephone Set, excepting that it is equipped with:
1 No. 21F Condenser.
1 No. 22F Condenser.
2 No. 22F Condenser.
3 No. 21F Condenser.
4 No. 23F Condenser.
5 No. 1331E Telephone Set, excepting that it is equipped with:
1 No. 146 Plug.
1 No. 509 Cord, 6 ft. long, for making connection to the line through 186 or 187 Jacks.



No. 1332A Portable Set



No. 1375B Portable Set

Code No.

132A

Telephone Set in portable leather case with a shoulder carrying strap. For use in connection with Nos. 3 or 5 Line Poles on train dispatching circuits. Contains:

1 No. 29 Induction Coil.
1 No. 21BW Condenser.
2 No. 792 Eveready dry batteries furnished only when ordered.

The complete set weighs approximately 6 lbs. The size is 93/6 x 71/8 x 4 inches.

1332E

Same as No. 1332A, excepting that it is equipped with a No. 3B 2500 ohm Buzzer.

Telephone Set in portable leather case with adjustable hand or shoulder carrying strap. Apparatus moisture-proofed and mounted on an aluminum frame. Contains:

1 No. 1001H Hand Set.
1 Special No. 2150 ohm Buzzer (D21141).
1 Special No. 31 Induction Coil (D17624).
1 No. 703 Eveready Battery.

Complete set weighs approximately 10½ lbs. The size is 9% inches high, 3% inches deep and 6% inches wide. This telephone set can be equipped with the No. 1001G Hand Set where a lighter weight is desired.


Local battery, portable, moisture-proof, magneto telephone set enclosed in wooden case and equipped with a handle or shoulder strap. Contains:
1 No. 29E Generator.
1 No. 21K Condenser.
1 No. 31 Induction Coil (D17624).
1 No. 703 Eveready Battery.
1 No. 704 Eveready Battery.
1 No. 705 Eveready Battery.
1 No. 706 Eveready Battery.
1 No. 707 Eveready Battery.
1 No. 708 Eveready Battery.
1 No. 708 Eveready Battery.
1 No. 709 Eveready Battery.

Telephone Sets (Continued)

Weatherproof Telephone Sets



No. 1336F Closed



No. 1336F Open

Code No.

1336F

Description

- An iron box, local battery telephone set for heavily loaded lines for use out of doors on train dispatching circuits. Provided with high efficiency transmission circuit. All parts treated to effectively resist the action of moisture and fumes. Employs push button for use when talking. Five bar AC generator and 2500 ohm unbiased ringer. Contains:
 - 1 No. 48C Generator.
 - No. 143K Switchhook.
 - No. 45BG Ringer.
 - No. 32 Induction Coil.

 - 1 No. 601A Transmitter.

- 1 No. 51B Retardation Coil.
- 1 No. 21AA Condenser.

- 1 Special No. 1002A Push Button.
- 1 No. 508 Receiver.
- 2 No. 385 Transmitter Cords.
- 1 No. 384 Receiver Cord, 101/2 in.
- 1 No. 540 Cord.
- 3 1/2 x 3/8 x 21/4 inch leather cable holders.
- 2 Dry cells (when specified in the order).

1336H Circuits are arranged so that it is unnecessary to use a push button for talking. Contains:

- 1 No. 144 Receiver.
- 1 No. 601A Transmitter.
- 1 No. 540 Cord.
- 1 No. 384 Cord, 101/2 in.
- 2 No. 385 Cords, 7 in.

- 1 No. 48C Generator.
- 1 No. 45BG Ringer.
- 1 No. 21AA Condenser.
- 1 Special No. 30 Induction Coil.
- 1 No. 143AA Switchhook.

TELEPHONE OUTFITS

LOUD SPEAKING

No. 12A Loud Speaking Telephone Outfit

The No. 12A Loud Speaking Telephone Outfit is intended for use in train dispatching circuits at Dispatchers' Stations and consists of

No. 519A Subscribers Set.
 No. 216A Vacuum Tube.

1 No. 543W Receiver.

Note: A No. 579A Loud Speaking Telephone or a KS6368 Horn with a No. 549 Receiver may be used in place of the No. 543W Receiver in this outfit.

No. 519A SUBSCRIBERS SET

The No. 519A Subscribers Set consists of an oak cabinet 91/4 inches wide, 163/4 inches high and 63/6 inches deep in which is mounted the following apparatus:

1 No. 100L Vacuum Tube

Socket

No. 19DP Resistance.

No. 19DR Resistance.

No. 19DN Resistance. No. 34H Resistance.

1 No. 100A Retardation Coil.

No. 43 Induction Coil. No. 44 Induction Coil.

No. 218F Input Transformer.


No. 21AK Condensers.

No. 21F Condensers. No. 21D Condenser.

1 No. 272A Key.

The No. 519A Subscribers Set functions similarly to the No. 502A Subscribers Set and in addition is equipped with one stage of amplification which is operated on a direct current power supply. This set operates with a No. 543W Loud Speaking Receiver.

The set is provided with a key to switch in either the loud speaker or a regular dispatcher's head receiver. The amplification is such that satisfactory volume may be obtained over a 200 or 300 mile line (open wire).



Schematic of No. 519A Subscribers Set

DIRECTIONS

Make connections to line, foot switch, jack box, transmitter battery and amplifier "A" and "B" current supplies as indicated. Adjust current through filament of tube to approximate .95 ampere by means of R3 and R4. This current may be measured on an ammeter connected across terminals 13 and 14 with the strap between these two removed. After adjusting current, strap should be replaced. To adjust for loudness connect flexible leads from terminals 20 and 22 across different sections of R1 until desired volume is obtained. Connect flexible lead from terminal 21 across enough of R1 so that when foot switch is operated to talk, the set does not sing and the volume is not too great.

No. 216A VACUUM TUBE

A No. 216A Vacuum Tube is required for this set but is not a part of it. The heating current for the filament of the tube may be derived from either 6 volt AC or DC source of energy. The tubes are sold only with the No. 12A Loud Speaking Telephone Outfit or as a replacing part.

No. 6052A AMPLIFIER.

The No. 6052A Amplifier is used in conjunction with a No. 501B Desk Set Box at Way Stations and with a No. 502A Desk Set Box at Dispatchers' Stations.


No. 6040A AMPLIFIER.

The No. 6040A Amplifier being electrically the same as the No. 6052A except for the frequency of the power source required for its operation, may be used under otherwise identical conditions.

Note: For further information regarding Loud Speaking Telephone Equipment see Page 18.

TIME SENDING SET

No. 60A TIME SENDING SET



Schematic of No. 60A Time Sending Set



No 604 Set

The 60A Time Sending Set is intended for use in conjunction with the 60B Selector Apparatus Case and the time repeating relay at the dispatcher's station, to transmit time impulses over the system so that the bell in each of the way station sets will tap and give a signal corresponding to each closure of the local

contact of the time repeating relay.

Consists of a black finished metal surface cabinet containing a black phenol fibre mounting plate on which is mounted the following equipment:

No. R1971 Relay.
 No. 149AN Relay.

DPDT Rotary Snap Switch. 4 No. 63C Resistances.

Approximate overall dimensions are 6 16" wide x 75%" high x 614" deep.

Entirely replaces the D14386 Time Sending Set.

For further information regarding the operation of this equipment refer to Page 14.

NO. 341A TRANSFORMER



No. 341A


The No. 341A Transformer has a shell type silicon steel core clamped between angle iron brackets which also provide a mounting for the transformer and for the terminal connecting block.


Code	No. of	No. of Wind-	Resista	nce, Ohms	Approx.	Approx.
No.	Coils	ings Each Coil	Primary	Secondary	Dimensions	Weight
341A	1	$4{2 \text{ Primary} \choose 2 \text{ Secondary}}$	90	175	$\left\{ {6'' \times {5 \choose 8}'' \atop \times 53 / 4''} \right\}$	20 lbs.

The primary windings and the secondary windings are each balanced from a resistance, inductance and capacity standpoint to within 200 crosstalk units to permit the coil to be used on simplexed telephone circuits arranged for duplex telegraph without interference from the telegraph on the side or phantom telephone circuits.

Note: The No. 341A Transformer is especially designed for repeating the low frequency (3½ cycles) selector impulses for long lines with a large number of selectors. The impedance at 900 cycles of the two secondary windings connected in series aiding is approximately 6,000 ohms and of the two primary windings in series aiding is approximately 12,000 ohms. The loss from bridging the transformer on a line as a simplex bridge is, therefore, very small. The loss in telephone transmission due to inserting this transformer in the center of an electrically long line of No. 9 B & S non-loaded open copper wire is approximately 5 decibels.

TRANSMITTER ARMS





	No. 1020CC Trans. Arm	No. 1048DD Trans. Arm
Code No.	Description	
1020CC	For regular local or central battery service.	Used on flat top desks. Includes:
	1 No. 20CC Transmitter Arm.	1 No. D3A Cord, 8 ft.
	1 No. 323 Transmitter.	1 No. R2A Cord, 2½ ft.
	1 No. 144 Receiver.	2 No. T1A Cords, 12 ins.
1020C	For way station use on train dispatching cir	rcuits, Includes:
	1 No. 20C Transmitter Arm.	1 No. 409 Cord, 8 ft.
	1 No. 349 Transmitter.	1 No. 554 Cord, 2½ ft.
	1 No. 186 Receiver.	1 No. 426 Cord, 12 in.
******		1 No. 427 Cord, 12 in.
1020E	Includes:	
	1 No. 20E Transmitter Arm.	1 No. R2U Cord, 2½ ft.
	1 No. 349 Transmitter.	1 No. 416 Cord, 8 ft.
	1 No. 186 Receiver.	2 No. 427 Cords, 12 in.
1048DA	Adjustable folding arm, having telephone sedesk. Includes:	et incorporated in it. Mounts on side of a roll top
	1 No. 148DA Transmitter Arm.	1 No. 186 Receiver.
	1 No. 349 Transmitter.	1 No. 409 Cord, 8 ft.
		1 No. 554 Cord, 2½ ft.
1048DB	Adjustable folding arm, having telephone so desk or on wall. Includes:	et incorporated in it. Mounts on sides of flat top
	1 No. 148DB Transmitter Arm.	1 No. 186 Receiver.
	1 No. 349 Transmitter.	2 No. 427 Cords, 91/8 in.
1048DC	Same as No. 1048 DA, except mounts on to	p of flat top desk.
1048DD	Same as No. 1048DA except mounts on wall where it is desired to place a flat top dwall.	in way stations
1048GA	Equipped with a No. 349 Transmitter, No. No. 416 Cord, 8 ft., No. 554 Cord, 2½ ft.	, No. 330 Cord, Train dispatching at way sta-

91/8 in. long. Mounts on side of roll top desk. 1048GB

Same as No. 1048GA except mounts on wall or side of flat top desk. Same as No. 1048 GA except mounts on top of flat top desk. 1048GC

Same as No. 1048GA except mounts on wall in way stations where it is desired to place a flat top desk against the wall. 1048GD

Transmitter arm same as the No. 1020C except that the 189 Receiver is used instead of the No. 186. 1120C

Same as No. 1048DA except that it is equipped with low wound No. 189 Receiver. 1148DA

Same as No. 1048DB except that it is equipped with low wound No. 189 Receiver. 1148DB

Same as No. 1048DC except that it is equipped with low wound No. 189 Receiver. 1148DC

Same as No. 1048DD except that it is equipped with low wound No. 189 Receiver. 1148DD

tions with a desk set box employing a four conductor cord and an induction coil having the primary and secondary windings insulated from each other.

Used at way stations with the Nos. 501A and B Desk Set Boxes.


Used with Nos. 501A and B Desk Set Boxes.

Used with Nos. 501A and B Desk Set Boxes.

Used with No. 501A and B Desk Set Boxes.

Used with Nos. 501A and B Desk Set Boxes.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS TRANSMITTER ARM BRACKETS



Transmitter Arm Brackets

Code	Dimensions, Inches							
No.	Description	Length of Rod	Overall Length	Use				
2A	Consists of an iron base equipped with a steel rod about which the arm rotates	71/16	10^{25} ₃₂	Mounts on the side of roll top desks.				
2B	Same as the No. 2A except equipped with a collar assembled on the rod for the purpose of stopping the rotation of the transmitter arm in any one of the four predetermined positions.	7½ ₆	15½	Mounts on wall or side of flat top desks.				
2C	Similar to the No. 2A.	$71/_{6}$	10^{25} ₃₂	Mounts on the top of a flat top desk.				

TRANSMITTER BRACKETS

Code No.	Description	Use
3E	For mounting insulated transmitters.	Nos. 1293AD, AE, AK, AL and 1305AC Telephone Sets.
8A	Black finish bracket, for mounting transmitters on wooden telephone sets.	Nos. 1317P, S, W, AD, AH, AW, AE, BU, CN, CP, CR, CS and CG Tele- phone Sets.

TOOLS



Code	
No.	Description
48	Used for adjusting Nos. 50A and 50B Selectors. Consists of a wrench and screw driver. Will fit 1/4 inch and 1/2 inch nuts.
115	Used for changing Nos. 50A and 50B Selectors to call different stations. It is a small double ended tool, one end consisting of a wrench for ¼ inch hexagonal nut; the other end a small wire hook.
144	Used for changing Nos. 60A, 60B, 60AP and 60BP Selectors to call different stations. Consists of a socket wrench and screw driver.
145	Used for changing Nos. 60A and 60B Selectors to call different stations. Small double ended tool, one end consisting of a wrench for ½ inch hexagonal nut; the other end a small wire hook.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS TESTING APPARATUS

Test Sets



No. 60B Test Set



No. 1017 Type Test Set

Code No. 60B

Description

Intended for use in the field for electrically testing No. 60 type Selectors and No. 160 type Selector Sets. Consists of a black finished metal box having a hinged cover and a carrying handle. Contains a fibre panel on which are mounted the following:

1 Weston No. 506 Milliammeter.
1 Polynet Type VC 1946 Wire Wound Volume Control.
3 No. 92 Type Keys.
1 No. R323 Relay.
1 No. 138B Condenser.
2 No. 768 France in Patterior and in the following the following the following in the following the

3 No. 768 Eveready Batteries required (must be ordered separately). 8 Terminal Punchings.

The terminal punchings are provided for use in making external connections to the Nos. 60, 61 or 62 type Selector Keys. An opening in the panel and other means are provided for internally connecting in the test circuit, a No. 60 type Selector Key when it is desired to use this key in this manner for operating the selector under test.

Approximate overall dimensions of the No. 60B Test Set with cover closed, are 8½" long, 6" deep and 9" high. Approximate weight including batteries 14 lbs.

NO. 1017C TEST SET consists of a wooden box telephone set equipped with a regular battery talking circuit consisting of a standard transmitter, induction coil, receiver and a special three cell dry battery unit. It can be used either on magneto or central battery lines. Will ring through 5,000 ohms. Contains:

Code No.

1017C

No. 2D Buzzer. No. 29F Generator. No. 572 Cord.

No. 13 Induction Coil.

No. 515 Receiver.
 No. 266 Transmitter.

Description

1 No. 703 Eveready Battery
(must be ordered separately)

1 Special Switch.
2 No. 2C Binding Posts.

THE NO. 1017E TEST SET is similar to the No. 1017C except it is equipped for use on either composited or straight telephone lines. Contains:

1017E

*1 No. 29F Generator. 1 No. 2E Buzzer. 1 No. 515 Receiver.

No. 13 Induction Coil. 1 No. 266 Transmitter.

1 No. 714 Eveready Battery (must be ordered separately).

1 No. 572 Cord, 2 ft. 1 No. 6000A Interrupter.

* This generator will operate a No. 56A Drop through 11,500 ohms resistance.

The above sets have a birch mahogany finish. Size of case, length 63/2", width 43/2" and height 73/2". Weight 7 lbs

D86418

Similar to a No. 1017E Test Set except that it includes an exploring coil, special switching device, and a modified circuit for controlling the test tone for the exploring coil. This set is intended to fulfill the standard uses for the No. 1017 Type Test Sets and in addition includes a fault direction locating feature for use in testing open wire lines. The No. 515 Receiver and No. 266 Transmitter are required for operation but must be ordered separately.

Testing Apparatus (Continued)



No. 43A Test Set



No. 1020C Test Set

CABLEMAN'S TEST SET

Code No.

Description

43A

Splicer's Portable Test Set. Intended for use in connection with the installation and maintenance of cable in manual or dial telephone areas. Consists of a buzzer circuit which provides tone for identifying wires for balance testing and for running down resistance faults on short non-loaded cable by the exploring coil method; together with auxiliary circuits which provide for a battery for detecting defective pairs by receiver battery tests or for energizing the transmitter of a talking set and a ringer buzzer by means of which the splicer may be called from a central office when communication with him is desired. Woodwork birch, finish olive-green. Contains:

- 10 Binding Posts.

 1 No. 21F Condenser.

 1 No. 21R Condenser.

 1 No. 2D Buzzer.

- SPST Snap Switches. 2 No. 1AG Resistances.

No. 15 Lungen Buzzer, Size No. 2, wound to 40 ohms.
 No. 771 Eveready Batteries required (must be ordered separately).
 No. 13 Induction Coil.

1020C

1120C

Designed for use by cable repairmen as a portable test set for locating shorts, grounds, crosses, split pairs and wet spots in cables. The case has a birch mahogany finish and weighs 12½ lbs. without batteries. Size 12½ "wide, 6½" deep and 10½" high. Consists of the Nos. 20C and 1019C Test Sets, the latter being contained in the case of the former:

THE NO. 1019C TEST SET consists of the No. 19C Test Set equipped with one No. 747 Cord, one No. 186 Plug and one No. 528 Receiver.

THE NO. 19C TEST SET consists of an exploring coil, a condenser and three jacks enclosed in a nickel silver case.

THE NO. 20C TEST SET consists of the following apparatus:

1 Interrupter.

3 No. 540 Cords 1 No. 18AC Resistance. 1 No. 21K Condenser.

1 2-Point Switch.4 Dry Cells (must be ordered separately).

1 Vibrator.

This Test Set is the same as the No. 1020C Test Set except that it contains a No. 1119C Test Set instead of a No. 1019C.

THE NO. 1119C TEST SET consists of a No. 19C Test Set equipped with one No. 584 Cord, one No. 186 Plug, one No. 1A Headband and two No. 502 Receivers.

SWITCHING AND TESTING PANELS

We are prepared to furnish switching and testing panels to take care of any requirements. These panels are equipped with switches and are used for testing and patching purposes on train dispatching and simplexed block circuits.

Prices furnished on request.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS TRANSMITTERS







Head Telephone Set with No. 386 Transmitter



No. 285 Transmitter



No. 353 Transmitter



No. 3A Transmitter Attachment

Code No.	Description
244	An insulated high resistance nickel finish transmitter. Con- sists of a cylindrical brass case with a perforated metal mouth piece and an inner case. Provided with No. 16 Button.
266	An insulated high resistance nickel finish transmitter, provided with aluminum punch cover, but without a mouth piece so that it can be mounted inside of a box. Cords enter through brass bushing on the lower side. Equipped with No. 9 Button.
285	An insulated low resistance transmitter similar to the No. 244. Uses a special No. 16 Button. Nickel.
323	A high resistance insulated black finished transmitter, provided with mounting lug and clamping bolt. Replaces Nos. 291W 317W and 329W Transmitters.
349	An insulated black finished transmitter similar to the No. 323 except that it is equipped with a low resistance button. Replaces No. 280W, also No. 284W except for replacement purposes.
353	A high resistance insulated bracket type transmitter. Equipped with two T1A Cords, 9 1/4 inches. Case, bracket and arm finished in black. Replaces No. 350 Transmitter.
359	A centrally damped transmitter similar to No. 323 except it is equipped with a reinforced mouthpiece.
386	A low resistance insulated aluminum centrally damped local battery chest transmitter. Replaces No. 283 Transmitter.
601A	An insulated, low resistance, centrally damped, granular carbon transmitter equipped with a reinforced composition mouth piece and a black finished bell having a flat back arranged to mount on a transmitter bracket in the No. 336 Type Sub- scriber Set. Replaces No. 292W Transmitter.
603A	A black finished, centrally damped, insulated, low resistance, granular carbon transmitter unit mounted on a sbort black finished hollow transmitter arm which is in turn pivoted to a bracket in such a manner that the transmitter may be swung in a vertical plane. The transmitter unit is equipped with a reinforced mouth piece. Two No. 323 Cords, 8" long are connected to the transmitter terminals. Replaces No. 282W Transmitter.

Used

With No. 1001H Hand Set, Nos. 1278G, H and 1375B Telephone Sets.

Used in Nos. 1017C and E Tests Sets.

On No. 1001C Hand Set, Nos. 1330E, F, 1331E, F, 1332A, and E Portable Telephone Sets.

On Nos. 1317P, S, AH, AW, BK, CG, CN, CP, CR, CS, DU and 6023A Telephone Sets; Nos. 1020AL, U, 1040AL and U Desk Stands; and No. 1020CC Transmitter Arm.

With Nos. 1293AD, AE, AK, AL, BC, 1317W, AD, AE and BU Telephone Sets; Nos. 1020C, E, 1048DA, DB, DC, DD, GA, GB, GC, GD, 1120C, 1148DA, DB, DC, and DD Transmitter Arms; Nos. 1042AB, BR and 1142AB Desk Stands.

Magneto and central battery wall telephones, requiring insulated bracket type transmitter such as No. 1317BK Telephone Set.

With No. 1305AC Telephone Set.

With No. 375 Cord in dispatcher telephone sets.

With the Nos. 1336F and H Telephone Sets.

Railway train dispatching systems.

Transmitters (Continued)

Code No.	Description	Used
604A	Consists of a No. 354 type high resistance Transmitter mounted on a black finished hollow transmitter arm which is in turn pivoted to a bracket in such a manner that the transmitter can be swung in a vertical plane. Two No. 356 Cords pass through the transmitter arm with the cord tip ends connected to the transmitter terminals and the other end soldered to terminals in the back of the bracket. Replaces No. 286W Transmitter.	With No. 1312A Telephone Sets.
605A	A centrally damped, insulated, low resistance, granular carbon transmitter, having a nickel finished brass bell and a face plate of polished aluminum. Horn mouth piece. Arranged to mount on transmitter arms. Replaces No. 287W Trans- mitter.	Railway train dispatching systems.
606A	A black finished, centrally damped, insulated, high resistance, granular carbon transmitter. Equipped with a reinforced mouth piece and a bell having no lug and arranged to mount on transmitter arms. Replaces No. 228W Transmitter.	With the No. 1314A Telephone Set and Railway Train Dispatching Systems.
607A	Consists of a No. 606 type Transmitter mounted on a black finished transmitter arm, which is in turn pivoted to a bracket in such a manner that the transmitter may be swung in a vertical plane. A No. 13 Induction Coil is mounted in the bracket on which four insulated terminals and one grounded terminal are mounted. Leads from the four terminals of the induction coil are connected to the four insulated terminals on the bracket. Replaces No. 259 W Transmitter.	Railway Train Dispatching Systems.

TRANSMITTER ATTACHMENTS

Used for supporting chest type transmitter

Code No.	Description	Code No.	Description
2A	Buckle only,	3B	Buckles and black colored tape.
3A	Buckles and slate colored tape.	3C	Buckles and white colored tape.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS BATTERIES AND SUPPLIES

COLUMBIA RAY LABE POR TELEPHOR SERVICE

Dry Batteries for Telephone Service

COLUMBIA GRAY LABEL DRY CELLS

This battery is specially designed for telephone work. It is noted for its long life and satisfaction on light-drain service. A patented Eveready feature—the new metal top protects against leakage, bulging and breakage. Made in 6 inch size only. Falmestock Spring Binding Posts are furnished without extra charge when requested.

EVEREADY EXTRA LONG LIFE TELEPHONE CELLS

It is the longest lasting battery manufactured for telephone work. The many hours of extra service obtained from this battery more than compensates for its slight extra cost. It has the new metal seal top—all armored construction. Made in 6 inch size only.



Long Life

Gray Label

DESCRIPTION

Type Columbia Gray Label Eveready Long Life	Voltage	Diameter Inches 2½	Height Inches 6	Approx. Weight of Standard Packages lbs. 56	in Standard Package 25
Telephone	11/2	21/2	6	57	2.5

EVEREADY COLUMBIA DRY CELLS

Eveready Columbia No. 6 Dry Cell with the new Metal Top—a patented Eveready feature—protects against leakage, bulging and breakage. Renowned for its long life and excellent service for all Dry Cell uses. Its exceptionally long life and quick recuperation have made the Eveready No. 6 Dry Cell famous for ignition, radio and other heavy duty service. It is the best general purpose dry cell. Made in 6 inch size only.



Eveready Columbia

DESCRIPTION

Type	Voltage	Diameter Inches	Height Inches	of Standard Packages lbs.	Quantity in Standard Package
Type Eveready Columbia Dry Cell	11/2	$2\frac{1}{2}$	6	57	25

OVAL COLUMBIA BATTERIES FOR PORTABLE TELEPHONES

Low	Time	Mith	Dantable	Telephones
LOL	1 3500	VV IIIII	r or taote	regniones

ist	Size of Zinc Cans
No.	Inches
04	$1\frac{1}{4} \times 2\frac{1}{4} \times 4$

This Cell is equipped with Screw Binding Posts Weight Per Cell Ozs. 111/4

EVEREADY FLASHLIGHT BATTERIES

Size Overall

List No.	No. of Cells	Height Ins.	Width Ins.	Depth Ins.	Standard Package	Used
703	3	219/32	27/16	27/32	10	In the Nos. 1017B, C, E Test Sets and
790	2	413/16	1^{11}_{232}	-	120	No. 1375B Telephone Set. In the Nos. 1330E, F, 1331E and F Telephone Sets.
792	2	$2^{21}/_{32}$	121/32	27/32	i	In the Nos. 1332A and E Telephone Sets.

GraybaR.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS

Batteries and Supplies (Continued)



Complete Cell



Cell in Tray



Complete Renewal

EDISON PRIMARY BATTERIES AND RENEWALS

GENERAL

Edison Primary Batteries are furnished in capacities ranging from 75 to 1000 ampere hours. The 75, 250 and 500 ampere hour cells are the sizes best adapted to telephone work.

The characteristics of this battery, which make it particularly well suited for telephone service, are: uniform voltage under continuous discharge; extremely low and constant internal resistance; freedom from depreciation when the circuit is open; long life, with no attention between renewals; indicator panels in plates, which accurately show the approach of exhaustion, thus making it possible to maintain a circuit indefinitely without battery failure; immunity from polarization when continually discharged at or below recommended rates. Each cell consists of the following:

Permanent Parts

Jar, heat resisting glass. Porcelain cover. Set of terminal nuts and washers. Active Materials

Assembled Element (Electrodes). Can of Caustic Soda. Bottle of special battery oil.

For initial installations, complete cells are ordered which include all of the parts listed above. When a cell exhausts, the active materials (elements, caustic soda and oil) only are required, the permanent parts being continued in service indefinitely. The active materials are designated as a renewal by means of which an exhausted cell is restored to its original capacity.

Special heat resisting glass jars are used with Edison Primary Cells. These jars, which were developed for use with this form of battery, withstand the variations in temperatures to which they are subjected when the electrolyte is being mixed and are not affected by the solution. They make for convenience in checking the condition of the elements and solution lines.

The open circuit voltage of all Edison Primary Cells when new is 0.9. The closed circuit voltage is very constant and ranges from 0.6 to 0.65 depending on the rate of discharge and the degree of exhaustion.



Type S75



Type S252 Cell



Type S502 Cell



Type S50

Type S-75 Cell

The type 75 cell meets the demand for a small cell of dependable capacity, capable of delivering comparatively strong currents, practically free from shelf depreciation and selling at a low price. Inexpensive jars of ordinary glass are used and the entire cell is discarded at exhaustion. The overall dimensions are 3 inches in diameter by $7\frac{1}{2}$ inches high.

Batteries and Supplies (Continued)

Type S-75

The maximum recommended continuous current is 0.65 ampere. Maximum recommended intermittent current, 1 ampere. The type 75 is a highly efficient telephone cell and is also suitable for any service where the current requirements come within the recommended discharge limits. For voltage see general descriptive matter.

Type S-252 Cell

This cell is used extensively in railway telephone service for dispatchers and way station transmitters; in many cases the way station transmitter battery also supplies the current for selective ringing. It is a particularly well balanced cell, as regards relation of electrodes to electrolyte, with the element carried high in the jar and clear of the dense solution at the bottom of the cell.

The maximum recommended current is as follows: continuous 1 ampere, intermittent 1.5 amperes. For voltage see general descriptive matter.

Capacity 250 ampere hours. Rectangular heat resisting glass jar. Size overall, 3% x 5% x 12 inches. Jar only, inside, 2% x 5% x 10 inches.

Description

Type S-252 Cell Complete. Type S-250 Renewal Complete.

Separate Parts

Type 252 Jar.
Type 252 Cover.
Wing Nuts and Washers per set.
Type 8-250 Element.
Type 250 Caustic Soda, per can.
Type 250 Oil, per bottle.

Type S-502 and S-504 Cells

These cells have a capacity of 500 ampere hours and are furnished with either rectangular shaped jars (S-502) or barrel shaped jars (S-504). They are recommended for the dispatcher's and busy way station transmitters, the operators transmitter on magneto switchboards, interrupters and pole-changers, private branch exchanges, inter-communicating systems, etc. They provide the most economical battery for circuits that consume 500 ampere hours in two years or less, the cost of active materials, per unit of energy, being extremely low.

The maximum recommended continuous current is 2 amperes. Maximum recommended intermittent current is 3 amperes. For voltage see general descriptive matter.

Type S-502 Cell

Capacity 500 ampere hours. Rectangular heat resisting glass jar. Size overall, $5\frac{3}{4} \times 6\frac{3}{4} \times 12\frac{1}{4}$ inches. Jar only, inside dimensions $5 \times 6 \times 10$ inches.

Description

Type S-502 Cell. Type S-500 Renewal.

Type S-504 Cell

Capacity 500 ampere hours.

Barrel Shaped heat resisting glass jar.

Size overall, 7 x 11 ½ inches.

Jar only, inside dimensions 6 x 9 ½ inches.

Description

Type S-504 Cell. Type S-500 Renewal.

Separate Parts

Type 502 Jar.
Type 502 Cover.
Wing nuts and washers, per set.
Type S-500 Element.
Type 500 Caustic Soda, per can.
Type 500 Oil, per bottle.

Separate Parts

Type 504 Jar
Type 504 Cover.
Wing nuts and washers, per set.
Type S-500 Element.
Type 500 Caustic Soda, per can.
Type 500 Oil, per bottle.


GraybaR.

RAILWAY TRAIN DISPATCHING TELEPHONE SYSTEMS

Batteries and Supplies (Continued)

Exide-Chloride Storage Batteries

In Sealed Glass



5 Cell BTMH2 Unit

RATED CAPACITIES

	In Ampere Hours					
	At	At	At			
	72-Hour	8-Hour	3-Hour			
Type	Rate to	Rate to	Rate to			
Cell	1.85 Volts	1.75 Volts	1.75 Volts			
BTMH-2	8.4	6	4.4			
CTMH-2	16.8	12	8.7			
PTMH-2	33.6	24	16.8			
ETMH-2	50.4	36	24.0			

This type of Exide-Chloride is especially suitable for service where a small capacity is required. The positive plate is the well known Manchester type and the negative plate is the familiar Box Negative type. Units are assembled, sealed and charged and filled with electrolyte and include the necessary bolt connectors on the terminal cells of each unit. The PTMH-2 and ETMH-2 units are equipped with chest handles on the crates.

TABLE OF DIMENSIONS AND WEIGHTS

Number of Cells in Crates	BTMH-2 UNITS					CTMH-2 UNITS				
	Overall Dimensions in Inches			Approximate Weight in Pounds					Approximate Weight in Pounds	
				Complete Unit A.S. & C.	Packed for L.C.L.	Overall Dimensions in Inches			Complete Unit A.S. & C.	Packed for L.C.L.
	Length	Width	Height	Unpacked	Shipment	Length	Width	Height	Unpacked	Shipmen
2 Cells—1 Row 3 Cells—1 Row 4 Cells—1 Row 5 Cells—1 Row 6 Cells—1 Row 9 Cells—1 Row 10 Cells—1 Row 10 Cells—1 Row 11 Cells—1 Row 12 Cells—1 Row 12 Cells—1 Row 13 Cells—1 Row 14 Cells—1 Row 15 Cells—2 Rows 16 Cells—2 Rows 16 Cells—2 Rows 17 Cells—2 Rows 18 Cells—2 Rows 19 Cells—2 Rows 11 Cells—2 Rows 11 Cells—2 Rows 12 Cells—2 Rows 12 Cells—2 Rows 13 Cells—2 Rows 14 Cells—2 Rows 15 Cells—16 Rows 16 Cells—17 Crate	514 77% 103% 123% 143% 173% 2113% 2413% 26538 2813% 103% 123% 1438 1438 1438 2536	4444444449999999	9999999999999999999	11.0 16.0 21.0 26.0 31.0 36.0 42.0 46.0 51.0 51.0 46.0 52.0 46.0 52.0 56.0 61.0	15 23 30 37 44 53 61 67 74 88 45 61 70 75 83 88	6 18 8 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	7 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	11 75 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	25.0 36.0 47.0 58.0 69.0 80.0 91.0 102.0 113.0 70.0 92.0 103.0 125.0 125.0 135.0	33 45 59 73 87 102 115 129 143 156 170 77 116 133 144 160 171

Electrolyte per BTMH-2 Cell-1 pound.

Electrolyte per CTMH-2 Cell-31/4 pounds.

Exide-Chloride Storage Batteries (Continued)

TABLE OF DIMENSIONS AND WEIGHTS

	A	NITS	ETMH-2 UNITS							
Number of Cells in Crates				Approximate Weight in Pounds					Approx Weight in	cimate Pounds
	Overall Dimensions in Inches			Complete Unit A.S. & C.	Packed for L.C.L.	Overall Dimensions in Inches			Complete Unit A.S. & C.	Packed for L.C.L.
	Length	Width	Height	Unpacked	Shipment	Length	Width	Height	Unpacked	Shipment
2 Cells—1 Row 3 Cells—1 Row 4 Cells—1 Row 5 Cells—1 Row 6 Cells—1 Row 7 Cells—1 Row 9 Cells—1 Row 10 Cells—1 Row 11 Cells—1 Row 12 Cells—2 Rows 8 Cells—2 Rows 9 Cells—2 Rows 10 Cells—2 Rows 11 Cells—2 Rows 11 Cells—2 Rows	61-30 97/8 1213/6 153/4 1811/6 24-3/6 24-3/6 307/8 36-7/6 33-8/8 1213/6 153/4 1811/6 1811/6	55 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8	16% 16% 16% 16% 16% 16% 16% 16% 16% 16%	42 60 78 97 115 133 152 170 188 206 225 115 174 192 211 229	52 73 95 117 140 162 184 207 228 249 271 143 188 215 232 258 275 21	79.66 66 66 66 66 66 66 66 66 66 66 66 66	10% 10% 10% 10% 10% 10% 10% 10% 10% 10%	16 3 3 4 4 1 1 6 3 3 4 4 1 1 6 3 3 4 4 1 1 6 3 3 4 4 1 1 6 3 3 4 4 1 1 6 3 3 4 4 1 1 6 3 3 4 1 1 6 3 4 1	63 91 118 146 173 201 230 258 286 178 235 263 290 318 345 26	75 105 137 168 201 233 266 297 329 206 270 306 333 368 395

Electrolyte per PTMH-2 Cells, 434 pounds.

Electrolyte per ETMH-2 Cell-7% pounds.

INDEX

Material Page	Material Page
Adapters, Condenser	Key Spaces, Selector 94
Amplifiers	Layout of System
Apparatus Cases, Selector	Lead Covered Cable
Attachments, Foot Switch 96	Line Poles
Attachments, Transmitter	Lond Ringing Extension Bells
Batteries and Supplies	Loud Speaking Telephone Equipment 18 20, 103
Battery Boxes	Micas, Protector 74
Battery Requirements	Mountings, Gong 51
Binding Posts. 30	Mountings, Jack
Booth Switches	Plugs
Boxes, Battery	Poles, Line
Boxes, Desk Set (Subscriber Sets)15, 17, 47, 48	Portable Telephone Sets 100 101
Boxes, Hand Generator	Posts, Binding
Brackets, Condenser	Protectors
Brackets, Transmitter 106	Protector Micas
Cables	Push Button Switches
Cable Terminals	Punchings, Terminal
Cases, Selector Reparatus	Receivers
Circuit Breakers	Relays 7, 75
Code Cattings for Salartons 10	Repeating Coils
Coils, Induction	Resistances
Coils, Resistance	Retardation Coils
Coils. Retardation	Ringers
Combined Jacks and Signals	Selector Annaratus Cases 7 88
Condensers 34-36	Selector Keys8-13, 89-93
Condensers, Adapters, Brackets, Straps 37	Selector Key Cases 94
Connecting Blocks 38 Cords 39-41	Selector Key Spaces 94 Selector Sets 15, 94, 95
Cord Tips	Sets Telephone 27 08-109
Designation Strips	Sets, Test. 27, 107, 108 Set, Time Sending. 14, 104 Signals, Combined with Jacks. 65, 66
Desk Stands	Set, Time Sending
Dispatcher's Station Circuit	Stands, Desk
Dry Batteries	Straps, Condenser
Extension Bells	Strips, Designation
Foot Switches	Subscriber Sets(See Desk Set Boxes) Switches, Booth
Foot Switch Attachments	Switches, Foot
Fuses 48, 49	Switches, Foot. 20, 96 Switches, Push Button 97
Generators 50 Generator Boxes 50	Switch Hooks96, 97
Gongs, Gong Mountings 51	Telephone, Loud Speaking 18, 20, 103 Telephone Sets 27, 98-102
Hand Generator, Boxes	" (Portable) 100 101
Hand Sets	Telephones, Weatherproof 102 Terminals, Cable. 31-33
Head Bands, Receiver. 78 Head Sets. 52	Terminals, Cable
Hook Switches	Terminal Punchings 30 Test Sets 27, 107, 108
Howlers 52	Time Sending Set
Indicator Fuses48, 49	Tips, Cord
Interior Cable 52, 53	Tools 106
Interior Cable 31 Interrupters 52, 53	Transformers 23-26, 104 Transmitters 109, 110
Jacks	Transmitter Arms
Jack Boxes 15, 62-65 Jacks for Pole Mounting 62	Transmitter Arm Brackets
Jack Mountings	Transmitter Attachments 110 Transmitter Brackets 106
Jack Mountings 66 Jacks, Combined Jacks and Signals 65, 66	Tubular Fuses
Reys	Vacuum Tube Rectifier 21 22 74
Key Cases, Selector	Way Station Circuit 50
Keys, Selector	Way Station Equipment. 15-18 Weatherproof Telephones 102
	102

DISTRIBUTOR IN THE UNITED STATES

GraybaR

Akron Albany Asheville Atlanta Baltimore Beaumont Birmingham Boston Brooklyn Buffalo Charlotte Chicago Cincinnati Cleveland Columbus Dallas
Davenport
Dayton
Denver
Detroit
Duluth
Durham
Flint
Fort Worth
Grand Rapids
Hammond
Harrisburg
Hartford
Houston
Indianapolis

Jacksonville
Kansas City
Knoxville
Los Angeles
Louisville
Memphis
Miami
Milwaukee
Minneapolis
Mount Vernon
Nashville
Newark
New Haven
New Orleans
New York (2)

Norfolk Oakland Oklahoma City Omaha Philadelphia Pittsburgh Portland Providence Reading Richmond Roanokc Rochester St. Louis St. Paul Salt Lake City San Antonio San Francisco Savannah Seattle Spokane Syracuse Tacoma Tampa Toledo Washington Wichita Worcester Youngstown

A NATIONAL ELECTRIC SERVICE

DISTRIBUTOR FOR CANADA AND NEWFOUNDLAND



General Sales Offices: 1261 Shearer Street, Montreal, P. Q.

STIDHN N.B. HALIFAX QUEBEC MONTREAL OTTAWA TORONTO HAMILTON LONDON WINDSOR NEW LISKEARD SUBBURY WINNIPES RESINA CALGARY EDMONTON VANCOUVER

A NATIONAL ELECTRICAL SERVICE

FOREIGN DISTRIBUTORS

International Standard Electric Corporation

67 Broad Street

New York, U.S.A.

